

[Manuals.plus](#) /

› [Armitron](#) /

› Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch Instruction Manual

Armitron 75/2447CHGPHY

Armitron Women's Diamond-Accented Leather Strap Watch Instruction Manual

Model: 75/2447CHGPHY | Brand: Armitron

INTRODUCTION

Thank you for choosing the Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch. This timepiece combines elegant design with reliable Japanese quartz movement, featuring a genuine diamond accent at the 12 o'clock position and a scratch-resistant mineral crystal lens. This manual provides essential information for the proper setup, operation, and care of your new watch to ensure its longevity and performance.

PRODUCT OVERVIEW



Figure 1: Front view of the Armitron 75/2447 watch, showcasing the light champagne sunray dial, gold-tone hands, and the diamond accent at 12 o'clock.

Your Armitron watch features a sophisticated design with a honey brown leather strap and a gold-tone case. The dial is a light champagne sunray finish, complemented by gold-tone hands and markers. A genuine diamond is set at the 12 o'clock position, adding a touch of elegance. The watch is protected by a curved wall-to-wall mineral crystal lens, designed for scratch resistance.

- **Dial:** Light champagne sunray with gold-tone hands and markers.
- **Diamond Accent:** Genuine diamond at 12 o'clock.
- **Crystal:** Curved wall-to-wall mineral crystal, scratch resistant.
- **Case:** Gold-tone finish.
- **Strap:** Honey brown leather with buckle closure.
- **Movement:** Japanese quartz movement for accurate timekeeping.

SETUP AND TIME SETTING

Setting the Time



Figure 2: Side view of the watch, highlighting the crown for time adjustment.

1. Locate the **crown** (the small knob on the right side of the watch case).
2. Gently **pull the crown outwards** to the time-setting position. You may feel a slight click.
3. **Rotate the crown** either clockwise or counter-clockwise to move the hour and minute hands until the desired time is displayed.
4. Once the time is set, **push the crown back inwards** firmly against the watch case. This will start the watch movement and ensure it keeps accurate time.

CARE AND MAINTENANCE

General Care

To maintain the appearance and functionality of your Armitron watch, follow these care guidelines:

- Wipe the watch case and crystal with a soft, dry cloth to remove dust and smudges.
- For the leather strap, avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture, as these can cause the leather to dry out, crack, or discolor.
- Clean the leather strap with a damp cloth and mild soap if necessary, then wipe dry immediately. Do not immerse

the strap in water.

Battery Replacement

Your watch is powered by a Japanese quartz movement, which requires a battery. When the watch stops running, it indicates that the battery needs to be replaced. It is highly recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and prevent damage to the internal components.

Water Resistance

IMPORTANT: This watch is NOT water resistant.

Avoid all contact with water, including showering, swimming, or exposure to rain. Water exposure can cause severe damage to the watch's internal mechanism and is not covered under warranty.

TROUBLESHOOTING

If you encounter any issues with your watch, please refer to the following common troubleshooting tips:

Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in against the watch case. If it is pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Refer to the "Battery Replacement" section and consider having the battery replaced by a professional.

Inaccurate Time

- **Crown Position:** Verify the crown is fully pushed in. If it's not completely seated, the timekeeping can be affected.
- **Magnetic Fields:** Strong magnetic fields can temporarily affect quartz watch accuracy. Move the watch away from magnetic sources (e.g., speakers, large electronics).
- **Battery Life:** A low battery can sometimes cause the watch to run slow or erratically before stopping completely.

If these steps do not resolve the issue, please contact Armitron customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	75/2447CHGPHY
Brand	Armitron
Movement	Japanese Quartz
Crystal	Curved Wall-to-Wall Mineral Crystal
Dial Features	Light Champagne Sunray, Genuine Diamond at 12 o'clock
Strap Material	Honey Brown Leather
Water Resistance	Not Water Resistant
Package Dimensions	4.21 x 3.23 x 2.76 inches
Item Weight	6.24 ounces

Country of Origin

China



Figure 3: The watch is presented in a durable Armitron branded box, ensuring protection during transit and storage.

WARRANTY AND SUPPORT

Armitron watches are manufactured with quality and precision. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Armitron website. For technical support, service, or inquiries about replacement parts, please contact Armitron customer service directly.

Manufacturer: Armitron

For the most up-to-date contact information and support resources, please visit www.armitron.com.

© 2025 Armitron. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question