

[Manuals.plus](#) /

› [Silonn](#) /

› Silonn Ice Maker Countertop Instruction Manual

Silonn SLIM09

Silonn Ice Maker Countertop Instruction Manual

MODEL: SLIM09



The Silonn Ice Maker Countertop, Model SLIM09, in black, ready for use.

Product Overview

The Silonn Countertop Ice Maker (Model SLIM09) is designed for convenient and efficient ice production in various settings such as home kitchens, offices, bars, and parties. It produces 9 bullet-shaped ice cubes in as little as 6 minutes, with a maximum ice capacity of 26 pounds in 24 hours. This machine offers two sizes of ice cubes to suit different needs and features a self-cleaning function for easy maintenance. Its compact and portable design, complete with a sturdy handle, allows for easy relocation.

- **Fast Ice Production:** Produces 9 bullet-shaped ice cubes in 6-8 minutes.
- **High Capacity:** Up to 26 pounds of ice in 24 hours.
- **Dual Ice Sizes:** Offers small and large bullet ice cubes.
- **Portable Design:** Compact size (11 x 9 x 11 inches) with a sturdy handle for easy carrying.
- **Quiet Operation:** Operates at less than 35dB, comparable to a working refrigerator.

- **Self-Cleaning Function:** Simplifies maintenance with an automatic cleaning cycle.
- **User-Friendly Indicators:** Transparent lid and sensor for monitoring ice levels and water status.

Setup Instructions

1. **Unpacking:** Carefully remove the ice maker from its packaging. Ensure all components, including the ice scoop and ice basket, are present.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
3. **Initial Standby:** It is crucial to let the ice maker stand upright for at least 24 hours before plugging it in. This allows any refrigerant and oils to settle properly, preventing potential damage to the compressor.
4. **Cleaning:** Before first use, clean the interior of the ice maker. Remove the ice basket and wipe the interior with a soft cloth dampened with warm water and a mild detergent. Rinse thoroughly and wipe dry.
5. **Add Water:** Open the top lid and fill the water reservoir with clean, filtered water up to the "MAX" fill line. Do not overfill.
6. **Power Connection:** Plug the ice maker into a grounded electrical outlet.



The internal view of the Silonn Ice Maker, highlighting its efficient design for quick ice production.

Your browser does not support the video tag.

Official video demonstrating the water filling process and initial ice production cycle of the Silonn Ice Maker.

Operating Instructions

1. **Power On:** Press the "ON/OFF CLEAN" button to turn on the ice maker. The "POWER" indicator light will illuminate.

2. **Select Ice Size:** Press the "SELECT" button to choose between small (S) or large (L) ice cubes. The corresponding indicator light will illuminate.
 3. **Ice Production:** The machine will automatically begin the ice-making cycle. Ice cubes will be ready in approximately 6-8 minutes, depending on the selected size and ambient temperature.
 4. **Ice Full Indicator:** The "ICE FULL" indicator light will illuminate when the ice basket is full, and the machine will automatically pause ice production.
 5. **Add Water Indicator:** The "ADD WATER" indicator light will illuminate when the water reservoir is low, prompting you to refill it. The machine will pause until water is added.
 6. **Collecting Ice:** Use the provided ice scoop to remove ice from the basket. For best results, transfer freshly made ice to a freezer for storage, as the ice maker is not designed to keep ice frozen for extended periods.
 7. **Power Off:** Press the "ON/OFF CLEAN" button again to turn off the ice maker when not in use.
-

One-button Ice Ready



The user-friendly control panel of the Silonn Ice Maker, featuring clear indicator lights and simple buttons for operation.

Two Ice Cube Sizes



Large Size
25*26mm



Small Size
22*24mm



Visual representation of the two available ice cube sizes: small (22x24mm) and large (25x26mm).

Maintenance

1. **Regular Cleaning:** For optimal performance and hygiene, clean the ice maker regularly, ideally once a week or every two weeks depending on usage.
2. **Self-Cleaning Function:**

- Ensure the water reservoir is filled with clean water.
 - Press and hold the "ON/OFF CLEAN" button for 5 seconds. The "ADD WATER" and "ICE FULL" indicator lights will flash alternately, indicating the self-cleaning cycle has started.
 - The self-cleaning process takes approximately 30 minutes. The machine will circulate water through its internal components.
 - Once the cycle is complete, the machine will automatically turn off.
3. **Draining Water:** After cleaning or when storing the machine, drain any remaining water from the reservoir. Locate the drain plug at the bottom of the unit, remove it, and allow the water to flow out into a sink or container. Replace the plug securely.
4. **Exterior Cleaning:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
5. **Storage:** If storing the ice maker for an extended period, ensure it is completely dry inside and out to prevent mold or mildew growth. Store in a cool, dry place.
-

Self-cleaning Function



1 Press



30 Mins



The self-cleaning function of the Silonn Ice Maker, illustrating the internal water circulation for thorough cleaning.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
"ADD WATER" indicator light is on.	Water reservoir is empty or water level is too low.	Add clean water to the reservoir up to the "MAX" fill line. The light should turn off and ice production will resume.
"ICE FULL" indicator light is on.	Ice basket is full.	Remove ice from the basket. The light should turn off and ice production will resume.
Ice maker is not producing ice.	No power, insufficient water, or internal malfunction.	Check power connection. Ensure water is filled. If problem persists, contact customer support.
Ice cubes are too small or cloudy.	Water temperature is too high or mineral buildup.	Use colder water. Perform a self-cleaning cycle. Consider using distilled or purified water.
Unusual noise during operation.	Normal operation sounds (fan, water pump) or potential obstruction.	Ensure the unit is on a stable surface. Check for any obstructions in the ice-making area. If noise is excessive or unusual, contact customer support.

Specifications

Feature	Detail
Brand	Silonn
Model Name	Portable ice maker machine
Item Model Number	SLIM09
Product Dimensions	11.4"D x 8.7"W x 11.5"H
Capacity	26 Pounds (ice production in 24 hours)
Wattage	160W
Ice-making Current	1.5A
Ice-harvest Current	1.8A
Country of Origin	China
What's in the Box	Ice maker, Ice Scoop, Ice Basket, User manual

Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual provided with your Silonn Ice Maker. A digital version of the user manual can be accessed via the following link:

[Download User Manual \(PDF\)](#)

For further assistance or inquiries, please visit the official Silonn store on Amazon or contact their customer service directly.

[Visit Silonn Store](#)

© 2025 Silonn. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

[Submit question](#)