

[Manuals.plus](#) /

› [Linstaine](#) /

› Linstaine Dimmable Candle Warmer Lamp User Manual

Linstaine Black

Linstaine Dimmable Candle Warmer Lamp User Manual

Model: Black

Brand: Linstaine

INTRODUCTION

Thank you for purchasing the Linstaine Dimmable Candle Warmer Lamp. This innovative lamp provides a safe and efficient way to enjoy your scented jar candles without an open flame, smoke, or soot. Its adjustable height and dimmable light allow for customized ambiance and compatibility with various candle sizes. Please read this manual carefully before use to ensure proper operation and maintenance.

Safety Information

- For indoor use only.
- Do not immerse the lamp in water or any other liquid.
- Keep out of reach of children and pets.
- Ensure the lamp is placed on a stable, flat, heat-resistant surface.
- Do not touch the bulb or lamp shade immediately after use, as they may be hot.
- Unplug the lamp before cleaning or replacing the bulb.
- Use only the specified GU10 bulb (35 watts).
- Do not use with candles that exceed the maximum recommended height (6.7 inches).

Safe for Children & Pets

✓ No-Flame ✓ No-Soot ✓ No-Smoke



The Linstaine candle warmer lamp is designed for safety, operating without an open flame, smoke, or soot, making it suitable for homes with children and pets.

PRODUCT COMPONENTS

Before assembly, ensure all parts are present:

- Candle Warmer Lamp Base

- Adjustable Lamp Pole with Curved Arm
- GU10 Bulb (pre-installed or included)
- Power Cord with In-line Controller (Timer & Dimmer)



The complete Linstaine Dimmable Candle Warmer Lamp, showcasing its elegant design and functional components.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place the Base:** Position the lamp base on a stable, flat, and heat-resistant surface.
3. **Adjust Height:** Loosen the height adjustment knob on the lamp pole. Adjust the height of the curved arm to accommodate your candle. Ensure there is sufficient space between the bulb and the top of the candle for optimal melting (typically 1-2 inches). Tighten the knob securely. The lamp is designed to fit candles up to 6.7 inches tall.
4. **Insert Candle:** Place your scented jar candle directly onto the center of the lamp base.
5. **Connect Power:** Plug the power cord into a standard electrical outlet.

Adjustable Height

Fit candles up to 6.7in



The lamp's adjustable height feature allows it to accommodate various candle sizes, ensuring optimal melting performance.

OPERATING INSTRUCTIONS

Power On/Off and Brightness Adjustment

The lamp is controlled by an in-line switch on the power cord.

1. **Power On/Off:** Press the power button (●) to turn the lamp on or off.
2. **Adjust Brightness:** Use the '+' and '-' buttons to cycle through the 7 levels of brightness. Adjust the light intensity to control the melting speed of your candle and set the desired ambiance.

Timer Function

The built-in timer allows you to set the lamp to automatically turn off after a specified duration.

1. **Activate Timer:** Press the timer button () repeatedly to select a timer setting: 2 hours, 4 hours, or 8 hours.
2. **Timer Indication:** An indicator light on the controller will illuminate next to the selected time (2H, 4H, 8H).
3. **Cancel Timer:** To cancel the timer, press the timer button until no indicator light is illuminated, or simply turn off the lamp.

Timer for Auto Shut Off

Adjustable Brightness



The in-line controller provides easy access to power, brightness adjustment, and timer settings for convenient operation.

MAINTENANCE

Cleaning

To maintain the appearance and functionality of your candle warmer lamp:

- Always unplug the lamp and allow it to cool completely before cleaning.
- Wipe the lamp base and pole with a soft, dry cloth.
- For the glass shade, use a soft, damp cloth and mild detergent if necessary, then dry thoroughly.
- Do not use abrasive cleaners or solvents.

Bulb Replacement

The lamp uses a GU10 bulb (35 watts). If the bulb needs replacement:

1. **Unplug:** Ensure the lamp is unplugged from the power outlet and the bulb has cooled down.
2. **Remove Old Bulb:** Gently push the GU10 bulb into its socket and twist counter-clockwise to release it.
3. **Insert New Bulb:** Align the pins of the new GU10 bulb with the slots in the socket, push in gently, and twist clockwise to secure it.
4. **Test:** Plug in the lamp and test the new bulb.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; Power outlet issue; Bulb is loose or burnt out.	Check power connection; Test outlet with another device; Ensure bulb is securely seated or replace bulb.
Candle wax not melting.	Bulb brightness too low; Bulb too far from candle; Candle type not suitable.	Increase brightness using '+' button; Adjust lamp height closer to the candle (ensure safety distance); Use jar candles designed for melting.
Timer not working.	Timer not activated correctly.	Press the timer button until the desired time (2H, 4H, or 8H) is indicated.

SPECIFICATIONS

- **Brand:** Linstaine
- **Model:** Black
- **Product Dimensions:** 7.17"D x 7.17"W x 14.37"H
- **Lamp Type:** GU10 Bulb, 3000K
- **Wattage:** 35 watts
- **Power Source:** Corded Electric
- **Control Method:** Touch (via in-line controller)
- **Special Features:** Dimmable, Timer (2/4/8 hours), Adjustable Height
- **Material:** Metal
- **Color:** Black
- **Item Weight:** 1.68 pounds

WARRANTY AND SUPPORT

Linstaine products are manufactured with quality and durability in mind. For specific warranty details and customer support, please refer to the warranty card included with your purchase or visit the official Linstaine store on Amazon:

[Linstaine Official Store](#)

For technical assistance or inquiries, please contact Linstaine customer service through the Amazon platform or via the contact information provided in your product packaging.