

[Manuals.plus](#) /

› [Darkaway](#) /

› Darkaway 11-inch Gold Flush Mount Ceiling Light Fixture (Model 6T1F) Instruction Manual

Darkaway 6T1F

Darkaway 11-inch Gold Flush Mount Ceiling Light Fixture (Model 6T1F) Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Darkaway 11-inch Gold Flush Mount Ceiling Light Fixture, Model 6T1F. Please read this manual thoroughly before installation and retain it for future reference.



Image 1.1: The Darkaway 11-inch Gold Flush Mount Ceiling Light Fixture. This fixture features a gold finish and a seeded glass shade, designed for flush mounting on ceilings.

2. SAFETY INFORMATION

WARNING: To avoid electric shock, always turn off the power at the main circuit breaker or fuse box before beginning installation or performing any maintenance. Consult a qualified electrician if you are unsure about the installation process.

- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- Wear safety glasses and gloves during installation.
- Do not exceed the recommended wattage for bulbs (60-watt max E26 base).
- This fixture is suitable for both indoor and outdoor use, but ensure proper sealing for outdoor applications to prevent moisture ingress.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Light Fixture Assembly (Canopy, Socket Assembly, Glass Shade)
- Mounting Hardware (Mounting bracket, screws, wire nuts)
- Instruction Manual

Note: Bulbs are not included and must be purchased separately.

4. SPECIFICATIONS

Feature	Specification
Brand	Darkaway
Model Name	6T1F
Dimensions (L x W x H)	11" x 11" x 6" (approximate)
Color	Gold
Material	Metal, Seeded Glass
Light Source Type	LED, CFL, Incandescent, Halogen
Bulb Base	E26
Max Wattage per Bulb	60 Watts
Number of Light Sources	2

Voltage	120 Volts
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor, Outdoor
Item Weight	4.92 Pounds




Image 4.1: Product dimensions for the 11-inch fixture.

5. SETUP AND INSTALLATION

Follow these steps to install your ceiling light fixture:

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the light fixture's location and turn off the power. Verify power is off using a voltage tester.
2. **Prepare Mounting:** Attach the mounting bracket to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
3. **Wire Connections:** Connect the fixture's wires to the corresponding house wires using wire nuts. Typically, connect black to black (live), white to white (neutral), and green or bare copper to green or bare copper (ground). Ensure all connections are secure.
4. **Mount Fixture:** Carefully align the fixture's canopy with the mounting bracket and secure it with the provided screws or decorative nuts.
5. **Install Bulbs:** Screw two E26 base bulbs (not included, 60-watt max each) into the sockets.

6. **Attach Glass Shade:** Carefully place the seeded glass shade onto the fixture and secure it with the finial or retaining ring. Do not overtighten.
7. **Restore Power:** Turn the power back on at the circuit breaker or fuse box. Test the light fixture.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the bulb installation process for the Darkaway Gold Ceiling Light Fixture. It shows how to screw in the E26 base bulbs and secure the seeded glass shade.



Image 5.2: Detailed view of the fixture's internal components, including the two E26 bulb sockets.

6. OPERATING INSTRUCTIONS

Once installed, operate the light fixture using a standard wall switch connected to the circuit. Ensure the correct type and wattage of bulbs are installed for optimal performance and safety.



Image 6.1: The light fixture shown in both off and on states.

7. MAINTENANCE

Regular maintenance ensures the longevity and appearance of your fixture:

- **Cleaning:** Turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. For the glass shade, a damp cloth with mild soap can be used, followed by drying with a clean, soft cloth. Avoid abrasive cleaners or solvents.
- **Bulb Replacement:** Turn off the power. Allow bulbs to cool completely before attempting to replace them. Unscrew the old bulb and screw in a new E26 base bulb (60-watt max).
- **Inspection:** Periodically check for any loose connections or signs of wear. If any issues are found, turn off power and consult a qualified electrician.

8. TROUBLESHOOTING

If your light fixture is not functioning correctly, refer to the following common issues and solutions:

- **Light does not turn on:**

- Check if the power is on at the circuit breaker.
- Ensure the bulb is screwed in tightly and is not burnt out. Replace if necessary.
- Verify wire connections are secure.

- **Flickering light:**

- Ensure the bulb is fully screwed into the socket.
- Check for loose wire connections.
- Confirm the bulb type is compatible with the fixture and any dimmer switches (if applicable).

- **Glass shade is loose:**

- Gently tighten the finial or retaining ring that secures the glass shade. Do not overtighten.

If problems persist, contact customer support or a qualified electrician.

9. WARRANTY AND SUPPORT

Darkaway products are designed for quality and durability. For specific warranty details, please refer to the product packaging or contact Darkaway customer service directly. Keep your purchase receipt as proof of purchase.

Customer Support: For technical assistance, replacement parts, or warranty inquiries, please visit the official Darkaway website or contact their customer service department. Contact information can typically be found on the product packaging or on the brand's online store.

You can visit the Darkaway Store for more information:[Darkaway Store on Amazon](#)

© 2025 Darkaway. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question