



Manuals.plus /

› BOMOVA /

› BOMOVA Heated Electric Blanket User Manual

BOMOVA Heated Throw

BOMOVA Heated Electric Blanket User Manual

Model: Heated Throw

Brand: BOMOVA

1. INTRODUCTION

Thank you for choosing the BOMOVA Heated Electric Blanket. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new electric blanket. Please read all instructions carefully before use and retain this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

- Always disconnect the power cord from the electrical outlet when the blanket is not in use.
- Do not use this blanket with an infant, a child, an incapacitated person, a paraplegic, a quadriplegic, a diabetic, anyone insensitive to heat, or anyone who cannot clearly understand the instructions.
- Avoid folding, creasing, or bunching the blanket during use, as this can cause overheating.
- Do not use pins or other metallic objects with this blanket. They may damage the electrical wiring.
- The blanket features an Overheat Protection system that automatically shuts off power if it detects unsafe temperatures.
- Before cleaning, always unplug the controller from the blanket and the wall outlet, and allow it to cool completely.

3. PRODUCT FEATURES

- **Adjustable Temperature Settings:** 10 levels of temperature control (86°F - 113°F) for personalized warmth.
- **Automatic Shut-off Timer:** Set the blanket to automatically turn off after 1 to 8 hours, ensuring safety and energy conservation.
- **Digital Display Controller:** Intuitive display shows current temperature and timer settings.
- **Premium Material:** Constructed with 200gsm flannel and 180gsm snow flannel for a soft, cozy, and durable feel. The heating wires are designed to be thin and barely noticeable.

- **Overheat Protection:** Built-in safety feature to prevent overheating.
- **Machine Washable:** Easy to clean and maintain (controller must be removed).
- **Flexible Use:** Long power cords allow for use in various locations such as beds, sofas, study rooms, and offices. (Throw Size: 7.87ft power cord; Twin, Full, Queen, King Sizes: 14.44ft power cord).

4. SETUP INSTRUCTIONS

1. **Unpack the Blanket:** Carefully remove the electric blanket and its components from the packaging.
2. **Connect the Controller:** Locate the connector on the blanket and firmly plug the controller's cord into it. Ensure a secure connection.
3. **Position the Blanket:** Spread the blanket evenly over your bed or desired surface. Ensure there are no folds, creases, or bunched areas.
4. **Plug into Power:** Insert the power plug into a standard 110-120V AC electrical wall outlet.



Image: Diagram illustrating the connection of the controller to the blanket.

5. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the digital display controller to turn on the blanket. The display will illuminate, showing the default temperature and timer settings.

2. **Adjust Temperature:** Use the temperature control button (often marked with a thermometer icon) to cycle through the 10 available heat levels (L1 to H9, or 86°F to 113°F). Select your desired warmth level.
3. **Set Timer:** Use the timer button (often marked with a clock icon) to select the automatic shut-off duration. Options typically range from 1 to 8 hours. The blanket will turn off automatically after the selected time.
4. **Power Off:** Press the power button again to turn off the blanket. The display will turn off.



Image: A person adjusting the digital controller for the electric blanket, showing temperature and timer settings.

6. MAINTENANCE AND CARE

Proper care ensures the longevity and safe operation of your electric blanket.

- **Before Washing:** Always disconnect the controller(s) from the blanket and the wall outlet. Allow the blanket and controller to cool completely.
- **Machine Washing:** Wash on a gentle cycle with cold water. Do not bleach.
- **Drying:** Tumble dry on low heat or air dry. Ensure the blanket is completely dry before reconnecting the controller or storing. Do not iron.
- **Storage:** Store the blanket in a cool, dry place. Avoid folding tightly or placing heavy objects on it, which could damage the internal wiring.

EASY TO CLEAN AND CARE



Note: Please remove the controller when washing to avoid damage

Image: A washing machine containing an electric blanket, with a reminder to remove the controller before washing.

7. TROUBLESHOOTING

If your electric blanket is not functioning as expected, please check the following:

- **No Power/Not Heating:** Ensure the power cord is securely plugged into both the blanket and a working electrical outlet. Check if the outlet is functional by plugging in another appliance.
- **Controller Error Code:** If the controller displays an error code (e.g., 'F2' as mentioned in some user experiences), unplug the blanket from the wall outlet, then disconnect and reconnect the controller to the blanket. Plug it back into the wall outlet. If the error persists, contact customer support.
- **Uneven Heating:** Ensure the blanket is spread flat without any folds or creases that might impede heat distribution.

8. SPECIFICATIONS

Brand	BOMOVA
Model Number	Heated Throw
Material	Sherpa (200gsm flannel + 180gsm snow flannel)
Color	Blue
Product Dimensions (Queen Size)	84"L x 90"W
Item Weight	7.61 pounds
Special Features	Adjustable Temperature, Automatic Shut-off, Overheat Protection
Power Cord Length (Throw Size)	7.87 ft
Power Cord Length (Twin, Full, Queen, King Sizes)	14.44 ft
UPC	768472983756

Note: Specifications may vary slightly depending on the specific size and variant of the BOMOVA Heated Electric Blanket.

PRODUCT SIZE






Image: Visual representation of various blanket sizes and their corresponding dimensions.

9. WARRANTY AND SUPPORT

For warranty information, product support, or any questions not covered in this manual, please contact BOMOVA customer service. Refer to the product packaging or the official BOMOVA website for contact details.