

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [sparefixd](#) /

› [Instruction Manual for sparefixd Bosch Door Shelf Rack Tray \(Part 00439684\)](#)

sparefixd 00439684

Instruction Manual

sparefixd Door Shelf Rack Tray for Bosch Fridges & Freezers

INTRODUCTION

This manual provides essential information for the installation, maintenance, and compatibility of your new sparefixd Door Shelf Rack Tray, designed as an equivalent replacement for Bosch fridge and freezer models. Please read these instructions carefully before proceeding with installation.

COMPATIBILITY

This sparefixd door shelf is an equivalent replacement for Bosch Part Number 00439684. It is compatible with a wide range of Bosch fridge and freezer models. To ensure proper fitment, please verify your appliance's model number against the list below. If your model is not listed, please cross-reference with the original part number.

Compatible Models Include:

- KSU40622NE/12, KSU40622NE/13, KSU40622NE/14, KSU40622NE/15, KSU40622NE/16
- KSU40623/01, KSU40623/02, KSU40623/03, KSU40623/04, KSU40623/05, KSU40623/06, KSU40623/08
- KSU40623NE/01, KSU40623NE/02, KSU40623NE/03, KSU40623NE/04
- KSU40630FF/01, KSU40630FF/02, KSU40630FF/03, KSU40630FF/04, KSU40630FF/05, KSU40630FF/06
- KSU40630NE/01, KSU40630NE/02, KSU40630NE/04, KSU40630NE/05, KSU40630NE/06, KSU40630NE/07, KSU40630NE/08, KSU40630NE/09, KSU40630NE/10
- KSU40631NE/01, KSU40631NE/02, KSU40631NE/03, KSU40631NE/04, KSU40631NE/05, KSU40631NE/06, KSU40631NE/07
- KSU40660/01, KSU40660/03, KSU40660/04, KSU40660/05, KSU40660/06, KSU40660/07
- KSU40660NE/01, KSU40660NE/04, KSU40660NE/05, KSU40660NE/06, KSU40660NE/09, KSU40660NE/10, KSU40660NE/11, KSU40660NE/12
- KSU40665/02, KSU40665/03, KSU40665/09, KSU40665/10
- KSU40671NE/01, KSU40671NE/02, KSU40671NE/03, KSU40671NE/05
- KSU45621AU/01, KSU45621AU/02
- KSU45621ME/04, KSU45621ME/06, KSU45621ME/09, KSU45621ME/16
- KSU45630NE/01, KSU45630NE/02, KSU45630NE/05, KSU45630NE/06, KSU45630NE/07, KSU45630NE/08, KSU45630NE/09, KSU45630NE/10, KSU45630NE/11

- KSU45631NE/01, KSU45631NE/02
- KSU49620/01, KSU49620/04, KSU49620/05, KSU49620/06, KSU49620/07, KSU49620/09, KSU49620/10, KSU49620/11
- KSU49621AU/02, KSU49621AU/03
- KSU49621ME/06, KSU49621ME/14, KSU49621ME/15, KSU49621ME/16
- KSU49621NE/02, KSU49621NE/03, KSU49621NE/04, KSU49621NE/05, KSU49621NE/06, KSU49621NE/07, KSU49621NE/08, KSU49621NE/09, KSU49621NE/10, KSU49621NE/11, KSU49621NE/12, KSU49621NE/13, KSU49621NE/14, KSU49621NE/15, KSU49621NE/16
- KSU49622NE/01, KSU49622NE/02
- KSU49630GB/01, KSU49630GB/02, KSU49630GB/03, KSU49630GB/05, KSU49630GB/06, KSU49630GB/07, KSU49630GB/08, KSU49630GB/09
- KSU49630NE/01, KSU49630NE/02, KSU49630NE/03, KSU49630NE/05, KSU49630NE/06, KSU49630NE/07, KSU49630NE/08, KSU49630NE/09, KSU49630NE/10, KSU49630NE/11
- KSU49631NE/01, KSU49631NE/02, KSU49631NE/03, KSU49631NE/04, KSU49631NE/05
- KSU49660/03
- KSU49670NE/02, KSU49670NE/03
- KGU40621/01, KGU40621/03, KGU40621/04, KGU40621/06
- KGU40622NE/01, KGU40622NE/02, KGU40622NE/04, KGU40622NE/05, KGU40622NE/06, KGU40622NE/07
- KGU40623IL/01, KGU40623NE/01
- KGU40640NE/01, KGU40642/01, KGU40642/02, KGU40642/03, KGU40642/04
- KGU40650/01, KGU40650/03, KGU40670/01, KGU40698NE/02, KGU40M70K/01
- KSU36622NE/02, KSU36622NE/03, KSU36622NE/04, KSU36622NE/05, KSU36622NE/07, KSU36622NE/08, KSU36622NE/09, KSU36622NE/10, KSU36622NE/12
- KSU36623/01, KSU36623/02, KSU36623/03, KSU36623/04, KSU36623/05, KSU36623/06, KSU36623/07, KSU36623/08, KSU36623/09, KSU36623/10
- KSU36623NE/01, KSU36623NE/02, KSU36623NE/03
- KSU36630NE/01, KSU36630NE/03, KSU36630NE/05, KSU36630NE/06, KSU36630NE/07
- KSU36631NE/01, KSU36631NE/02
- KSU36642/01, KSU36642/02, KSU36642/03, KSU36642/04, KSU36642/05, KSU36642/06
- KSU36665/02
- KSU40622NE/02, KSU40622NE/03, KSU40622NE/04, KSU40622NE/05, KSU40622NE/06, KSU40622NE/07, KSU40622NE/08, KSU40622NE/09, KSU40622NE/11

INSTALLATION GUIDE

Installing your new sparefixd door shelf is a straightforward process. Follow these steps carefully:

1. **Preparation:** Ensure your refrigerator or freezer is unplugged from the power outlet for safety. Remove any items from the door where the shelf is to be replaced.
2. **Remove Old Shelf (if applicable):** Gently lift the existing damaged or broken door shelf upwards and then pull it outwards to remove it from its mounting slots. If the shelf is stuck, check for any clips or tabs that might need to be released.
3. **Inspect Mounting Slots:** Clean the mounting slots on the inside of the refrigerator door to ensure no debris will obstruct the new shelf.
4. **Install New Shelf:** Align the new sparefixd door shelf with the designated slots on the refrigerator door. Carefully slide the shelf downwards into the slots until it clicks securely into place. Ensure both sides are fully seated and the

shelf is level.

5. **Verify Stability:** Gently push down on the installed shelf to confirm it is stable and properly locked into position.
6. **Restore Power:** Once the shelf is securely installed, plug your refrigerator or freezer back into the power outlet.



Image: The sparefixd Door Shelf Rack Tray, showing its overall design and structure. This is the part you will be installing.



Image: A close-up view of a key mounting point on the shelf, illustrating how it interfaces with the refrigerator door.

USAGE AND STORAGE

The sparefixd door shelf is designed for holding various items within your refrigerator or freezer door. Ensure that items placed on the shelf do not exceed its weight capacity to prevent damage. Distribute weight evenly to maintain stability.



Image: An angled perspective of the door shelf, highlighting its depth and capacity for various items.

CARE AND MAINTENANCE

To ensure the longevity and hygiene of your sparefixd door shelf, regular cleaning is recommended:

- **Cleaning:** The shelf can be easily removed for cleaning. Wash with mild soap and warm water. Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic.
- **Drying:** Allow the shelf to air dry completely or wipe it with a soft cloth before re-installing it in the refrigerator door.
- **Inspection:** Periodically inspect the shelf for any signs of cracks or damage. Replace if necessary to maintain optimal functionality and safety.



Image: The underside of the door shelf, showing its smooth surface for easy cleaning.

TROUBLESHOOTING

If you encounter issues with your sparefixd door shelf, consider the following:

- **Shelf Does Not Fit:** Double-check your refrigerator or freezer model number against the compatibility list provided in this manual. Ensure the shelf is oriented correctly and aligned with the mounting slots.
- **Shelf Is Loose:** Verify that the shelf is fully pushed down and clicked into all designated mounting points. Remove and re-install if necessary.
- **Damage During Installation:** If the shelf appears damaged upon arrival or during installation, do not force it. Contact customer support for assistance.

SPECIFICATIONS

Attribute	Detail
-----------	--------

Product Type	Door Shelf Rack Tray (Without Flap)
Brand	sparefixd
Equivalent Part Number	Bosch 00439684
Material	Durable Plastic
Color	White
Compatibility	Specific Bosch Fridge & Freezer Models (see Compatibility section)



Image: A top-down view of the sparefixd door shelf, illustrating its dimensions and internal compartments.



Image: A side profile of the door shelf, showing its height and structural integrity.

WARRANTY AND SUPPORT

For information regarding warranty coverage or to seek technical support, please refer to the contact details provided by your retailer or the sparefixd official website. Ensure you have your purchase details and the product's model number (00439684) ready when contacting support.

