

[Manuals.plus](#) /

› [Barbie](#) /

› Barbie Electric Vehicle HJV36 Instruction Manual

Barbie HJV36

Barbie Electric Vehicle HJV36 Instruction Manual

Model: HJV36

INTRODUCTION

This manual provides essential instructions for the safe and proper use of your Barbie Electric Vehicle. Please read this manual thoroughly before assembly and operation to ensure optimal performance and enjoyment. The Barbie Electric Vehicle is designed for imaginative play, featuring a transforming convertible top and a simulated charging station.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts.

This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during play. Keep all packaging materials away from children.

WHAT'S IN THE BOX

- 1 x Barbie Electric Vehicle
- 1 x Simulated Charging Station with Plug
- *Dolls are not included and are sold separately.*



Image: The Barbie Electric Vehicle in purple, accompanied by its simulated charging station. The car features a sunroof and a sleek design.

SETUP

1. Unpacking

Carefully remove all components from the packaging. Ensure all parts listed in "What's in the Box" are present. Dispose of packaging materials responsibly.

2. Initial Placement

Place the Barbie Electric Vehicle and charging station on a flat, stable surface suitable for play. The vehicle is designed for indoor use.



DOLL SOLD SEPARATELY. SUBJECT TO AVAILABILITY.

Image: A child interacting with the Barbie Electric Vehicle and a Barbie doll, demonstrating typical play setup.

OPERATING INSTRUCTIONS

1. Seating Dolls

The vehicle is designed to seat two Barbie dolls. Gently place dolls into the seats. Ensure dolls are securely positioned before play. *Dolls are not included.*

2. Transforming to Convertible Mode

To transform the vehicle into a convertible, gently lift and remove the roof section. This allows for open-top play. To revert to closed-top mode, align the roof section with the car body and press down until it clicks securely into place.



Image: The Barbie Electric Vehicle shown with its roof removed, illustrating its transformation into a convertible. Two dolls are seated inside.

3. Simulated Charging

Position the simulated charging station near the vehicle. Open the charging port cover on the side of the car. Take the plug from the charging station and insert it into the car's charging port. This simulates the charging process for an electric vehicle.



Image: A detailed view of the simulated charging station, featuring a screen with charging indicators and a plug.



Image: A hand inserting the charging plug from the station into the side port of the Barbie Electric Vehicle.

4. Rolling Play

The vehicle features functional wheels for push-and-play action. It does not move independently. Push the car gently to simulate driving.

MAINTENANCE

Cleaning

To clean the vehicle and charging station, wipe with a soft, damp cloth. Do not immerse in water. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.

Storage

Store the product in a cool, dry place away from direct sunlight when not in use to prevent discoloration or damage.

TROUBLESHOOTING

Wheels Not Rolling Smoothly

Check for any debris or obstructions caught in the wheels. Ensure the vehicle is on a smooth, flat surface. If issues persist, gently clean the wheel axles.

Roof Not Attaching Securely

Ensure the roof is correctly aligned with the attachment points on the car body. Apply gentle, even pressure until it clicks into place. Avoid forcing the roof.

SPECIFICATIONS

Feature	Detail
Model Number	HJV36
Product Dimensions	7.4 x 12.05 x 7.32 inches
Item Weight	1.54 pounds
Manufacturer Recommended Age	3 years and up
Brand	Barbie (Mattel)
Color	Purple
Features	Removable roof (transforms to convertible), rolling wheels, simulated charging station

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the official Barbie or Mattel website, or contact your retailer. Please retain your proof of purchase for any warranty claims.

© 2025 Barbie / Mattel. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B5HW3GWR>

More documents and user manuals: <https://manuals.plus/>