WOPET B0B5JV9Z1H

WOPET Automatic Pet Feeder User Manual

Model: B0B5JV9Z1H

1. Introduction

Thank you for choosing the WOPET Automatic Pet Feeder. This device is designed to provide convenient and consistent feeding for your cats and small to medium-sized dogs, ensuring they receive their meals on time, even when you are away. It features a timer function, voice recording, and a 3-liter capacity, offering flexibility and peace of mind for pet owners.

Please read this manual thoroughly before operating the feeder to ensure proper use and maintenance.

2. Safety Precautions

- Do not immerse the main unit in water or any other liquid.
- Keep the feeder away from direct sunlight and heat sources.
- Ensure the power cord is not chewed by pets. Use the battery backup feature for added safety during power outages.
- Use only dry pet food with a kibble size between 2-15mm.
- This product is for indoor use only.
- Keep out of reach of children.

3. Package Contents

- WOPET Automatic Pet Feeder Main Unit
- Food Tray

- USB Power Cable
- User Manual
- Desiccant Bag (pre-installed or separate)

4. Product Overview



The WOPET Automatic Pet Feeder with its food bowl, ready for use.




Diagram showing the internal components: secure twist-lock lid, desiccant box, patented rotor design, and moisture-proof port.

Key Components:

- **Food Storage Tank:** 3L capacity for dry pet food.
- **Control Panel:** Digital display and buttons for setting time, meals, and recording voice.
- **Food Outlet:** Dispenses food into the tray.
- **Food Tray:** Detachable for easy cleaning.
- **Desiccant Box:** Keeps food fresh and dry.


- **Battery Compartment:** For 3 x D-size batteries (not included) for backup power.
- **USB Power Port:** For primary power supply.

5. Setup

5.1 Assembly

1. Place the main feeder unit on a flat, stable surface.
2. Attach the food tray to the base of the feeder, ensuring it clicks securely into place.

5.2 Power Supply (2-Way Power)



The feeder supports both USB power and D-size battery backup, preventing power cord chewing.

- **USB Power:** Connect the provided USB cable to the feeder's power port and plug the other end into a compatible USB power adapter (not included) or a power bank.
- **Battery Backup:** For power outages or portability, insert 3 D-size batteries (not included) into the battery compartment at the bottom of the unit. This ensures continuous operation even if the main power is interrupted.

5.3 Filling the Food Tank

1. Open the lid of the food storage tank.
2. Pour dry pet food into the tank. Ensure the kibble size is between 2-15mm to prevent jamming.
3. Close the lid securely. The twist-lock mechanism helps keep food fresh and prevents pets from accessing it.

5.4 Initial Settings (Time & Voice Recording)



The feeder allows you to record a personalized voice message to call your pet for meals, providing comfort and familiarity.

- **Set Current Time:** Refer to the manual's specific instructions for setting the current time on the digital display. This is crucial for accurate meal scheduling.

- **Record Voice Message:** Press and hold the record button (usually indicated by a microphone icon) to record a short voice message (e.g., "Time to eat, Fido!"). This message will play before each scheduled meal.

6. Operating the Feeder

6.1 Manual Feeding

- Press the manual feed button (often indicated by a paw or food icon) to dispense a single portion of food immediately. This is useful for extra treats or testing the dispenser.

6.2 Scheduled Feeding



The feeder allows setting 1-6 meals per day, with 1-8 portions per meal (1 portion = 15g), and has a 3L visible capacity tank.



The automatic feeder provides peace of mind for pet owners during short trips, busy workdays, or late nights, ensuring pets are fed on schedule.

- The feeder supports up to 6 meals per day.
- Each meal can be programmed with 1 to 8 portions (approximately 15g per portion).
- Follow the on-screen prompts and button instructions to set desired meal times and portion sizes for each meal.
- Ensure all settings are confirmed and saved.

7. Maintenance

7.1 Cleaning



The feeder features a detachable design for easy and convenient cleaning of the food tank and tray.

- The food tank and food tray are detachable for easy cleaning.
- Wash these parts with mild soap and water. Rinse thoroughly and dry completely before reassembling.

- Do not wash the main unit with water. Wipe it clean with a damp cloth.

7.2 Desiccant Bag Replacement

- The desiccant bag helps keep the food fresh. Replace it periodically (e.g., every 1-2 months) or when it appears saturated.
- Access the desiccant box located under the lid of the food tank.

8. Troubleshooting

Problem	Possible Cause	Solution
Feeder not dispensing food.	Food tank empty; kibble jammed; power issue.	Refill food tank; check kibble size (2-15mm) and clear any blockages; ensure power cable is connected or batteries are installed correctly.
Display not turning on.	No power supply.	Check USB cable connection; ensure batteries are inserted correctly and are not depleted.
Voice recording not playing.	No recording saved; volume too low.	Re-record voice message; check volume settings if applicable.
Scheduled meals not dispensing.	Incorrect time setting; schedule not saved.	Verify current time and meal schedule settings; ensure all settings are saved.

9. Specifications

Feature	Detail
Model	B0B5JV9Z1H
Capacity	3 Liters
Material	Stainless Steel (likely referring to internal components or bowl)
Power Supply	USB Power Cable, 3 x D-size Batteries (not included)
Max Meals per Day	6 Meals
Portions per Meal	1-8 portions (approx. 15g per portion)
Recommended Kibble Size	2-15mm

Feature	Detail
Dimensions	18 x 18 x 28 CM (approx. 7.1 x 7.1 x 11 inches)
Color	White

10. Warranty and Support

WOPET products are manufactured with quality and reliability in mind. For warranty information or technical support, please refer to the contact details provided on the product packaging or the official WOPET website. Keep your purchase receipt as proof of purchase.

© 2024 WOPET. All rights reserved.