

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Music Sound](#) /
- › [Music Sound BTSPKMSMINI2K Portable Bluetooth 5.0 Speaker User Manual](#)

Music Sound BTSPKMSMINI2K

Music Sound BTSPKMSMINI2K Portable Bluetooth Speaker User Manual

Model: BTSPKMSMINI2K

1. INTRODUCTION

Thank you for purchasing the Music Sound BTSPKMSMINI2K Portable Bluetooth Speaker. This compact and versatile speaker is designed to provide high-quality audio on the go. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device to ensure optimal performance and longevity.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Contact qualified service personnel for any repairs.
- Use only the provided charging cable or a certified equivalent.
- Keep the speaker away from water and liquids, despite its waterproof rating, to prevent damage to internal components.
- Dispose of batteries and electronic components responsibly according to local regulations.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- Music Sound BTSPKMSMINI2K Portable Bluetooth Speaker
- Charging Cable (USB)
- Auxiliary Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

The BTSPKMSMINI2K is a compact Bluetooth speaker designed for portability and ease of use. It features a soft-touch keypad for intuitive control and delivers 3 watts of audio power.



KEYPAD with **SOFT TOUCH FINISH**

Figure 4.1: Speaker Top View with Keypad. This image displays the top surface of the speaker, highlighting the integrated soft-touch control keypad. The buttons include power on/off, play/pause, skip track forward, skip track backward, and a call management button.



EASY-TO-CARRY MINI-SIZED DESIGN

Figure 4.2: Compact Design. This image illustrates the small, mini-sized design of the speaker, making it easy to carry and suitable for various occasions.

3 WATTS of power



Figure 4.3: Speaker Grille and Power Output. This image focuses on the speaker's grille, featuring the brand's logo, and highlights its 3 watts of audio power output.

5. SETUP

5.1 Initial Charge

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging time is approximately 2 hours.

5.2 Powering On/Off

- To power on: Press and hold the **Power button** (usually marked with a circle and a vertical line) on the keypad until you hear an audible indicator or see an LED light up.
- To power off: Press and hold the **Power button** again until the indicator light turns off or you hear an audible signal.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode. An LED indicator will typically flash to show it's ready to pair.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.

3. Select "**BTSPKMSMINI2K**" or a similar name from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the LED indicator will stop flashing and remain solid.
5. The speaker is compatible with all Bluetooth version 1.1 or higher devices.

6.2 Music Playback

- **Play/Pause:** Press the **Play/Pause button** (usually marked with a triangle and two vertical lines) on the keypad.
- **Next Track:** Press the **Next Track button** (usually marked with two triangles pointing right and a vertical line).
- **Previous Track:** Press the **Previous Track button** (usually marked with two triangles pointing left and a vertical line).
- **Volume Control:** Volume is typically controlled directly from your connected device. Some speakers may have dedicated volume buttons; refer to the keypad image for specific controls.

6.3 Answering Calls

If your speaker has a built-in microphone, you can answer calls:

- **Answer/End Call:** Press the **Call button** (usually marked with a phone icon) on the keypad.
- **Reject Call:** Press and hold the **Call button**.

7. CHARGING AND BATTERY LIFE

The speaker is equipped with a rechargeable Lithium-Ion battery.

- **Charging Time:** Approximately 2 hours for a full charge.
- **Playback Time:** Up to 4 hours of music playback on a full charge.
- **Charging Indicator:** An LED indicator will typically show the charging status (e.g., red while charging, off or green when fully charged).



Figure 7.1: Battery Life Indication. This image shows the speaker in use, highlighting its capability of providing up to 4 hours of music playback on a single charge.

8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is discharged.	Charge the speaker for at least 30 minutes.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Bluetooth is not enabled on your device or speaker is not in pairing mode. Device is too far from speaker.	Ensure Bluetooth is enabled on your device and the speaker is in pairing mode. Move device closer to the speaker (within 10 meters).
No sound or low volume.	Volume on speaker or connected device is too low. Speaker is not properly paired.	Increase volume on both the speaker and your connected device. Re-pair the Bluetooth connection.
Sound distortion.	Volume is too high. Device is too far from speaker.	Reduce volume. Move device closer to the speaker.

10. SPECIFICATIONS

Model Name:	BTSPKMSMINI2K
Brand:	Music Sound
Speaker Type:	Bluetooth
Connectivity Technology:	Bluetooth 5.0 (compatible with 1.1 or higher)
Wireless Range:	Up to 10 meters (33 feet)
Output Power:	3 Watts
Power Source:	Battery (Rechargeable Lithium Ion)
Battery Life:	Up to 4 hours of playback
Charging Time:	Approximately 2 hours
Control Method:	Touch (Keypad)
Material:	Plastic
Dimensions (D x W x H):	12 x 11 x 12 cm (approx.)
Waterproof:	Yes
Special Features:	Hi Res Audio, Bass Boost, USB Port
Compatible Devices:	Apple, Samsung, Acer, Huawei, Microsoft, Siemens, Skype, Sony, Nokia, Lenovo, HTC, Blackberry, universal

11. WARRANTY INFORMATION

This product comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty card included in your package or contact Music Sound customer support. The warranty typically covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

12. SUPPORT

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact Music Sound customer support. Refer to the product packaging or the official Music Sound website for contact details. For the latest information and FAQs, visit the official Music Sound website.

