

[manuals.plus](#) /› [Kichler](#) /› [Kichler Pallas 4-Light Mini Chandelier \(Model 52520BNB\) User Manual](#)**Kichler 52520BNB**

## **Kichler Pallas 4-Light Mini Chandelier (Model 52520BNB) User Manual**

Brand: Kichler | Model: 52520BNB

### **1. INTRODUCTION**

The Kichler Pallas 4-Light Mini Chandelier (Model 52520BNB) is a ceiling-mounted lighting fixture designed for indoor use. This fixture features a Brushed Natural Brass finish and accommodates four light sources. Optional linen tapered shades can be installed to enhance its appearance. This manual provides essential instructions for the safe installation, proper operation, and routine maintenance of your new chandelier.



Figure 1: Kichler Pallas 4-Light Mini Chandelier with optional linen tapered shades.

## 2. SAFETY INFORMATION

**WARNING: Risk of Electric Shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.**

- Always turn off electrical power at the main circuit breaker before beginning any installation, cleaning, or maintenance procedures.

- Consult a qualified electrician if you are unsure about wiring procedures or have any electrical questions.
- Use only the specified bulb type and wattage as indicated in the specifications section. Do not exceed the maximum wattage.
- Ensure all electrical connections are secure and properly insulated to prevent electrical hazards.
- This fixture is designed for indoor use only. Do not install in wet or damp locations.
- Handle glass components and bulbs with care to prevent breakage.

### 3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact Kichler customer support before proceeding with installation.

- Chandelier Fixture Body (1)
- Mounting Plate (1)
- Canopy (1)
- Downrods/Stems (various lengths for adjustable height)
- Mounting Screws and Wire Nuts (set)
- Optional Linen Tapered Shades (4)
- Instruction Manual (1)

### 4. SETUP AND INSTALLATION

Follow these steps carefully to install your Kichler Pallas Mini Chandelier. It is recommended to have a second person assist during installation.

#### 4.1. Preparation

1. **Turn off Power:** Locate the main circuit breaker for the room where the fixture will be installed and turn off the power.
2. **Inspect Components:** Carefully unpack all parts and inspect them for any damage. Ensure all items listed in the 'Package Contents' section are present.
3. **Gather Tools:** You may need a screwdriver, wire strippers, electrical tape, and a ladder (not included).

#### 4.2. Mounting Plate Installation

Attach the mounting plate to the ceiling junction box.





Figure 2: Detail of the fixture's canopy and downrod connection point.

1. Secure the mounting plate to the ceiling junction box using the screws provided. Ensure it is firmly attached and level.

#### **4.3. Adjusting Fixture Height and Assembling Downrods**

1. Determine the desired hanging height for your chandelier.
2. Thread the fixture wires through the chosen downrods and then connect the downrods to the fixture body and the canopy. Ensure all connections are tight.

#### **4.4. Wiring Connections**

Make electrical connections inside the junction box.

1. Connect the fixture's ground wire (bare copper or green) to the house ground wire using a wire nut.
2. Connect the fixture's neutral wire (white) to the house neutral wire (white) using a wire nut.
3. Connect the fixture's hot wire (black) to the house hot wire (black) using a wire nut.
4. After securing connections with wire nuts, wrap each connection with electrical tape for added insulation and security.
5. Carefully tuck all wires into the ceiling junction box.

#### **4.5. Canopy Installation**

1. Carefully raise the canopy to the ceiling, aligning the mounting screws on the mounting plate with the holes in the canopy.
2. Secure the canopy in place using the decorative nuts or screws provided.

#### **4.6. Shade and Bulb Installation**



Figure 3: Chandelier without shades, illustrating bulb socket type.

1. **Shade Installation (Optional):** If using the optional linen tapered shades, carefully place each shade over the bulb socket and secure it according to the fixture's design (e.g., with a socket ring or by resting on a holder).
2. **Bulb Installation:** Install four incandescent bulbs with a G13 base. Ensure the wattage does not exceed 100 watts per bulb. Screw bulbs in gently to avoid overtightening.

#### 4.7. Restore Power

1. Once installation is complete, turn the electrical power back on at the main circuit breaker.
2. Test the fixture to ensure it operates correctly.

### 5. OPERATING INSTRUCTIONS

The Kichler Pallas 4-Light Mini Chandelier is designed for simple operation via a standard wall switch. Ensure the fixture is properly installed and wired before attempting to operate it.

- To turn the chandelier ON, flip the wall switch connected to the fixture's electrical circuit to the 'ON' position.
- To turn the chandelier OFF, flip the wall switch to the 'OFF' position.

## 6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

### 6.1. Cleaning

- Always ensure the power to the fixture is turned off at the circuit breaker before cleaning.
- Wipe the fixture's metal surfaces with a soft, dry cloth.
- For optional linen shades, gently dust with a soft brush or vacuum with a brush attachment.
- Do not use abrasive cleaners, polishes, or solvents, as these can damage the finish and materials.

### 6.2. Bulb Replacement

- Turn off the power to the fixture at the circuit breaker and allow bulbs to cool completely before attempting replacement.
- Carefully unscrew the old bulb and screw in a new G13 base incandescent bulb.
- Ensure the new bulb does not exceed the maximum wattage of 100 watts.

## 7. TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wiring connection Burnt-out bulb	Check circuit breaker and wall switch Verify all wiring connections are secure (power off first) Replace bulb(s)
Lights flicker	Loose bulb Incorrect bulb type/wattage Faulty wiring	Tighten bulb(s) Ensure correct bulb type and wattage are used Consult a qualified electrician
Fixture hums	Incompatible dimmer switch Loose wiring	Ensure dimmer switch is compatible with incandescent fixtures Check wiring connections (power off first)

If the problem persists after attempting these solutions, please contact Kichler customer support or a qualified electrician.

## 8. SPECIFICATIONS

Brand	Kichler
Model Name	Pallas
Model Number	52520BNB
Color	Brushed Natural Brass
Material	Metal
Style	Modern
Light Fixture Form	Chandelier

<b>Room Type</b>	Living Room, Foyer, Dining Room
<b>Product Dimensions</b>	25"L x 25"W x 13.75"H
<b>Specific Uses For Product</b>	General Purpose, Indoor
<b>Power Source</b>	Corded Electric
<b>Installation Type</b>	Ceiling Mount
<b>Light Source Type</b>	Incandescent
<b>Finish Type</b>	Brushed Natural Brass
<b>Shade Material</b>	Optional Linen Tapered Shades (Fixture features Brass elements)
<b>Number of Light Sources</b>	4
<b>Voltage</b>	120 Volts
<b>Wattage</b>	100 watts (Max per bulb)
<b>Bulb Base</b>	G13
<b>Assembly Required</b>	No (Main body pre-assembled, installation required)
<b>Item Weight</b>	4.25 pounds

## 9. WARRANTY INFORMATION

The Kichler Pallas 4-Light Mini Chandelier (Model 52520BNB) is backed by a **1-year manufacturer's warranty** from the original date of purchase. This warranty covers defects in materials and workmanship under normal use and service.

This warranty does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized repairs. For warranty claims or detailed terms and conditions, please contact Kichler customer support.

## 10. CUSTOMER SUPPORT

For technical assistance, replacement parts, or warranty inquiries regarding your Kichler Pallas Mini Chandelier, please contact Kichler customer support through their official channels. You can also visit the official Kichler website for additional product information and resources.






For more information about Kichler products, you may visit the Kichler Store on Amazon:

[Visit the Kichler Store on Amazon](#)

Your browser does not support the video tag.

Video: Kichler Brand Story. This video provides an overview of the Kichler brand and its commitment to lighting design. It is not a product-specific installation guide.

## Related Documents - 52520BNB

	<p><a href="#">Kichler 52518 Pallas 12-Light Chandelier Installation Guide</a></p> <p>Step-by-step installation instructions for the Kichler 52518 Pallas 12-light chandelier, including parts list, safety precautions, and wiring guidance. Features detailed diagram descriptions and warnings.</p>
	<p><a href="#">Kichler Florence 52496BNB Chandelier Installation Guide - Brushed Natural Brass</a></p> <p>Step-by-step installation instructions, parts list, and safety precautions for the Kichler Florence 52496BNB chandelier. Learn how to assemble and install your Brushed Natural Brass lighting fixture.</p>
	<p><a href="#">Kichler Pallas Chandelier Installation Guide - Model 52517</a></p> <p>Comprehensive installation instructions for the Kichler Pallas Chandelier (Model 52517), including parts list, diagrams, wiring, and safety precautions. Supports English, French, and Spanish.</p>
	<p><a href="#">Kichler 38200 Semi-Flushmount Ceiling Fixture Installation Manual</a></p> <p>Installation instructions, safety information, parts list, and troubleshooting guide for the Kichler 38200 Semi-Flushmount Ceiling Fixture. Includes step-by-step assembly guidance.</p>
	<p><a href="#">Kichler 5-Light Chandelier Installation and Assembly Guide (Models 34686A, 34750A)</a></p> <p>Detailed instructions for assembling and installing the Kichler 5-Light Chandelier (Models 34686A, 34750A). Includes package contents, hardware list, safety precautions, step-by-step assembly, care, and troubleshooting.</p>
	<p><a href="#">Kichler Lighting Fixture Installation Guide - Model IS-52528</a></p> <p>Detailed installation instructions, parts list, and safety precautions for Kichler lighting fixtures. Learn how to safely assemble and wire your Kichler light.</p>

