Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl B0B5QRZPFL

onerbl AC/DC Adapter Instruction Manual

For MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/DC Adapter. This adapter is designed as a high-quality replacement power supply specifically for the MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System.
Key features include:

- Brand new, high-quality replacement AC wall power charger adapter.
- Wide input voltage range: AC 100-240V 50/60Hz (Auto-sensing for worldwide use).
- Extended cord length for convenience.
- Integrated safety protections: Over Voltage Protection, Over Heat Protection, Short-circuit Protection, and Over-current Protection.

2. Important Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Do not expose to liquids:** Keep the adapter away from water, rain, or excessive moisture.
- **Proper ventilation:** Ensure the adapter is used in a well-ventilated area. Do not cover the adapter or place it in an enclosed space that could restrict airflow.
- **Avoid extreme temperatures:** Do not operate the adapter in extremely hot or cold environments.
- **Inspect before use:** Before each use, inspect the adapter and its cord for any signs of damage. Do not use if the cord is frayed, cut, or if the adapter casing is damaged.
- **Unplug when not in use:** Disconnect the adapter from the power outlet when not in use for extended periods.
- **Do not disassemble:** Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- **Use with compatible devices only:** This adapter is designed for the MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System. Using it with incompatible devices may cause damage.
- **Keep out of reach of children.**

3. Package Contents

Verify that all items are present in your package:

- 1 x onerbl AC/DC Adapter



Image: The onerbl AC/DC Adapter, showing the main unit with a 2-pin US plug and the DC output connector, with the cable coiled neatly.

4. Specifications

Feature	Detail
Brand	onerbl
Input Voltage	AC 100-240V, 50/60Hz
Compatible Devices	MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System
Power Source	Corded Electric
Main Power Connector Type	2 Pin (US Standard)
Cable Length	Approximately 76 inches (6.33 feet)
Item Weight	8 ounces
Special Feature	Travel-friendly design
Manufacturer	Shenzhen Waweis Technology Co., Ltd




Image: Visual representation of the adapter's dimensions (2.6 inches length, 1.6 inches width, 1.2 inches height) and the cable length (76 inches).

5. Setup Instructions

Follow these steps to properly connect your onerbl AC/DC Adapter to your MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System:

1. **Identify the power input port:** Locate the DC power input port on your MEMOREX MI3021BLK Mi3021 iPod Docking Station. This port is typically labeled or indicated in your device's original manual.
2. **Connect the adapter to the device:** Carefully insert the DC output plug of the onerbl AC/DC Adapter into the power input port of your docking station. Ensure a snug and secure connection. Do not force the plug.
3. **Connect to a power outlet:** Plug the 2-pin AC input plug of the adapter into a standard wall power outlet (100-240V AC).
4. **Verify power:** Once connected, your MEMOREX docking station should receive power. Check for any power indicator lights on your device to confirm.



Image: The onerbl AC/DC Adapter plugged into a power strip, demonstrating a typical connection scenario for powering a device.

6. Operating Instructions

The onerbl AC/DC Adapter functions as a power supply and does not require specific operational steps beyond proper connection. Once connected as described in the Setup section, it continuously provides power to your MEMOREX MI3021BLK Mi3021 iPod Docking Station Speaker System.

- Ensure the adapter is securely plugged into both the wall outlet and your device.
- The adapter is designed for continuous use, but it is recommended to unplug it when the device is not in use for extended periods, especially during electrical storms.

7. Care and Maintenance

To ensure the longevity and optimal performance of your onerbl AC/DC Adapter, follow these maintenance guidelines:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Inspection:** Regularly inspect the power cord for any signs of wear, cuts, or kinks. If any damage is observed, discontinue use immediately and replace the adapter.
- **Environmental Conditions:** Avoid exposing the adapter to dust, dirt, or excessive humidity, which can affect its internal components.




Image: Illustration of the adapter's durable design, highlighting the copper wire and PVC jacket for enhanced durability and quality control.

8. Troubleshooting

If you encounter issues with your onerbl AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device not powering on.	Loose connection, faulty outlet, incompatible device, adapter failure.	◦ Ensure both ends of the adapter are securely plugged in. ◦ Try plugging the adapter into a different wall outlet to rule out a faulty outlet. ◦ Confirm the adapter is compatible with your MEMOREX MI3021BLK Mi3021 docking station. ◦ If the issue persists, the adapter may be faulty and require replacement.
Adapter feels hot during use.	Normal operation, poor ventilation, excessive load.	◦ A slight warmth is normal. ◦ Ensure the adapter is in a well-ventilated area and not covered. ◦ If it becomes excessively hot, unplug it immediately and allow it to cool. Ensure the device it's powering is not drawing too much current.
Device powers off unexpectedly.	Overload, short-circuit, over-voltage protection activated.	◦ The adapter features built-in protections (short-circuit, over-voltage, over-current) that may shut down power to prevent damage. ◦ Unplug the adapter and the device. Wait a few minutes, then reconnect. ◦ Ensure the device is not faulty or drawing excessive power.



Image: The 'SMART CHIP' feature, detailing the multiple protection mechanisms including short-circuit, over-voltage, and over-current protection, designed to guard electrical safety.

9. Warranty and Support

For warranty information and customer support regarding your onerbl AC/DC Adapter, please refer to the purchase documentation or contact the seller directly through the platform where the product was purchased.
Manufacturer: Shenzhen Waweis Technology Co., Ltd
Brand: onerbl
Product ASIN: B0B5QRZPFL

© 2023 onerbl. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B5QRZPFL

More documents and user manuals: **https://manuals.plus/**