

Juilist GS-336B

Juilist Centrifugal Juicer User Manual

Model: GS-336B

1. INTRODUCTION

Thank you for choosing the Juilist 600W Centrifugal Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The Juilist Centrifugal Juicer is designed for quick and efficient extraction of juice from various fruits and vegetables, featuring a powerful 600W motor, a wide 3-inch feed chute, and two-speed settings for optimal results with both soft and hard produce.



Image 1.1: The Julist Centrifugal Juicer with fresh ingredients and extracted juice.

2. IMPORTANT SAFETY PRECAUTIONS

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Always use the food pusher provided.
- Ensure all parts are correctly assembled and the locking bar is securely in place before operating the juicer.
- Do not process frozen fruits or vegetables, as this can damage the juicer's components.
- Avoid overfilling the feed chute. Process produce in manageable pieces.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is for household use only.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main parts of your Julist Centrifugal Juicer:

1. **Food Pusher:** Used to guide produce down the feed chute.
2. **Feed Chute:** Wide opening for inserting fruits and vegetables.
3. **Lid:** Covers the filter basket and feed chute.
4. **Filter Basket (Stainless Steel):** Contains the cutting blade and filter mesh.
5. **Pulp Container:** Collects discarded pulp.
6. **Juice Spout with Anti-Drip Function:** Dispenses juice into the jug.
7. **Motor Base:** Houses the motor and control dial.
8. **Locking Bar:** Secures the lid and filter basket to the motor base.
9. **Juice Jug:** Collects the extracted juice (400ml capacity).
10. **Anti-Slip Feet:** Provide stability during operation.

Anit-drip & Anit-slip Design

Never mess your kitchen,
better solve the problem of juice leakage



Image 3.1: Detail of the anti-drip design, preventing spills.



4. SETUP AND ASSEMBLY

Follow these steps to assemble your Juulist Centrifugal Juicer:

1. Place the motor base on a stable, flat, and dry surface.
2. Install the filter bowl onto the motor base.
3. Carefully place the stainless steel filter basket into the filter bowl, pushing down until it clicks securely into place.
4. Attach the pulp container to the side of the filter bowl.
5. Position the lid onto the filter bowl, aligning the feed chute with the filter basket.
6. Lift the safety locking bar and secure it into the two grooves on each side of the lid until it locks into position. The juicer will not operate if the locking bar is not correctly engaged.
7. Slide the foam separator into the long spout of the juice jug, then place the jug under the juice spout.

Savourons ensemble ce délicieux jus



65mm Tube d'alimentation extralarge

peut facilement extraire le jus des fruits et légumes, tels que la pomme, l'orange, la pastèque, la fraise, le kiwi, le céleri, etc.



304 Filtre en acier inoxydable

produit à basse température et séparation des résidus de jus, ce qui permet de conserver le goût frais et délicieux du jus.



Conception anti-goutte

fonction anti-goutte, pas besoin de s'inquiéter que le jus se répande partout.

Image 4.1: Quick installation guide for the Juulist Centrifugal Juicer.

5. OPERATING INSTRUCTIONS

5.1. Preparing Fruits and Vegetables

- Wash all fruits and vegetables thoroughly.
- For most fruits and vegetables, peeling is not necessary due to the wide feed chute. However, for citrus fruits, remove the peel.
- Remove large seeds or pits from fruits like peaches, plums, and cherries.
- Cut larger produce into pieces that fit comfortably into the 3-inch feed chute.

3 Inch Larger Feed Chute

Get juice quickly
without cutting it down



Image 5.1: The 3-inch wide feed chute allows for whole fruits and vegetables.

5.2. Juicing Process

1. Plug the juicer into a grounded electrical outlet.
2. Place the juice jug under the juice spout.
3. Turn the control dial to the desired speed setting:
 - **Speed 'I' (Low Speed):** 12,000-15,000 RPM, suitable for soft fruits and vegetables such as blueberries, watermelon, oranges, grapes, and tomatoes.
 - **Speed 'II' (High Speed):** 15,000-18,000 RPM, ideal for hard fruits and vegetables like apples,

carrots, celery, and ginger.

4. Gradually feed the prepared produce into the feed chute using the food pusher. Apply gentle, even pressure. Do not force produce down.
5. The juicer will extract juice into the jug and separate pulp into the pulp container.
6. Once juicing is complete, turn the control dial to '0' (Off) and unplug the appliance.



Image 5.2: Speed settings for various types of produce.

5.3. Not Recommended for Juicing

Certain fruits and vegetables are not suitable for this type of centrifugal juicer due to their texture or low juice yield:

- Bananas
- Avocados
- Figs
- Mangoes
- Coconut
- Sugar cane



Image 5.3: Fruits not recommended for juicing with this appliance.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your juicer. It is recommended to clean the juicer immediately after each use.

6.1. Disassembly

1. Unplug the juicer from the power outlet.
2. Release the safety locking bar.
3. Remove the lid, pulp container, filter basket, and filter bowl from the motor base.

6.2. Cleaning

- Rinse all detachable parts (lid, food pusher, filter basket, filter bowl, pulp container, juice jug) under running water.
- Use the included cleaning brush to thoroughly clean the stainless steel filter basket, paying special attention to the mesh to remove any pulp residue.
- Most detachable parts are dishwasher safe (top rack recommended). Refer to the product specifications for confirmation.
- Wipe the motor base with a damp cloth. Never immerse the motor base in water.
- Dry all parts thoroughly before reassembling or storing.

Easy to Clean & Assemble

Cleanup the detachable parts take no time at all for by a dishwasher. You can also wash it by brush



Image 6.1: Easy cleaning and dishwasher-safe parts for convenience.

7. TROUBLESHOOTING

If you encounter any issues with your Juilist Centrifugal Juicer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; safety locking bar not engaged; motor overheating.	Ensure power cord is securely plugged in. Check if the safety locking bar is fully engaged. If the motor overheated, unplug and let it cool for 30 minutes before restarting.
Low juice yield or wet pulp.	Incorrect speed setting for produce; filter basket clogged; produce not fresh.	Use appropriate speed setting (I for soft, II for hard). Clean the filter basket thoroughly. Use fresh, firm produce.
Excessive vibration or noise.	Improper assembly; uneven placement of juicer; hard produce.	Ensure all parts are correctly assembled and locked. Place the juicer on a stable, flat surface. Use the correct speed for hard produce.
Juice leaks from the side.	Lid not properly secured; pulp container full.	Ensure the lid is correctly placed and the locking bar is fully engaged. Empty the pulp container if it's full.

For further assistance, please refer to the customer support section.

Centrifugeuse à installation rapide



Image 7.1: Common questions and answers for troubleshooting.

8. SPECIFICATIONS

Feature	Specification
Brand	Juulist

Feature	Specification
Model Number	GS-336B
Color	Silver
Power	600 Watts
Voltage	220 Volts
Capacity (Juice Jug)	650 Centilitres (650 ml)
Material	Stainless Steel
Number of Speeds	2 (Low 'I', High 'II')
Product Dimensions (L x W x H)	20 x 5 x 15 cm
Item Weight	250 g
Special Features	Adjustable Speed Control, Dishwasher Safe (parts), Manual Operation

9. WARRANTY AND SUPPORT

For any questions, concerns, or technical support regarding your Juilist Centrifugal Juicer, please contact the seller or Amazon customer service. It is recommended to check the packaging upon receipt for any damage and contact customer service immediately if issues are found.