

[Manuals.plus](#) /

› [MEETOO](#) /

› MEETOO Rechargeable USB Type-C Electric Candle Lighter Instruction Manual

MEETOO B0B5SNVRSY

MEETOO Rechargeable USB Type-C Electric Candle Lighter Instruction Manual

Brand: MEETOO | Model: B0B5SNVRSY

1. INTRODUCTION

Thank you for choosing the MEETOO Electric Candle Lighter. This device utilizes plasma arc technology to provide a flameless, windproof, and rechargeable ignition source. Designed for safety and convenience, it eliminates the need for butane and matches, making it an ideal tool for lighting candles, gas stoves, and other items requiring a flame.



Image 1.1: The MEETOO Electric Candle Lighter.

2. PRODUCT FEATURES

- **Butane-Free Operation:** Utilizes plasma arc technology, eliminating the need for harmful chemicals like butane.
- **Rechargeable USB Type-C:** Easily charged via a standard USB Type-C cable, compatible with computers, power banks, and wall adapters.
- **Windproof Design:** The electric arc functions effectively even in windy conditions, ensuring reliable ignition outdoors.
- **Enhanced Safety:** Features a safety switch and automatic 7-second shut-off to prevent accidental activation and overheating.
- **LED Battery Indicator:** Displays the remaining battery life for convenient monitoring.

3. COMPONENTS AND CONTROLS



Image 3.1: Key components of the MEETOO Electric Candle Lighter.

1. **ARC Pulse Ignition:** Generates a high-voltage electric arc for ignition.
2. **LED Battery Indicator:** Four blue LED lights indicate battery charge level (25%, 50%, 75%, 100%).
3. **Safety Switch:** A sliding switch that must be pushed up to enable the ignition button.
4. **Ignition Button:** Activates the electric arc when the safety switch is engaged.
5. **Type-C Charging Port:** Input for the USB Type-C charging cable.

4. SETUP AND CHARGING

Before initial use, fully charge your MEETOO Electric Candle Lighter. The device comes with a USB Type-C charging cable.

- Connect the USB Type-C end of the cable to the charging port on the lighter.
- Connect the USB-A end of the cable to a compatible power source (e.g., computer USB port, power bank, wall adapter).

- The LED battery indicators will illuminate during charging and turn off when fully charged.



Image 4.1: Charging the lighter using a USB Type-C cable.

5. OPERATING INSTRUCTIONS

To operate your MEETOO Electric Candle Lighter:

1. Ensure the lighter is sufficiently charged (check LED indicators).
2. Push the safety switch (located below the ignition button) upwards to the "ON" position.
3. Press and hold the ignition button to activate the electric arc.
4. Position the arc near the wick of the candle or desired item until ignition occurs.
5. Release the ignition button to turn off the arc. The arc will automatically shut off after 7 seconds of continuous use as a safety measure.
6. For storage, push the safety switch downwards to the "OFF" position to prevent accidental activation.

PERFECT GIFT FOR CANDLE LOVER

USB charging can be recycled



Image 5.1: Using the lighter to ignite a candle.



Image 5.2: Close-up of the lighter igniting a candle.

Demonstration Videos:

Your browser does not support the video tag.

Video 5.3: A short demonstration of the lighter's use.

Your browser does not support the video tag.

Video 5.4: A detailed review and demonstration of the lighter.

Your browser does not support the video tag.

Video 5.5: Quick demonstration of the lighter's ease of use.

Your browser does not support the video tag.

Video 5.6: Demonstration highlighting the rechargeable aspect.

6. SAFETY INFORMATION

The MEETOO Electric Candle Lighter is designed with multiple safety features:

- **Child-Resistant Safety Switch:** Prevents accidental activation by requiring the safety switch to be pushed up before the ignition button can be pressed.
- **7-Second Auto-Off:** The electric arc automatically deactivates after 7 seconds of continuous use to prevent overheating and conserve battery.
- **Integrated Protection:** Features overload, short circuit, overcharge, and overheating protection circuits.
- **Flameless Operation:** Eliminates the risks associated with open flames, such as accidental burns or ignition of flammable materials.

OVERLOAD
PROTECT

SHORT CIRCUIT
PROTECT

OVERCHARGE
PROTECT

OVER HEATING
PROTECT

CHIP
PROTECT

7S AUTO OFF

Upgraded Tech & Safety Design

Provide a safer environment for your family

Image 6.1: Advanced safety features of the lighter.

7. MAINTENANCE

To ensure the longevity and optimal performance of your lighter:

- Keep the lighter clean and dry. Use a soft, dry cloth to wipe the exterior.
- Avoid exposing the lighter to extreme temperatures or direct sunlight for extended periods.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- Charge the lighter regularly, even if not in frequent use, to maintain battery health.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lighter does not activate.	Safety switch is in "OFF" position or battery is low.	Push safety switch to "ON" and ensure the lighter is charged.
Lighter does not charge.	Faulty cable or power source.	Try a different USB Type-C cable or power source. Ensure connections are secure.
Arc is weak or inconsistent.	Low battery or debris on electrodes.	Recharge the lighter. Gently clean the electrodes with a dry cloth if necessary.

9. SPECIFICATIONS

Feature	Detail
Brand	MEETOO
Model	B0B5SNVRSY
Material	Stainless Steel
Fuel Type	Electric (Rechargeable)
Product Dimensions	7"L x 1.6"W x 0.7"Th
Item Weight	1.6 ounces



Image 9.1: Product dimensions.

10. WARRANTY AND SUPPORT

For warranty information, product support, or to contact customer service, please refer to the manufacturer's official website or the contact details provided with your purchase documentation.

Manufacturer: MEETOO

Date First Available: October 23, 2022

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question