

AGARTT B0B5TM4L1P

AGARTT Queen Upholstered Platform Bed Frame Instruction Manual

Model: B0B5TM4L1P

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your AGARTT Queen Upholstered Platform Bed Frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Product Name: AGARTT Queen Upholstered Platform Bed Frame

Brand: AGARTT

Model: B0B5TM4L1P

Color: Black Linen

2. SAFETY INFORMATION

WARNING:

- Exercise caution around sharp edges during assembly and use.
- Assemble the bed frame strictly according to the provided instructions to prevent instability.
- Do not load the bed frame with more than 700 pounds. Exceeding this weight limit may cause damage or injury.
- Keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Before assembly, ensure all parts and hardware are present. Most parts are conveniently stored in a zippered

compartment on the back of the headboard. Hardware is individually wrapped and labeled for easy identification.

QUEEN SIZE



Image 3.1: Queen Bed Frame Dimensions and Components. This image illustrates the overall dimensions of the Queen size bed frame (83.62"L x 60.24"W x 41.06"H) and highlights the wooden slat support system. It also indicates a weight capacity of 800 lbs.

3.1. Parts List (Example - refer to your specific manual for exact list)

- Headboard (1)
- Footboard (1)
- Side Rails (2)
- Center Support Beam (1)
- Wooden Slats (approx. 12-14 pieces)
- Support Legs (various, for frame and center beam)

3.2. Hardware List (Example - refer to your specific manual for exact list)

- Bolts (various sizes)
- Washers

- Nuts
- Allen Wrench (included)

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. All necessary tools are included. It is recommended to assemble the bed frame with two people for ease and safety.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (like a rug or blanket) to prevent scratches. Locate the zippered compartment on the back of the headboard for additional parts and hardware.
2. **Identify Parts:** Match all parts and hardware to the lists provided in your specific assembly manual. Ensure nothing is missing.
3. **Attach Side Rails to Headboard:** Connect the side rails to the headboard using the specified bolts and washers. **Important:** Do not fully tighten bolts until all connections are made. This allows for slight adjustments and ensures proper alignment.
4. **Attach Side Rails to Footboard:** Connect the other end of the side rails to the footboard. Again, do not fully tighten bolts yet.
5. **Install Center Support Beam:** Secure the center support beam, if applicable, according to the instructions. Attach any support legs to the center beam.
6. **Insert Wooden Slats:** Place the wooden slats across the bed frame. Ensure they are evenly spaced and securely seated in their designated positions. The internal steel frame and quality wood slats provide durable support.
7. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts using the provided Allen wrench. Ensure all connections are firm and secure.
8. **Position Bed Frame:** Carefully move the assembled bed frame to its desired location.



Durable construction



The interior is supported by wooden panels and steel frame, and the high-density foam filling is selected to increase comfort and longevity.

No box spring required

Image 4.1: Durable Construction Detail. This image highlights the robust internal steel frame and wooden slat support system, designed for durability and mattress longevity.

5. OPERATING AND USAGE

Your AGARTT Upholstered Platform Bed Frame is designed for comfort and convenience.

- **Mattress Compatibility:** This platform bed frame does not require a box spring. You can place your mattress directly onto the wooden slats.
- **Recommended Mattress:** For optimal aesthetics and support, a mattress with a thickness of approximately 12 inches is recommended.
- **Weight Capacity:** The bed frame is designed to support a maximum weight of 800 pounds (including mattress and occupants).
- **Squeak Resistant:** The design incorporates features to minimize squeaking, providing a quiet sleeping environment.
- **Under-bed Clearance:** The ground to item distance is approximately 6.29 inches, offering some space for under-bed storage.

Bedding Selection



Recommended 12-inch thickness mattress

Image 5.1: Recommended Mattress Thickness. This image illustrates the recommended 12-inch mattress thickness for use with the bed frame, ensuring proper fit and appearance.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and structural integrity of your bed frame.

- **Cleaning Upholstery:** For general cleaning, gently vacuum the upholstered headboard and frame to remove dust and debris. For spills or stains, spot clean immediately with a mild fabric cleaner and a soft cloth. Test the cleaner on an inconspicuous area first.
- **Frame Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten any loose hardware to maintain stability and prevent squeaking.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on any part of the bed frame, as this may damage the finish or fabric.

7. TROUBLESHOOTING

If you encounter any issues with your bed frame, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or incorrect assembly.	Ensure all bolts are fully tightened. Review assembly instructions to confirm all parts are correctly installed. When assembling, avoid tightening all bolts fully until all connections are made, then tighten systematically.
Squeaking noises.	Loose connections or friction between parts.	Re-tighten all bolts. Check that wooden slats are properly seated and not rubbing against the frame.
Parts do not align during assembly.	Bolts tightened prematurely.	Loosen all bolts slightly, align the parts, then re-tighten all bolts evenly.
Missing or damaged parts.	Packaging error or shipping damage.	Contact AGARTT customer service immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	AGARTT
Model Number (ASIN)	B0B5TM4L1P
Size	Queen
Color	Black Linen
Product Dimensions (L x W x H)	83.62"L x 60.24"W x 41.06"H
Item Weight	82 pounds
Weight Capacity	800 pounds
Special Feature	Squeak Resistant
Finish Type	Steel (frame)
Included Components	Headboard, Footboard, Side Rails, Slats, Hardware
Box Spring Required	No
Assembly Required	Yes
Ground To Item Distance	6.29 Inches
Recommended Mattress Thickness	12 inches

9. WARRANTY AND SUPPORT

AGARTT is committed to providing quality service. If you have any questions or require assistance with your product, please contact our customer support team.

- **Customer Service:** For any inquiries before or after purchase, AGARTT offers dedicated support to help resolve issues. Refer to your purchase documentation or the seller's contact information for direct support channels.
- **Returns:** Please refer to the retailer's return policy for information regarding product returns.
- **Protection Plans:** Extended protection plans may be available through third-party providers at the time of purchase. These are separate from the manufacturer's support.

For more information about AGARTT products, visit the official AGARTT Store: [AGARTT Store on Amazon](#)

