

Trevi SL 3054

Trevi SL 3054 Quartz Alarm Clock User Manual

Model: SL 3054 | Brand: Trevi

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Trevi SL 3054 Quartz Alarm Clock. Please read this manual thoroughly before using the device to ensure proper function and longevity.

The Trevi SL 3054 is designed to provide accurate timekeeping and reliable alarm functionality with a silent sweep movement for undisturbed rest. It features a large, easy-to-read dial and a convenient snooze/light function.

PRODUCT FEATURES

- **Silent SWEEP Movement:** Ensures quiet operation without ticking sounds.
- **Large Dial:** Provides clear and easy readability of the time.
- **Snooze/Light Button:** Activates a temporary backlight for night viewing and pauses the alarm.
- **Electronic Alarm:** Produces an audible alert at the set time.
- **LED Dial Illumination:** For enhanced visibility in low-light conditions.
- **Ergonomic Design:** For comfortable handling and placement.

SETUP

1. Battery Installation

The Trevi SL 3054 requires one (1) AA battery (not included) for operation.

1. Locate the battery compartment cover on the back of the alarm clock.
2. Slide or lift the cover to open the compartment.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
4. Replace the battery compartment cover securely.



Image: Rear view of the Trevi SL 3054 alarm clock, highlighting the battery compartment and adjustment knobs for time and alarm settings.

2. Setting the Time

1. Locate the "TIME SET" knob on the back of the clock.
2. Rotate the "TIME SET" knob in either direction until the hour and minute hands display the correct current time.

3. Setting the Alarm

1. Locate the "ALARM SET" knob on the back of the clock.
2. Rotate the "ALARM SET" knob until the alarm hand points to your desired alarm time.
3. Ensure the alarm ON/OFF switch (usually a small slider) is in the "ON" position to activate the alarm.



Image: Front view of the Trevi SL 3054 alarm clock, showing the large, clear dial with hour, minute, and alarm hands.

OPERATING INSTRUCTIONS

1. Activating/Deactivating the Alarm

- To activate the alarm, slide the alarm ON/OFF switch (located on the back or side) to the "ON" position.
- To deactivate the alarm, slide the alarm ON/OFF switch to the "OFF" position.

2. Snooze/Light Function

- When the alarm sounds, press the large "SNOOZE/LIGHT" button located on the top of the clock.
- Pressing this button will temporarily silence the alarm, and it will sound again after a short interval (typically 5-10 minutes).
- Pressing the "SNOOZE/LIGHT" button at any time will illuminate the dial for a few seconds, allowing you to read the time in the dark.



Image: Side view of the Trevi SL 3054 alarm clock, illustrating the prominent snooze/light button on the top surface.

MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace the AA battery when the clock's timekeeping becomes inaccurate or the alarm weakens. Remove depleted batteries promptly to prevent leakage.
- **Storage:** If storing the clock for an extended period, remove the battery to prevent potential damage from battery leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working or running slow.	Depleted or incorrectly installed battery.	Replace the AA battery, ensuring correct polarity.
Alarm not sounding.	Alarm switch is OFF, alarm time not set correctly, or battery is low.	Ensure alarm switch is ON. Verify alarm hand is set to the desired time. Replace battery if low.
Light function not working.	Low battery.	Replace the AA battery.

SPECIFICATIONS

- **Model:** Trevi SL 3054
- **Movement:** Quartz, Silent SWEEP
- **Power Source:** 1 x AA Battery (not included)
- **Dimensions (L x W x H):** Approximately 10 x 3.81 x 9 cm (3.94 x 1.5 x 3.54 inches)
- **Weight:** Approximately 130 g (0.29 lbs)
- **Features:** Large Dial, Snooze/Light Function, Electronic Alarm, LED Illumination




WARRANTY AND SUPPORT




For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Trevi website. Keep your proof of purchase for any warranty claims.

If you encounter issues not covered in this troubleshooting section, please contact Trevi customer service for assistance.

© 2023 Trevi. All rights reserved.

Related Documents - SL 3054

	<p>Trevi SL 3054 Quartz Alarm Clock User Information and Warranty</p> <p>Detailed user information for the Trevi SL 3054 Quartz Alarm Clock, covering features, 24-month warranty details, and proper disposal guidelines according to EU regulations. Learn how to set the alarm, time, and use the snooze function.</p>
	<p>Trevi SLD 3875 Digital Alarm Clock, Thermometer, and Calendar User Manual</p> <p>Comprehensive user manual for the Trevi SLD 3875 digital alarm clock, thermometer, and calendar. Learn how to set the time, date, alarm, use the snooze function, and understand power and disposal information.</p>
	<p>Trevi SLD 3200 T Clock and Weather Station User Manual</p> <p>Comprehensive user manual for the Trevi SLD 3200 T clock and weather station, covering setup, functions, alarm settings, comfort index, temperature units, moon phase, technical specifications, warranty, and disposal information.</p>

	<p>Trevi RC 80D2 DAB: Guida all'uso e Funzionalità Radio DAB/FM</p> <p>Manuale d'uso completo per la radio sveglia Trevi RC 80D2 DAB, che offre ricezione radio DAB, DAB+ e FM, funzioni di sveglia e un design moderno. Scopri come configurare e utilizzare il tuo dispositivo.</p>
	<p>Trevi MPV 1780 SB: Manuale Utente e Specifiche Tecniche</p> <p>Guida completa al lettore audio/video/MP3/pedometro Trevi MPV 1780 SB, incluse istruzioni d'uso, caratteristiche tecniche e avvertenze.</p>
	<p>Trevi XF 370 KB Portable Bluetooth Speaker User Manual</p> <p>Comprehensive user manual for the Trevi XF 370 KB portable speaker, covering setup, functions, Bluetooth connectivity, TWS pairing, USB/SD playback, AUX input, disco light effects, microphone use, recording, technical specifications, and disposal information.</p>