

Manuals.plus /

> ALLIMITY /

> ALLIMITY Replacement Remote Control for LG Air Conditioners (Models AKB74955604, AKB73995805, AKB75215401, AKB74955602, AKB74955603, AKB75215402, AKB74955615)

ALLIMITY ALLIMITY

ALLIMITY Replacement Remote Control for LG Air Conditioners

MODEL: ALLIMITY

Compatible with LG AC Models: AKB74955604, AKB73995805, AKB75215401, AKB74955602, AKB74955603, AKB75215402, AKB74955615

1. Product Overview

This manual provides instructions for the ALLIMITY replacement remote control, designed to operate various LG air conditioner models. This remote offers full functionality without requiring any programming. Simply insert batteries, and it is ready for use.



Front view of the ALLIMITY replacement remote control for LG air conditioners, showing the LCD screen and all buttons.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.

Note: No programming is required. The remote is ready for use once batteries are installed.



Rear view of the ALLIMITY remote control, indicating the battery compartment location.

3. Operating Instructions

The remote control features various buttons for controlling your LG air conditioner. Refer to the image below for button identification.





Detailed view of the ALLIMITY remote control buttons, showing labels for various functions like Mode, Temp, Fan Speed, and Timer.

- **Power Button:** Press to turn the air conditioner ON or OFF.

- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temp Up/Down Buttons:** Adjusts the desired temperature.
- **Fan Speed Button:** Changes the fan speed settings (e.g., Low, Medium, High, Auto).
- **Swing Button:** Activates or deactivates the louver swing function for air distribution.
- **Jet Mode Button:** Activates rapid cooling or heating.
- **Comfort Air Button:** Adjusts airflow for optimal comfort.
- **Light Off Button:** Turns off the display light on the air conditioner unit.
- **Energy Ctrl Button:** Activates energy-saving functions.
- **Room Temp Button:** Displays the current room temperature.
- **Set Up / Diagnosis [5s] Button:**Used for advanced settings or diagnostic functions (press and hold for 5 seconds).
- **Func. Button:** Accesses additional functions.
- **Timer Button:** Sets the ON/OFF timer for the air conditioner.
- **Set/Cancel Buttons:** Used to confirm or cancel settings, particularly for timer functions.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's range decreases or it stops responding. Always use new alkaline batteries of the specified type (AAA). Do not mix old and new batteries or different battery types.

4.2 Cleaning

Wipe the remote with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
 - Check battery polarity.
 - Replace batteries with new ones.
 - Ensure there are no obstructions between the remote and the air conditioner's infrared receiver.
 - Verify the remote is pointed directly at the air conditioner unit.
- **Limited range:**
 - Replace batteries.
 - Ensure no strong light sources (e.g., direct sunlight) are interfering with the infrared signal.
- **Air conditioner not performing desired function:**
 - Confirm the air conditioner unit is powered on.
 - Check the air conditioner's display for error codes or specific settings that might override remote commands.

6. Specifications

Brand	ALLIMITY
Model Number	ALLIMITY (QYSY-AKB74955604-QYSY)

Compatible LG AC Models	AKB74955604, AKB73995805, AKB75215401, AKB74955602, AKB74955603, AKB75215402, AKB74955615
Connectivity Technology	Infrared
Maximum Range	10 Meters
Battery Type	Alkaline (AAA, not included)
Dimensions	4 x 12 x 0.3 cm
Weight	50 g
Color	White
Special Feature	Universal (for specified LG models)
Number of Buttons	10
Controller Type	Push Button Control

7. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact the retailer where the product was purchased. No specific warranty details are provided within this instruction manual.

© 2024 ALLIMITY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B5WQB6W7>

More documents and user manuals: <https://manuals.plus/>