Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ocioc 9012

ocioc Quiet Ceiling Fan with LED Light DC Motor

Model: 9012 (32-inch) - Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your ocioc Quiet Ceiling Fan with LED Light. Please read all instructions carefully before beginning installation or use. Retain this manual for future reference.

Safety Warnings

- Always turn off the power supply at the circuit breaker before installation or maintenance.
- Ensure the ceiling structure can support the fan's weight (approximately 8.12 pounds).
- Use appropriate tools for installation, including a screwdriver and electric drill.
- If you are unfamiliar with electrical wiring, consult a professional electrician.
- Keep the fan away from water and high humidity to avoid electrical hazards.

2. Product Overview

The ocioc 32-inch Quiet Ceiling Fan is designed for optimal air circulation and lighting in various indoor and outdoor settings. Key features include:

- **Quiet DC Motor:** Operates with minimal noise (30 Decibels) while providing large air volume (1364 Cubic Feet Per Minute).
- **Reversible Motor:** Allows switching between downward airflow for summer cooling and upward airflow for winter heat distribution.
- **Multifunctional Remote Control:** Offers 6 wind speed settings and 3 timer settings (1H/2H/4H).
- **Integrated LED Light:** Features three color temperatures (Warm Light 3000K, Natural Light 4500K, Day Light 6000K) with soft, bright, and non-blinding illumination (180W equivalent).
- **Easy Installation:** Designed for self-installation with detailed instructions and video support.



Figure 2.1: Overview of fan features including remote control, quiet DC motor, 6 speeds, timer, easy installation, and reversible function.

3. Specifications

Specification	Detail
Brand	ocioc
Model Name	9012
Size	32 inch
Color	Black
Product Dimensions	32"D x 32"W x 10"H
Item Weight	8.12 pounds
Power Source	AC

Wattage	48 watts
Voltage	120 Volts
Motor Type	DC
Noise Level	30 Decibels
Number of Blades	3
Air Flow Capacity	1364 Cubic Feet Per Minute
Control Method	Remote
Special Features	3 Color Temperature, DC Reversible Motor, LED Light, Remote Controlled, Timer
Indoor/Outdoor Usage	Indoor, Outdoor
Included Components	Light Kit, Remote

4. Setup & Installation

Follow these steps for proper installation of your ocioc ceiling fan. It is recommended to watch the installation videos for visual guidance.

Components Overview

Figure 4.1: All components included in the fan package.

Installation Steps

1. **Prepare the Motor Base:** Remove the motor base of the fan by unscrewing the four screws that secure it. Carefully remove the screws one by one and place them safely aside.
2. **Attach Fan Blades:** Take out the three fan blades. Insert each blade into its designated slot in the motor. Tighten the two screws on each blade securely. Repeat for all blades.
3. **Install Light Fixture:** Flip the fan over. Screw the light fixture into the blade's mounting hole one by one, ensuring all screws are securely fastened. Lock the safety rope to the motor base.
4. **Connect Light Wires:** Connect the light wires to the fan motor using the wiring terminals, ensuring correct orientation and secure connections.
5. **Connect Controller Wires:** Connect the wires from the controller to the motor power wires, matching the colors accordingly. Ensure each wire is securely connected and the plugs are fully inserted.
6. **Mount Hanger Bracket:** Secure the hanger bracket to the ceiling with four screws.
7. **Hang the Fan:** Align the fan's holes with the small hooks on the bracket, then hang the fan securely.
8. **Connect Ceiling Wiring:** Connect the wiring from the fan controller to the live wire, neutral wire, and ground wire in the ceiling. Ensure all connections are secure.
9. **Final Securement:** Hang the entire ceiling fan to the ceiling mounting base. Tighten the fan with screws to ensure it is firmly installed.

Installation Videos

Your browser does not support the video tag.

Video 4.2: Detailed guide on how to install the ocioc 32-inch ceiling fan. This video covers component assembly and ceiling mounting.

Your browser does not support the video tag.

Video 4.3: Another perspective on the ocioc Small Ceiling Fan Installation, providing additional visual assistance for the setup process.

Your browser does not support the video tag.

Video 4.4: General Ceiling Fan Installation Video, useful for understanding common wiring and mounting procedures.

5. Operating Instructions

Your ocioc ceiling fan is operated using the included remote control. Ensure the remote has working batteries.

Remote Control Functions

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Select from 6 different wind speed settings to adjust airflow intensity.
- **Timer Settings:** Set the fan to turn off automatically after 1 hour, 2 hours, or 4 hours.
- **Light Control:** Adjust the LED light through three color temperatures: Warm Light (3000K), Natural Light (4500K), and Day Light (6000K). The light is dimmable.
- **Reversible Motor:** Use the reversible function to change the direction of the fan blades. Downward airflow is ideal for cooling in summer, while upward airflow helps circulate warm air in winter.



Figure 5.1: Three color temperature options for the integrated LED light.



Figure 5.2: Illustration of the 6 adjustable fan speeds and their corresponding wind intensity.



Figure 5.3: Visual representation of the reversible motor function for seasonal use.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Screws:** Check all screws and connections annually to ensure they are secure. Loose connections can cause noise or malfunction.
- **Blade Balance:** If the fan wobbles, check that the blades are securely attached and balanced.

7. Troubleshooting

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Fan does not start	No power supply; Loose wiring; Remote control battery low	Check circuit breaker; Verify all wire connections; Replace remote control batteries.
Light does not work	Loose light wiring; LED module failure	Check light wire connections; Contact customer support if LED module is faulty.
Fan wobbles	Loose blade screws; Unbalanced blades; Improper mounting	Tighten all blade screws; Ensure blades are balanced; Recheck mounting bracket installation.
Excessive noise	Loose screws; Motor issue	Check and tighten all screws; If noise persists, contact customer support.

8. Warranty & Support

For any problems or inquiries regarding your ocioc ceiling fan, please contact customer support. Detailed installation instructions and videos are provided to assist with setup. If you encounter any issues, please reach out to us for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B5X5JQQH

More documents and user manuals: **https://manuals.plus/**