

[Manuals.plus](#) /

› [DOOGEE](#) /

› DOOGEE V30T 5G Unlocked Smartphone User Manual

DOOGEE V30T

DOOGEE V30T 5G Unlocked Smartphone User Manual

Model: V30T | Brand: DOOGEE

WELCOME TO YOUR DOOGEE V30T MANUAL

This comprehensive user manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new DOOGEE V30T 5G Unlocked Smartphone. Please read this manual carefully to ensure optimal performance and longevity of your device.



The DOOGEE V30T smartphone, showcasing its rugged design and display.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in your package:

- DOOGEE V30T Smartphone
- Charger (if included in your region's package)
- USB-C Cable
- SIM Ejector Tool
- User Manual (this document)

- Warranty Card (if applicable)

Note: Specific accessories may vary by region or package version.

KEY FEATURES AND COMPONENTS

Display

The DOOGEE V30T features a 6.58-inch Full HD+ screen with a 2408x1080 resolution and a 120Hz refresh rate, providing smooth visuals and responsive performance for all your content.



Provide super-fast refresh rates for high-speed games, fast apps running, smooth video and more

			
2408*1080/2K Resolution	120Hz Refresh Rate	480 Brightness	Corning Gorilla Glass 5



The vibrant 6.58-inch FHD+ display with 120Hz refresh rate.

Camera System

Equipped with a versatile camera system, the V30T includes a 108MP main camera for high-resolution photos, a 20MP

night vision camera for low-light conditions, a 16MP wide-angle & macro camera, and a 32MP front camera for stunning selfies and video calls.



Overview of the DOOGEE V30T's multi-camera setup.

Battery and Charging

The device is powered by a large 10800mAh battery, designed for extended usage. It supports 66W fast charging for quick power-ups and 15W wireless charging for convenience. OTG reverse charging is also available.

10800mAh Long Lasting Battery



15W

Wireless Charging



OTG

Reverse Charging



The powerful 10800mAh battery and fast charging capabilities.

Performance and Storage

With 20GB of RAM (including virtual RAM) and 256GB of internal storage, the V30T ensures smooth multitasking and ample space for your apps, photos, and videos. Storage can be expanded up to 2TB.

20GB(12+8GB Virtual) RAM+256GB ROM

Support 2TB Expansion



The DOOGEE V30T's memory and storage capabilities.

Rugged Design

Built to withstand harsh environments, the DOOGEE V30T is MIL-STD-810H certified, IP68 waterproof (up to 1.5m for 30 minutes), and IP69K dustproof, making it highly durable for outdoor and demanding use.




MIL-STD-810H
A tough phone born
for harsh environment


IP68
Waterproof 30 minutes
1.5m deep


IP69K
Dustproof 360°

**MILITARY
GRADE
MIL-STD 810H
DROP ★ TEST
CERTIFIED**



The DOOGEE V30T's military-grade ruggedness and water/dust resistance.



The DOOGEE V30T demonstrating its waterproof capabilities.

INITIAL SETUP GUIDE

1. **Insert SIM Card(s):** Locate the SIM card tray on the side of the phone. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM card(s) and/or a microSD card (for storage expansion) into the designated slots. Ensure the tray is fully reinserted.
2. **Charge the Battery:** Connect the USB-C cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet. It is recommended to fully charge the device before first use.
3. **Power On:** Press and hold the Power button (usually on the right side) until the DOOGEE logo appears on the screen.
4. **Initial Configuration:** Follow the on-screen prompts to set up your device. This includes selecting your language, connecting to a Wi-Fi network, setting up your Google account, and configuring security features like face recognition or fingerprint unlock.

OPERATING YOUR DEVICE

Basic Navigation

The DOOGEE V30T uses a touchscreen interface. Swipe, tap, and pinch gestures are used for navigation and interaction with apps and content.

- **Home Screen:** The central hub for your apps and widgets.
- **App Drawer:** Swipe up from the home screen to access all installed applications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.

Making Calls and Sending Messages

Use the Phone app to make calls and the Messages app for SMS/MMS. Ensure your SIM card is active and has network

coverage.

Using the Camera

Open the Camera app to capture photos and videos. You can switch between different camera modes (Photo, Video, Night Vision, Wide Angle, Macro) and adjust settings like flash, HDR, and filters.

Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available Wi-Fi networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with Bluetooth devices like headphones or speakers.
- **NFC:** The device supports NFC for contactless payments and quick pairing with compatible devices. Enable it in Settings > Connected devices > Connection preferences > NFC.

DEVICE CARE AND MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check for and install system updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > System > System update.
- **Battery Optimization:** To prolong battery life, manage background app usage, reduce screen brightness, and disable features like Wi-Fi or Bluetooth when not in use.
- **Storage Management:** Periodically clear unnecessary files and uninstall unused apps to free up storage space and maintain optimal performance.

COMMON ISSUES AND SOLUTIONS

Problem	Solution
Device won't turn on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, try a forced restart (hold Power button for 10-15 seconds).
Poor network signal	Check if your SIM card is properly inserted. Move to an area with better network coverage. Restart the device.
Apps are crashing or freezing	Clear the app's cache and data (Settings > Apps > [App Name] > Storage & cache). Update the app to its latest version. If the issue persists, uninstall and reinstall the app.
Battery drains quickly	Reduce screen brightness, disable unused features (Wi-Fi, Bluetooth, GPS), close background apps, and check battery usage in settings to identify power-hungry apps.

Problem	Solution
Fingerprint sensor not working	Ensure your finger is clean and dry. Re-register your fingerprint in Settings > Security > Fingerprint Unlock.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Name	V30T
Display Size	6.58 Inches
Display Resolution	2408x1080 (FHD+)
Refresh Rate	120Hz
RAM	20 GB (12GB + 8GB Virtual)
Internal Storage	256 GB
Expandable Storage	Up to 2TB via microSD
Main Camera	108 MP
Night Vision Camera	20 MP
Wide Angle & Macro Camera	16 MP
Front Camera	32 MP
Battery Capacity	10800 mAh
Fast Charging	66W
Wireless Charging	15W
Operating System	Android (version not specified, assumed latest at release)
Processor	MediaTek Dimensity 1080 (Octa-core, 2.6 GHz)
Connectivity	5G, Wi-Fi 6, Bluetooth, NFC
SIM Card Slot	Dual SIM
Dimensions	6.67 x 3.2 x 0.63 inches
Weight	13.3 ounces

Feature	Detail
Durability	MIL-STD-810H, IP68 (Waterproof), IP69K (Dustproof)
Security	Face Recognition, Fingerprint Sensor

WARRANTY INFORMATION AND SUPPORT

Your DOOGEE V30T smartphone comes with a **2-Year Limited Warranty**, covering manufacturing defects from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please visit the official DOOGEE website or contact their customer service. You can find more information and support resources at the [DOOGEE Store on Amazon](#).

After-sales Support





30-Day

Money Back Guarantee and Free Return



2-Year

Limited Warranty



24/7

Online Support 1-on-1

DOOGEE's commitment to after-sales support.

© 2023 DOOGEE. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question