

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tronsmart](#) /

› [Tronsmart T7 Mini Compact Portable Bluetooth Speaker User Manual](#)

Tronsmart T7 mini

Tronsmart T7 Mini Portable Bluetooth Speaker User Manual

Model: T7 mini | Brand: Tronsmart

INTRODUCTION

Thank you for purchasing the Tronsmart T7 Mini Portable Bluetooth Speaker. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and longevity of your device. Please read it carefully before use.



Figure 1: Tronsmart T7 Mini Portable Bluetooth Speaker.

WHAT'S IN THE BOX

- 1 x Tronsmart T7 Mini Outdoor Speaker
- 1 x User Manual
- 1 x Warranty Card
- 1 x Type-C Charging Cable
- 1 x Aux-in Cable

PRODUCT OVERVIEW

Controls and Indicators



Figure 2: Top control panel with power, play/pause, volume, and light buttons.

Power Button: Press and hold for 2 seconds to power on/off. Press once to switch modes (Bluetooth, TF Card, AUX-in). Double press to enter/exit stereo pairing.

Play/Pause Button: Press once to play/pause music. Double press to activate voice assistant. Press once to answer/hang up phone call. Press for 2 seconds to reject phone call. Press for 8 seconds to reset.

LED Light Switch: Press once to turn on/off LED indicator or switch lighting modes.

Volume +: Press once to turn up volume. Double press to skip to next track.

Volume -: Press once to turn down volume. Double press to skip to previous track.

Volume + & Volume - (simultaneously): Press for 2 seconds to disconnect from device.

Ports and Design



Figure 3: Internal view highlighting 15W audio driver and port locations.

The speaker features a durable fabric mesh exterior and rubberized top and bottom for enhanced grip and protection. A rubber gasket covers the charging and auxiliary ports to maintain its waterproof rating. It also includes a built-in lanyard for easy portability.

SETUP

Charging the Speaker

Before first use, fully charge your Tronsmart T7 Mini speaker. Connect the provided Type-C charging cable to the speaker's charging port and a compatible USB power source. The LED indicator will show charging status. A full charge takes approximately 3 hours.

Bluetooth Pairing

1. Power on the speaker by pressing and holding the Power button for 2 seconds. The LED light will illuminate.
2. On your device (smartphone, tablet), enable Bluetooth and search for