

[Manuals.plus](#) /

> [SUPERJARE](#) /

> SUPERJARE VC80924ZCH 4-Tier Bakers Rack with Power Outlets Instruction Manual

SUPERJARE VC80924ZCH

SUPERJARE 4-Tier Bakers Rack with Power Outlets

Model: VC80924ZCH

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before assembly.
- Do not overtighten screws during assembly to avoid damaging components.
- Place the rack on a flat, stable surface to prevent tipping.
- Do not exceed the maximum weight capacity for each shelf. The main wooden shelf supports up to 88 lbs.
- Keep children and pets away from the assembly area.
- Only use the integrated power outlets for appliances within their specified wattage.

PACKAGE CONTENTS

Verify that all components are included in your package:

- Metal frame components
- Wooden shelves
- Wire mesh shelves
- Integrated power strip with 2 AC outlets and 1 switch
- 10 S-shaped hooks
- Adjustable feet
- Assembly hardware (screws, wrench, etc.)
- Instruction manual

SETUP AND ASSEMBLY

Follow these general steps to assemble your bakers rack. Refer to the included diagram for specific part identification and order of assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Frame:** Connect the main vertical metal poles using the provided hardware.
3. **Attach Shelves:** Secure the wooden and wire mesh shelves to the frame. The wire mesh shelves are height-adjustable.
4. **Install Power Strip:** Mount the integrated power strip onto the designated wooden panel.
5. **Attach Hooks:** Place the S-shaped hooks onto the hanging strip as desired.
6. **Adjust Feet:** Once assembled, adjust the leveling feet at the bottom of the rack to ensure stability on uneven floors.



Overall view of the SUPERJARE 4-Tier Bakers Rack with Power Outlets, demonstrating its capacity and design.

Height-Adjustable Shelves

Shelves can be adjusted to different heights. All your tall and short objects will find suitable places.




Diagram illustrating the height-adjustable shelves feature, allowing customization for various item sizes.



Close-up of the adjustable feet, designed to ensure stability and protect floors.



OPERATING INSTRUCTIONS

This bakers rack is designed for versatile use in your kitchen or other areas, offering both storage and convenient power access.

Using the Integrated Power Outlets

The rack includes a built-in power strip with two AC outlets and a master switch. This allows you to power small kitchen appliances directly from the rack, reducing cord clutter.

- Plug the rack's main power cord into a wall outlet.
- Connect your appliances (e.g., coffee maker, microwave) to the AC outlets on the power strip.
- Use the red switch to turn the power strip on or off.



Detail of the integrated power strip with two AC outlets and a power switch for convenient appliance use.

Your browser does not support the video tag.

Official product video demonstrating the features and versatility of the SUPERJARE Kitchen Baker's Rack, including its power outlets and storage capabilities.

Utilizing S-Shaped Hooks

The 10 S-shaped hooks can be attached to the hanging strip or mesh shelves to organize utensils, mugs, or other small items.




Image showing the S-shaped hooks used for hanging mugs and utensils on the rack.

Adjusting Shelf Height

The wire mesh shelves are height-adjustable. To adjust, loosen the clips holding the shelf in place, reposition the shelf to the desired height, and re-secure the clips firmly.

MAINTENANCE

Proper maintenance ensures the longevity and appearance of your bakers rack.

- **Cleaning:** Wipe the surfaces with a dry cloth to remove dust and spills. Avoid abrasive cleaners that

may damage the finish.

- **Stability Check:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Adjust Feet:** Re-adjust the leveling feet if the rack becomes wobbly.

TROUBLESHOOTING

If you encounter any issues with your bakers rack, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rack is wobbly	Uneven floor; loose connections	Adjust the leveling feet; tighten all screws.
Power outlets not working	Power switch off; rack not plugged in; circuit overload	Ensure the red power switch is on; check if the rack's main cord is securely plugged into a wall outlet; reduce the number of appliances plugged in.
Shelf not holding weight	Exceeding weight capacity; improper installation	Ensure weight is within limits (88 lbs for main wooden shelf, 33 lbs for wire shelves); re-install shelf clips securely.

SPECIFICATIONS

Feature	Detail
Model Number	VC80924ZCH
Dimensions (D x W x H)	13.7" x 35.4" x 62.9"
Material	Engineered Wood, Metal
Number of Shelves	4
Main Wooden Shelf Weight Capacity	88 Pounds
Wire Mesh Shelf Weight Capacity	33 Pounds (each)
Power Outlets	2 AC Outlets, 1 Switch
Special Features	Adjustable Shelves, Charging Station, 10 S-Shaped Hooks
Color	Rustic Brown
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or product support, please contact SUPERJARE customer service directly. Details can typically be found on the product packaging or the manufacturer's official website.

