Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC/AC Adapter

onerbl AC/AC Adapter User Manual

Compatible with Yamaha MG8/2FX 8-Input Stereo Mixer

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/AC Adapter. This power supply is specifically designed to be compatible with the Yamaha MG8/2FX 8-Input Stereo Mixer, providing the necessary AC power for its operation. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The onerbl AC/AC Adapter. This image displays the main power adapter unit with its attached power cord and barrel connector output cable.

2. Important Safety Information

WARNING: To reduce the risk of fire or electric shock, carefully follow these instructions.

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations only. Do not expose to rain, moisture, or extreme temperatures.
- **Correct Voltage:** Ensure the wall outlet voltage matches the adapter's input requirements (AC 110V).
- **AC to AC Output:** This adapter provides an AC output, not DC. Ensure your device (Yamaha MG8/2FX) requires an AC input. Connecting to a DC-only device may cause damage.
- **Proper Connection:** Always connect the adapter to the device first, then plug the adapter into the wall outlet. When disconnecting, unplug from the wall outlet first.
- **Avoid Overloading:** Do not overload wall outlets or extension cords.
- **Cable Care:** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the adapter.
- **No Disassembly:** Do not attempt to open or modify the adapter. There are no user-serviceable parts inside.
- **Children and Pets:** Keep the adapter out of reach of children and pets.



Image 2.1: Smart Chip with Multiple Protection. This graphic illustrates the adapter's built-in safeguards, including short-circuit protection, over-voltage protection, and over-current protection, designed to enhance electrical safety.

3. Setup Instructions

Follow these steps to properly connect your onerbl AC/AC Adapter to your Yamaha MG8/2FX Mixing Console:

1. **Verify Compatibility:** Confirm that your device is a Yamaha MG8/2FX Mixing Console and requires an AC power input.
2. **Inspect Adapter:** Before connecting, visually inspect the adapter and its cables for any signs of damage. Do not use if damaged.
3. **Connect to Mixer:** Locate the power input port on your Yamaha MG8/2FX Mixing Console. Carefully insert the barrel connector of the onerbl AC/AC Adapter into this port. Ensure a snug fit.

4. **Connect to Power Outlet:** Plug the AC power cord of the adapter into a standard AC 110V wall outlet.
5. **Power On:** Once connected, you can power on your Yamaha MG8/2FX Mixing Console according to its own operating instructions.

4. Operating Instructions

The onerbl AC/AC Adapter operates automatically once connected to a power source and your Yamaha MG8/2FX Mixing Console. It provides continuous AC power to your device.

- **Continuous Power:** The adapter is designed for continuous operation.
- **Disconnection:** To disconnect power, first turn off your Yamaha MG8/2FX Mixing Console, then unplug the adapter from the wall outlet, and finally disconnect the barrel connector from the mixer.

5. Maintenance and Care

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Cable Inspection:** Periodically inspect the power cord and connector for any signs of wear, cuts, or damage. Replace the adapter if any damage is found.



Image 5.1: Durable Design and Quality Control. This image highlights the internal construction, showing copper wires and a PVC jacket, indicating a focus on durability and quality in the adapter's design.

6. Troubleshooting

If you encounter issues with your onerbl AC/AC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to mixer	Adapter not plugged in correctly Wall outlet not functioning Damaged adapter or cable	Ensure adapter is fully plugged into both the mixer and the wall outlet. Test the wall outlet with another device. Inspect adapter and cables for damage. If damaged, discontinue use and replace.
Mixer powers on intermittently	Loose connection Faulty adapter	Check all connections for tightness. If problem persists, the adapter may be faulty and require replacement.
Adapter feels excessively hot	Poor ventilation Overload Internal fault	Ensure adapter is in a well-ventilated area. Do not cover. Verify the mixer's power requirements are within the adapter's specifications. If overheating continues, discontinue use immediately and replace.

7. Specifications

- **Brand:** onerbl
- **Input Voltage:** AC 110V (North American standard)
- **Output Type:** AC (Alternating Current)
- **Output Voltage:** 110 Volts
- **Connector Type:** Barrel Connector
- **Compatibility:** Yamaha Mixing Console MG8/2FX
- **Item Weight:** Approximately 8 ounces (227 grams)
- **Cable Length:** Approximately 6.6 ft (2 meters) for the output cable, and 10 ft (3 meters) for the input cable.




Image 7.1: Extended Cord Design. This image illustrates the generous cable lengths provided with the adapter, showing both a 10 ft and a 6.6 ft cable, offering flexibility in placement.

8. Warranty and Support

This onerbl AC/AC Adapter comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact the retailer from whom you purchased the product. For technical support or inquiries, please contact onerbl customer service through the retailer's platform or the contact information provided with your purchase.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B63JDTL6

More documents and user manuals: **https://manuals.plus/**