

- Manuals.plus /
- › **PERFASCIN** /
- › PERFASCIN AR-JW2 Replacement Remote Control for Fujitsu Air Conditioner User Manual

PERFASCIN AR-JW2

PERFASCIN AR-JW2 Replacement Remote Control User Manual

Model: AR-JW2

1. INTRODUCTION

This manual provides instructions for the PERFASCIN AR-JW2 Replacement Remote Control, designed for use with various Fujitsu Air Conditioner models. This remote control offers a straightforward solution for operating your air conditioning unit without complex setup procedures.

Compatible Models: This remote is compatible with a wide range of Fujitsu Air Conditioner models, including but not limited to: AR-JW1, AR-JW2, AR-JW3, AR-JW4, AR-JW5, AR-JW6, AR-JW7, AR-JW8, AR-JW9, AR-JW10, AR-JW11, AR-JW12, AR-JW13, AR-JW14, AR-JW15, AR-JW16, AR-JW17, AR-JW18, AR-JW19, AR-JW20, AR-JW21, AR-JW22, AR-JW23, AR-JW24, AR-JW25, AR-JW26, AR-JW27, AR-JW28, AR-JW29, AR-JW30, AR-JW31, AR-JW32, AR-JW33, AR-JW34, AR-JW35, AR-JW36, AR-JW37, AR-JW38.



Figure 1: Front view of the PERFASCIN AR-JW2 Replacement Remote Control, showing its buttons and display.

2. SAFETY INFORMATION

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always remove exhausted batteries promptly.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.
- Keep batteries out of reach of children.

3. PACKAGE CONTENTS

The package includes:

- 1 x PERFASCIN AR-JW2 Replacement Remote Control

Note: Two (2) AAA batteries are required and are not included in the package.

4. SETUP

This remote control requires no programming or complex setup. Simply insert the batteries, and it is ready for use.

4.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards in the direction of the "OPEN" arrow to remove it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open, showing the slots for two AAA batteries.

5. OPERATING INSTRUCTIONS

The PERFASCIN AR-JW2 remote control provides direct access to common Fujitsu Air Conditioner functions. Point the

remote control directly at the air conditioner's receiver when operating.

5.1 Key Functions

- **START/STOP Button:** Powers the air conditioner ON or OFF.
- **Temperature Adjustment Buttons (+/-):** Increases or decreases the set temperature.
- **FAN Button:** Adjusts the fan speed.
- **MODE Button:** Cycles through operating modes (e.g., Cool, Heat, Dry, Fan).
- **SLEEP Button:** Activates or deactivates the sleep mode.
- **TIMER Button:** Sets or cancels the timer function.
- **SWING Buttons (SET SWING):** Controls the vertical and horizontal louver swing.
- **TIME ADJUST / ACL:** Used for setting the clock or resetting settings (ACL).

Important Note on Temperature Display: This remote control is designed to display temperature in **Fahrenheit ONLY**, specifically for the USA and Canada markets. It does not support Celsius display.

6. MAINTENANCE

6.1 Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

6.2 Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Follow the battery installation steps in Section 4.1.

7. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure the remote is pointed directly at the air conditioner's receiver.
 - Check if the batteries are correctly inserted with the correct polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote and the air conditioner.
- **Temperature display is incorrect (e.g., showing Celsius):**
 - This remote control is designed for Fahrenheit display only. If your unit displays Celsius, this remote may not be fully compatible with that specific display setting, even if other functions work.

8. SPECIFICATIONS

Model Number	AR-JW2
Brand	PERFASCIN
Compatible Devices	Fujitsu Air Conditioners
Power Source	2 x AAA Batteries (not included)

Product Dimensions	6 x 3 x 0.5 inches (approx.)
Item Weight	2 ounces (without batteries)
Special Feature	No Programming Required, Fahrenheit Display Only

9. SUPPORT

For any questions regarding the quality or functionality of your PERFASCIN AR-JW2 Replacement Remote Control, please contact our customer support. We are committed to resolving any issues promptly.

Contact information is typically provided by the seller at the point of purchase or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B63RCBWD>

More documents and user manuals: <https://manuals.plus/>