

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZHIBAI](#) /

› [ZHIBAI Rechargeable Electric Fabric Shaver \(Model QL-01\) User Manual](#)

ZHIBAI QL-01

ZHIBAI Rechargeable Electric Fabric Shaver (Model QL-01)

USER MANUAL

[Safety Instructions](#)

[Package Contents](#)

[Product Overview](#)

[Setup](#)

[Charging](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

1. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the ZHIBAI Electric Fabric Shaver. Retain this manual for future reference.

- Keep the device out of reach of children and pets.
- Do not use the shaver on skin or directly on clothing while wearing it.
- Ensure the fabric is laid flat and taut to prevent damage.
- Do not immerse the device in water or any other liquid.
- Avoid using the shaver in wet environments.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Always turn off the device before cleaning or replacing blades.
- Use only the provided USB-C cable for charging.
- Do not use the device if the blade cover is damaged or missing.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- ZHIBAI Electric Fabric Shaver (Model QL-01)
- USB-C Charging Cable
- 2 x Replacement Blade Sets
- Cleaning Brush
- Instruction Manual (this document)



Image 1: The ZHIBAI Electric Fabric Shaver, including two replacement blade sets, a USB-C charging cable, and a cleaning brush.

3. PRODUCT OVERVIEW

The ZHIBAI Electric Fabric Shaver is designed to efficiently remove lint, fuzz, and pills from various fabric types, restoring their appearance. It features a powerful motor, durable blades, and an adjustable shaving height for optimal results.

Key Features:

- **Efficient Performance:** Equipped with a powerful motor and aerodynamic design for quick lint removal without clogging.
- **Adjustable Shaving Height:** Five adjustable fabric-mesh distances accommodate various fabric surfaces, from delicate to coarse.
- **Versatile Use:** Suitable for a wide range of fabrics, including clothing, couches, furniture, and bedding.
- **Rechargeable Battery:** Built-in lithium-ion battery provides up to 80 minutes of operation on a full charge.
- **USB-C Charging:** Conveniently charges via USB-C from various power sources.
- **Large Lint Bin:** Reduces the frequency of emptying, with a transparent window to monitor lint accumulation.
- **Easy Cleaning:** Features a one-click release button for quick and hygienic lint bin emptying.

Cyclone Convection Design

Remove lint from the blade instantly,
No decline in performance.



Image 2: An internal diagram illustrating the cyclone convection design, which helps remove lint from the blades instantly to maintain performance.

4. SETUP

Initial Charge:

1. Before first use, fully charge the fabric shaver. Refer to the "Charging" section for detailed instructions.
2. Ensure the device is turned off during charging.

Blade Installation:

The shaver comes with blades pre-installed. If you need to install or replace them:

1. Ensure the device is turned off and unplugged.
2. Gently twist and remove the protective mesh cover.
3. Carefully remove the old blade set by lifting it from the center spindle.
4. Align the new blade set with the spindle and press down gently until it clicks into place.
5. Replace the protective mesh cover, ensuring it is securely fastened.

5. CHARGING

The ZHIBAI Fabric Shaver is powered by a rechargeable lithium-ion battery.

- Connect the provided USB-C cable to the charging port on the shaver.
- Plug the other end of the USB-C cable into a compatible power source (e.g., PC, power bank, or a 5V/1A DC adapter).
- The charging indicator light will illuminate during charging and change color or turn off when fully charged.
- A full charge typically takes approximately 2 hours and provides up to 80 minutes of continuous use.



Image 3: The fabric shaver being charged via its USB-C cable, demonstrating compatibility with various power sources like laptops, power banks, and car chargers.

6. OPERATING INSTRUCTIONS

Using the Fabric Shaver:

1. Ensure the shaver is fully charged and the lint bin is empty.
2. Lay the garment or fabric flat on a hard, smooth surface. Stretch the fabric taut to ensure an even surface.
3. Adjust the shaving height according to the fabric type (see "Adjusting Shaving Height" section).
4. Press the power button to turn on the shaver.
5. Gently glide the shaver head over the pillied or fuzzed area in small, circular motions. Avoid pressing too hard.
6. Regularly check the lint bin through the transparent window. Empty it when it appears full to maintain optimal performance.
7. Once finished, press the power button to turn off the shaver.




Image 4: A hand operating the ZHIBAI Fabric Shaver on a gray sweater, demonstrating its use on various fabric items like socks, bedding, sweaters, furniture, and wool coats.

7. ADJUSTING SHAVING HEIGHT

The ZHIBAI Fabric Shaver features 5 adjustable fabric-mesh distances to protect different fabric types and achieve the best results.

- Locate the adjustment dial on the top of the shaver head.
- Rotate the dial to select the desired height setting (0-4).

- **Setting 0:** Recommended for most clothing and general use.
- **Settings 1-4:** Use higher settings for more delicate fabrics or when less aggressive shaving is required. Lower settings are for tougher pills or more durable fabrics.
- Always test on an inconspicuous area of the fabric first to ensure the chosen setting is appropriate.

Keep Your Fabrics Looking like New



Recommend gear **0** for most clothing



Image 5: A close-up view of the fabric shaver's head, highlighting the adjustable dial for setting the shaving height. Setting '0' is recommended for most clothing.

8. CLEANING AND MAINTENANCE

Emptying the Lint Bin:

1. Ensure the shaver is turned off.
2. Press the ergonomically designed release button located at the back of the lint bin.
3. The lint bin will detach. Empty the collected lint into a waste receptacle.
4. Reattach the lint bin securely until it clicks into place.

Unique Patent Design: One Click to Clean

Only press the release button to clean the lint bin



Image 6: A hand demonstrating the one-click cleaning feature, showing lint being emptied from the shaver's collection bin into a waste bin.

Cleaning the Blades and Mesh Cover:

1. Turn off the shaver and remove the lint bin.
2. Gently twist and remove the protective mesh cover.
3. Carefully remove the blade set.
4. Use the provided cleaning brush to remove any trapped lint or debris from the blades, the mesh cover, and the internal area of the shaver.
5. Ensure all components are dry before reassembling.

Replacing Blades:

The shaver includes 2 extra blade sets. Each blade set can last for approximately 2-3 years, depending on usage. Replace blades when you notice a decrease in shaving efficiency.

1. Follow steps 1-3 from "Cleaning the Blades and Mesh Cover" to remove the old blade set.
2. Carefully place a new blade set onto the central spindle, ensuring it sits flat and securely.
3. Reattach the protective mesh cover and the lint bin.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
	Blade cover or lint bin not securely attached.	Ensure all parts are correctly assembled and locked into place.
Poor lint removal performance.	Lint bin is full.	Empty the lint bin.
	Blades are dull or clogged.	Clean the blades with the brush or replace them.
	Incorrect shaving height setting.	Adjust the shaving height to a lower setting for more effective removal.
Shaver stops during use.	Battery is low.	Recharge the shaver.
	Overheating protection activated.	Turn off the shaver and allow it to cool down for a few minutes before resuming use.

10. SPECIFICATIONS

Feature	Detail
Brand	ZHIBAI
Model Number	QL-01
Material	Stainless Steel (Blades), Alloy Steel (Handle)
Color	Silver
Product Dimensions	2.9"D x 2.8"W x 8.1"H
Operation Mode	Automatic
Item Weight	12 ounces
Battery Type	1 Lithium Ion battery (included)

Feature	Detail
Charging Interface	USB-C
Adjustable Heights	5 levels

11. WARRANTY AND SUPPORT

ZHIBAI offers a **180-day free return or exchange guarantee** for this product. If you encounter any issues or have questions regarding your ZHIBAI Electric Fabric Shaver, please do not hesitate to contact our customer support team.

For support, please refer to the contact information provided on your purchase platform or the ZHIBAI official website.