

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PECOLE](#) /

› [PECOLE Dog Training Collar User Manual](#)

PECOLE PE-18

PECOLE Dog Training Collar User Manual

Model: PE-18

Brand: PECOLE

INTRODUCTION

This user manual provides comprehensive instructions for the PECOLE Dog Training Collar, Model PE-18. This device is designed to assist in dog training through various modes, promoting positive behavior and effective communication between you and your canine companion. Please read this manual thoroughly before use to ensure proper operation and safety.



Image: The PECOLE Dog Training Collar system, showing the remote transmitter and the collar receiver.

PRODUCT COMPONENTS

The PECOLE Dog Training Collar kit includes the following items:

- Receiver with adjustable dog collar
- Transmitter (Remote Control)
- USB Charging Cable (2-in-1)
- Wrist Strap
- Test Light Tool
- Contact Points (short and long)
- Conductive Silicone Prongs (rubber caps)
- User Manual (this document)

SETUP

1. Charging the Devices

Both the transmitter and the receiver are rechargeable. Use the provided 2-in-1 USB charging cable to charge both units simultaneously.

1. Connect the dual charging ends to the charging ports on the receiver and transmitter.
2. Connect the USB-A end of the cable to any standard 5V USB charging base (e.g., phone charger, power bank, PC/laptop USB port).
3. Charging time is approximately 2-3 hours.
4. The receiver has a standby time of up to 30 days (8 days working time).
5. The transmitter has a standby time of up to 45 days (12 days working time).

Long-Lasting Battery Life

Easy charging by your Power Bank / Phone Charger / PC / Laptop



Image: Illustration of the 2-in-1 USB charging cable connected to both the remote transmitter and the collar receiver for simultaneous charging.

2. Attaching Contact Points and Silicone Prongs

Select the appropriate contact points (short or long) based on your dog's coat thickness. For dogs with thicker coats, longer contact points may be necessary to ensure proper contact with the skin. Always attach the conductive silicone prongs (rubber caps) over the metal contact points for your dog's comfort and safety.

3. Fitting the Collar

Proper fit of the collar is crucial for effective operation and your dog's comfort. The collar is adjustable and suitable for all breeds weighing between 10-110 lbs.

1. Place the receiver unit centrally on your dog's neck, just below the ears.
2. Ensure the contact points are touching the skin. You may need to part your dog's fur to ensure good contact.
3. The collar should be snug enough that two fingers can barely fit between the strap and your dog's neck. It should not be too tight to restrict breathing or too loose to move around.
4. The nylon strap can be adjusted to fit. Excess strap can be cut off if desired.

Adjustable Collar FOR ALL BREEDS from 10-110 lb.



29 inch (Adjust from 10-110 lb.)



Extra part can be cut off

Image: Diagram showing the adjustable collar and its suitability for dogs ranging from 10 to 110 lbs, with an option to trim excess strap.

OPERATING INSTRUCTIONS

1. Powering On/Off

- To power on the receiver, press and hold the power button until the indicator light illuminates.
- To power on the transmitter, press any button.
- To power off, press and hold the power button on each unit until the indicator light turns off.

2. Training Modes

The PECOLE Dog Training Collar offers three distinct training modes:

- **Beep Mode:** Emits an audible tone. Ideal for initial training and gaining your dog's attention.
- **Vibration Mode (Levels 1-9):** Delivers a gentle vibration. Useful for mild corrections or as a precursor to static stimulation.
- **Shock Mode (Levels 1-99):** Provides static stimulation. Use with caution and at the lowest effective level. A "High level warning" is displayed for higher settings.

3 Training Modes

Let you customize corrections to your pup's compliance.



Beep Mode



Vibration Mode
(level 1-9)



Shock Mode
(level 1-99)
High level warning



Image: Visual representation of the three training modes (Beep, Vibration, Shock) and their respective intensity levels, with a dog wearing the collar.

3. Remote Control Operation

The transmitter allows remote control of the collar from a distance of up to 1,600 feet.

- Use the dedicated buttons on the remote to activate Beep, Vibration, or Shock modes.
- Adjust the intensity levels for Vibration and Shock modes using the remote's controls.




Image: A hand holding the remote transmitter, showing its long-range capability with a dog in the background.

4. Security Keypad Lock

For safety, the remote control is equipped with a keypad lock to prevent accidental activation or misuse of the training modes.

- Locate the lock switch on the side of the remote.
- Slide the switch to the locked position to disable button functions.
- Slide the switch to the unlocked position to enable button functions.

Security Keypad Lock

SAFETY COMES FIRST for you and your pet,
a keypad lock on the side can prevent accidental activation.



Image: A close-up of the remote transmitter highlighting the security keypad lock buttons on the side, with a person and dog in the background.

MAINTENANCE

1. Waterproof Design

The receiver collar is IPX7 waterproof, meaning it can withstand immersion in water up to 1 meter for 30 minutes. This allows for use in various weather conditions and during water activities.

IPX7 Waterproof

Dog collar for training frees you for impromptu trips to the park, no matter the weather.



Image: A dog wearing the collar playing in water, demonstrating its IPX7 waterproof rating.

2. Cleaning and Care

- Regularly inspect the collar and contact points for dirt or debris. Clean with a damp cloth.
- Ensure the contact points are clean and free of corrosion for optimal performance.
- The collar is made of heavy-duty nylon and designed for durability.
- Care Instructions: Keep away from Children.

TROUBLESHOOTING

If you encounter issues with your PEcole Dog Training Collar, please refer to the following common solutions:

- **No Response from Collar:**

- Ensure both the transmitter and receiver are fully charged.
- Check if both units are powered on.
- Verify that the remote's keypad lock is disengaged.

- Ensure the collar is properly paired with the remote. Refer to pairing instructions if needed (not detailed in provided data, but a common troubleshooting step).

- **Inconsistent Stimulation:**

- Check the fit of the collar. It should be snug with contact points touching the skin.
- Ensure the correct contact points (short/long) are used for your dog's coat thickness.
- Clean the contact points and your dog's neck area to remove any dirt or oil.

- **Short Battery Life:**

- Ensure the devices are fully charged for the recommended 2-3 hours.
- Avoid leaving the units powered on when not in use to conserve battery.

For further assistance, please contact PECOLE customer support.

SPECIFICATIONS

Brand	PECOLE
Model Number	PE-18
Item Weight	1.76 ounces (50 Grams)
Item Dimensions (LxWxH)	8.85 x 4.92 x 0.04 inches
Material	Nylon
Color	PE-18 (Black)
Battery Type	1 Lithium Polymer battery (included)
Charging Time	2-3 hours
Receiver Standby Time	Up to 30 days
Transmitter Standby Time	Up to 45 days
Waterproof Rating	IPX7 (Receiver)
Remote Range	Up to 1,600 feet
Age Range Description	All dogs of more than 6 months
Breed Recommendation	All type dogs
First Available Date	July 8, 2022

WARRANTY & SUPPORT

Warranty: The PECOLE Dog Training Collar comes with a 1 Year Warranty from the date of purchase.

Customer Support: For any questions, troubleshooting assistance, or warranty claims, please contact PECOLE customer service through the retailer where the product was purchased or visit the official PECOLE brand store online.

Note: Always ensure to follow all safety guidelines and consult with a professional dog trainer if you are unsure about using this product for your dog's specific needs.

