

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GOODTEL](#) /

> [GOODTEL G10 10-inch Android Tablet User Manual](#)

GOODTEL G10

GOODTEL G10 10-inch Android Tablet User Manual

Model: G10

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your GOODTEL G10 10-inch Android tablet. Please read this guide thoroughly to ensure proper use and to maximize your device's performance and longevity.

SETUP

1. Package Contents

Upon unboxing, verify that all items are present:

- GOODTEL G10 Tablet
- Stylus for touchscreen
- Protective case
- Charger
- User Manual

2. Charging the Tablet

Before first use, fully charge the tablet. Connect the provided charger to the USB Type-C port on the tablet and plug it into a power outlet. The charging indicator will show the charging status.

3. Powering On/Off

- **To Power On:** Press and hold the power button until the screen lights up.
- **To Power Off:** Press and hold the power button, then select 'Power off' from the options on the screen.

4. Inserting a MicroSD Card

The tablet supports MicroSD/TF cards from 4GB to 256GB for expanded storage. Locate the MicroSD card slot, gently insert the card with the gold contacts facing down until it clicks into place.

5. Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted, then tap **Connect**.

6. Bluetooth Pairing

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. The tablet will scan for available devices. Select the device you wish to pair with from the list.
4. Confirm the pairing code if prompted.



This detailed diagram illustrates the location and function of all external ports and buttons on the GOODTEL G10 tablet, such as the USB Type-C charging port, headphone jack, and MicroSD card slot.

OPERATING INSTRUCTIONS

1. Android 12 OS Navigation

Your GOODTEL G10 tablet runs on Android 12, offering an intuitive user interface. Swipe up from the bottom of the screen to access the app drawer, swipe down from the top for quick settings and notifications. The 10-inch IPS display provides wide viewing angles and responsive touch sensitivity.

2. Camera Usage

The tablet features a 5MP front camera and an 8MP rear camera. Open the Camera application to capture photos and videos. Tap the screen to focus and press the shutter button to take a picture.

3. Audio and Multimedia



This image highlights the main technical specifications and features of the GOODTEL G10 tablet, including its operating system, memory, connectivity options, and display characteristics.

5. Productivity and Communication

The G10 tablet is compatible with WPS Office and other office applications (WORD, EXCEL, PPT, PDF) for document editing and management. It supports voice and video calls, making it suitable for connecting with family, friends, and colleagues via applications like ZOOM.



The tablet is depicted in a work or study environment, paired with an external keyboard, demonstrating its use for educational purposes or office applications.

6. Parental Control


The tablet includes Google's Family Link parental control feature, allowing remote device management, usage time limits, and content filtering via the Family Link application.

7. Additional Features

The G10 supports gravity detection, FM radio, quick screenshot capture, and screen recording functionalities.



This image shows the tablet's user interface, featuring the Android home screen with common applications, indicating ease of access and navigation.



This image emphasizes the tablet's 10-inch IPS screen, known for its wide viewing angles and vivid color reproduction.



The GOODTEL G10 tablet is shown in a home setting, demonstrating its use for entertainment and interaction with smart home devices.

MAINTENANCE

1. Battery Care

The 8000mAh battery provides extended usage. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery fully discharge frequently.
- Use the original charger provided.

2. Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surface.

3. Software Updates

Regularly check for system updates in **Settings > System > System update** to ensure your tablet has the latest features and security patches. While specific software update guarantees are not available, keeping your device updated is recommended.

TROUBLESHOOTING

Common Issues and Solutions:

- **Tablet does not power on:** Ensure the tablet is sufficiently charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Wi-Fi connectivity issues:** Check if Wi-Fi is enabled in settings. Restart your Wi-Fi router. If the issue persists, try forgetting the network and reconnecting.
- **Applications are slow or unresponsive:** Close unused applications running in the background. Restart the tablet. If the problem continues, consider clearing the cache of problematic apps or performing a factory reset as a last resort (*note: a factory reset will erase all data on the table*).
- **Touchscreen is unresponsive:** Restart the tablet. Ensure the screen is clean and free of debris.

If you encounter issues not covered here, please refer to the support section for assistance.

SPECIFICATIONS

Brand	GOODTEL
Model Name	G10
Model Number	G2
Operating System	Android 12 OS
Processor	Octa-Core, 1.6 GHz
RAM	4 GB
Internal Storage (ROM)	64 GB
Expandable Storage	MicroSD/TF (4-256 GB)
Screen Size	10 Inches
Screen Type	IPS
Battery Capacity	8000 mAh
Rear Camera	8 MP
Front Camera	5 MP
Connectivity	WiFi, Bluetooth, AGPS, Hotspots
Wireless Technology	802.11b, 802.11g
Ports	USB Type-C, 3.5mm Headphone Jack

Weight	450 Grams
---------------	-----------

WARRANTY INFORMATION

Specific warranty details for the GOODTEL G10 tablet are not provided in the product information. Please refer to the warranty card included in your package or contact the seller/manufacturer directly for comprehensive warranty terms and conditions. Information regarding spare parts availability and guaranteed software updates is also not available.

SUPPORT

For further assistance, technical support, or inquiries regarding your GOODTEL G10 tablet, please contact our service team. GOODTEL provides a friendly and professional service and technical team dedicated to offering prompt and excellent pre-sales and after-sales support.

Please refer to the contact information provided with your purchase documentation or visit the official GOODTEL website for support options.

