

[Manuals.plus](#) /

› [AECOJOY](#) /

› AECOJOY 7-Piece Outdoor Dining Set Instruction Manual

AECOJOY 16081-98BK-04

AECOJOY 7-Piece Outdoor Dining Set Instruction Manual

Model: 16081-98BK-04

INTRODUCTION

Thank you for choosing the AECOJOY 7-Piece Outdoor Dining Set. This manual provides essential information for the safe assembly, proper use, and maintenance of your new patio furniture. Please read these instructions thoroughly before assembly and retain them for future reference.

SAFETY INSTRUCTIONS

- Always assemble the product on a soft, non-abrasive surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten all fasteners to maintain stability.
- Do not overload the table or chairs. The table has a weight capacity of 150 lbs.
- Ensure stability when stacking and storing chairs to prevent tip-overs.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Use the product only for its intended purpose as outdoor dining furniture.

PACKAGE CONTENTS

Your AECOJOY 7-Piece Outdoor Dining Set is delivered in 4 boxes. Please verify that all components are present before beginning assembly.

- 1 x Rectangular Dining Table
- 6 x Stackable Dining Chairs
- All necessary assembly tools and hardware
- Detailed instruction manual (this document)



Image: Product Dimensions. This diagram illustrates the dimensions of the dining table and six chairs included in the set.

ASSEMBLY INSTRUCTIONS

The assembly process for your AECOJOY dining set is designed to be straightforward. All required accessories and tools are included. No additional tools are needed.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to avoid scratches.
2. **Identify Parts:** Refer to the parts list in the included detailed instruction sheet to identify each component.
3. **Assemble Chairs:**
 - Attach the chair back to the seat frame using the provided hardware.
 - Connect the chair legs to the assembled seat and back.
 - *Important:* Hand-tighten all screws initially. Once all parts are aligned and connected, fully tighten all fasteners. This prevents misalignment and stripping.

4. Assemble Table:

- Attach the table legs to the tabletop frame.
- Secure any crossbars or support structures as indicated in the detailed instructions.
- Adjust the feet pads on the table legs to ensure stability on uneven surfaces.
- *Important:* Hand-tighten all screws initially. Once all parts are aligned and connected, fully tighten all fasteners.

5. **Final Check:** Ensure all components are securely fastened and the furniture is stable before use.



Image: Key Features and Assembly Details. This image illustrates the table's fashion pattern design, adjustable feet pads for stability, reinforced table structure, ergonomic chair design, and the metal frame for easy assembly.

USAGE

This AECOJOY 7-Piece Outdoor Dining Set is designed for comfortable outdoor dining and relaxation. Its spacious design accommodates up to 6 people, making it suitable for various settings.

- **Placement:** Ideal for gardens, backyards, decks, bistros, bars, and indoor spaces.
- **Stability:** Utilize the adjustable feet pads on the table to ensure a level and stable surface on various floor types.
- **Chair Use:** The chairs are designed for comfortable seating. Avoid standing on chairs or using them as step stools.
- **Table Use:** The large rectangular tabletop provides ample space for dining and other activities. Do not exceed the 150 lbs weight capacity.
- **Space Saving:** Chairs are stackable for convenient storage when not in use. They can also be placed under the table to save space.



Image: Stackable Design. This image illustrates how the chairs can be stacked to save space when not in use.

CARE AND MAINTENANCE

Proper care and maintenance will extend the life and appearance of your AECOJOY dining set.

- **Cleaning:** Wipe the table and chairs with a dry cloth. For more thorough cleaning, use a mild soap and water solution, then rinse thoroughly and dry completely to prevent water spots.
- **Material Specifics:** The powder-coated aluminum frame is rust-proof. The wood-plastic composite tabletop is designed for easy cleaning and maintenance.
- **Protection:** While designed for outdoor use, covering the set during harsh weather conditions (heavy rain, snow, intense sun) or prolonged periods of non-use can help preserve its condition.
- **Inspection:** Periodically inspect all nuts, bolts, and connections to ensure they remain tight. Re-tighten as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Furniture feels wobbly or unstable.	Loose fasteners or uneven surface.	Check and tighten all bolts and screws. Adjust the feet pads on the table legs to level the furniture.
Difficulty during assembly.	Parts misalignment or incorrect order of tightening.	Ensure all parts are loosely fitted before fully tightening any fasteners. Refer to the detailed assembly instructions.
Scratches or minor damage during assembly.	Assembly on a hard or abrasive surface.	Always assemble on a soft, protective surface (e.g., carpet, blanket). Minor scratches can sometimes be touched up with appropriate paint.

SPECIFICATIONS

- **Model:** 16081-98BK-04
- **Set Includes:** 1 Rectangular Dining Table, 6 Stackable Dining Chairs
- **Table Dimensions (L x W x H):** 59" x 35.5" x 29"
- **Chair Dimensions (W x D x H):** 22" x 25" x 34.5"
- **Table Weight Capacity:** 150 lbs
- **Materials:** Powder-coated Aluminum Frame, Wood-Plastic Composite Tabletop and Chair Slats
- **Color:** Matte Black
- **Style:** Modern
- **Total Item Weight:** Approximately 184.4 pounds (packaged)

WARRANTY AND SUPPORT

For warranty information, missing parts, or any questions regarding your AECOJOY 7-Piece Outdoor Dining Set, please contact AECOJOY customer support. Refer to the contact information provided at the point of purchase or on the official AECOJOY website.

Product Care Instructions: Wipe with Dry Cloth.

© 2024 AECOJOY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question