



Manuals.plus /

› DNKMOR /

› DNKMOR Portable Charcoal Grill User Manual

## DNKMOR A-01

# DNKMOR Portable Charcoal Grill User Manual

Model: A-01

Brand: DNKMOR

## 1. INTRODUCTION

Thank you for choosing the DNKMOR Portable Charcoal Grill. This compact and versatile grill is designed for convenient outdoor cooking, perfect for camping, picnics, backyard barbecues, and beach outings. Its lightweight and portable design, combined with ample grilling space, makes it an ideal solution for preparing meals for small to medium-sized groups.

This manual provides essential information for the safe and efficient operation, assembly, maintenance, and troubleshooting of your new grill. Please read it thoroughly before first use and retain it for future reference.

## 2. SAFETY INFORMATION


- Always use the grill outdoors in a well-ventilated area. Never use indoors or in enclosed spaces.
- Keep children and pets away from the hot grill.
- Place the grill on a stable, level, non-combustible surface.
- Do not move the grill while it is hot or in use.
- Use heat-resistant gloves when handling hot components.
- Allow the grill to cool completely before cleaning or storing.
- Never use gasoline, kerosene, or alcohol to light charcoal. Use only charcoal starter fluid.
- Keep a fire extinguisher or a bucket of sand nearby in case of fire.
- Ensure all charcoal is fully extinguished before disposing of ashes.

### 3. PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Grill Body with Lid
- Cooking Grid
- Charcoal Pan
- Wooden Handle (for lid)
- Built-in Thermometer
- Chimney/Ventilation System
- Legs (4)
- Assembly Hardware (screws, nuts, washers)
- Instruction Manual (this document)

## STURDY & DURABLE & PORTABLE



**CHIMNEY**



**THERMOMETER**



**COOL HANDLE**



**CHARCOAL PAN**



**HEAT RESISTANT POWDER**

Figure 3.1: Key components of the DNKMOR Portable Charcoal Grill.

## 4. SETUP AND ASSEMBLY

---

The DNKMOR Portable Charcoal Grill requires basic assembly. Please follow these steps carefully. Basic tools (not included) such as a screwdriver and wrench may be required.

1. Unpack all components and verify against the "Package Contents" list.
2. Attach the four legs to the main grill body using the provided hardware. Ensure they are securely fastened for stability.
3. Install the wooden handle onto the lid of the grill using the designated screws.
4. Place the charcoal pan inside the grill body, ensuring it sits correctly at the bottom.
5. Position the cooking grid above the charcoal pan.
6. Ensure the chimney/ventilation system on the lid is securely attached and functional.
7. Before first use, it is recommended to season the grill. This involves burning a small amount of charcoal for about 30-60 minutes to burn off any manufacturing residues and create a protective layer.



Figure 4.1: Assembled DNKMOR Portable Charcoal Grill.

## 5. OPERATING INSTRUCTIONS

### 5.1 Lighting the Charcoal

1. Open the grill lid and ensure the charcoal pan is in place.
2. Arrange charcoal briquettes or lump charcoal on the charcoal pan. Do not overfill.
3. Apply charcoal starter fluid evenly over the charcoal. Allow it to soak for a few minutes.
4. Carefully light the charcoal using a long match or lighter.
5. Allow the charcoal to burn until it is covered with a light gray ash (approximately 15-20 minutes).

### 5.2 Temperature Control

The grill features a built-in thermometer on the lid and an adjustable chimney system for temperature control.

- **Thermometer:** Monitor the internal temperature of the grill using the integrated thermometer.
- **Chimney Vent:** Adjust the opening of the chimney vent on the lid to control airflow. More open means higher temperature, less open means lower temperature.
- For slow cooking or smoking, keep the vent mostly closed. For searing, open it fully.



Figure 5.1: Grilling various foods on the cooking grid.



Figure 5.2: Grill capacity for larger items like a whole chicken.

### 5.3 Cooking

Once the charcoal is ready and the desired temperature is reached, place your food on the cooking grid. The grill offers approximately 110 square inches of cooking space, suitable for 4-6 burgers or a variety of other items. The lid can be closed to retain heat and smoke for more even cooking and enhanced flavor, or kept open for direct grilling.

## 6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will extend the life of your grill and ensure optimal performance.

- **After Each Use:**
  - Allow the grill to cool completely.
  - Remove the cooking grid and charcoal pan.

- Dispose of cooled ashes safely.
- Clean the cooking grid with a grill brush. For stubborn residue, wash with warm soapy water.
- Wipe down the interior and exterior of the grill body with a damp cloth.

- **Periodic Maintenance:**

- Inspect all nuts and bolts periodically and tighten if necessary.
- Store the grill in a dry, covered area when not in use to prevent rust, especially if exposed to moisture. The lid locks tightly for easy transport and storage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Grill not heating up sufficiently.	Insufficient charcoal; vents are closed; charcoal not fully lit.	Add more charcoal; open chimney vent fully; ensure charcoal is fully ashed over.
Excessive smoke.	Too much fat dripping onto coals; unseasoned grill.	Trim excess fat from meat; ensure grill is properly seasoned before first use.
Food cooking unevenly.	Uneven charcoal distribution; grill not level.	Distribute charcoal evenly; ensure grill is on a flat, stable surface.

## 8. SPECIFICATIONS

<b>Feature</b>	<b>Detail</b>
Model Name	Portable Charcoal Grill
Model Number	A-01
Brand	DNKMOR
Color	Round Black
Material	Alloy Steel, Wood (handle)
Product Dimensions (L x W x H)	14.6" (L) x 11.8" (W) x 16.5" (H) (Overall) / 10.7"D x 14"W x 17"H (Product)
Cooking Surface Area	Approx. 110 Square Inches
Item Weight	7.9 Pounds
Fuel Type	Charcoal
Heat Resistant Temperature	400°C
Thermometer	Integrated, $\Phi$ 1.96"
Assembly Required	Yes

# PROTABLE TABLETOP GRILL




Figure 8.1: Product Dimensions.

# CAN PLACED IN THE TRUNK OF THE CARS



Figure 8.2: Compact size for portability.

## 9. WARRANTY AND SUPPORT

For warranty information or customer support, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific details regarding warranty coverage and contact methods.

If you have any problems or questions, feel free to contact our after-service team. We aim to reply within 12 hours and resolve your problems.