

[Manuals.plus](#) /

› [XTREME](#) /

› Xtreme Multicolor LED Gaming Speakers User Manual

XTREME XCA2-1016-BLK

Xtreme Multicolor LED Gaming Speakers

USER MANUAL

Introduction

Thank you for choosing the Xtreme Multicolor LED Gaming Speakers. These speakers are designed to enhance your audio experience for desktop and laptop computers, featuring dynamic LED lighting and convenient volume control. This manual provides essential information for setting up, operating, and maintaining your new speakers.



Image: Front view of the Xtreme Multicolor LED Gaming Speakers product packaging, showcasing the speakers with their vibrant LED lights, and indicating features like RGB, 3.5mm AUX, and USB connectivity.

What's in the Box

Please check the package contents to ensure all items are present:

- 2 x Xtreme Multicolor LED Gaming Speakers
- 1 x USB Power/Line-In Aux Cable
- 1 x User Manual (this document)



Image: The two Xtreme Multicolor LED Gaming Speakers displayed alongside their retail packaging, illustrating the product and its box.

Setup

Follow these steps to connect your Xtreme Multicolor LED Gaming Speakers to your computer:

1. **Position the Speakers:** Place the two speakers on either side of your desktop or laptop computer for optimal stereo sound.
2. **Connect the USB Power Cable:** Insert the USB connector of the included USB Power/Line-In Aux Cable into an available USB port on your computer or a USB wall adapter (not included). This provides power to the speakers and activates the LED lights.
3. **Connect the Audio Cable:** Insert the 3.5mm audio jack (Aux Cable) into the headphone or audio output port of your computer.
4. **Verify Connection:** Once both cables are connected, the speakers should power on, and the LED lights will begin to cycle through colors.



Image: The two Xtreme Multicolor LED Gaming Speakers connected by their integrated cables, showing the USB and 3.5mm audio jacks, indicating they are USB powered.

Operating Instructions

These speakers are designed for simple plug-and-play operation. Here are the key functions:

- **Volume Control:** Adjust the audio output level using the inline volume control switch located on the speaker cable. Slide the switch to increase or decrease the volume to your desired level.



Image: A close-up view of the inline volume control switch on the speaker cable, featuring the Xtreme logo.

- **LED Lighting:** The speakers feature unique LED lights that automatically cycle through a series of rainbow colors when powered on. This provides an ambient lighting effect for your gaming or computing setup.



Image: A banner showing the Xtreme speakers with their LED lights displaying various colors, accompanied by text indicating "LED Color Changing Lights Cycle Through Colors" and an RGB icon.

- **Usage Scenarios:** These speakers are ideal for various audio needs, including:
 - **Movies:** Enjoy clear audio for films and videos.




Image: An overhead view of a person watching a movie on a computer, with a bowl of popcorn, illustrating the use of speakers for movies.

- **Music:** Listen to your favorite music with enhanced sound.




Image: A group of people in a dimly lit setting, suggesting a party or concert, illustrating the use of speakers for music.

- **Games:** Immerse yourself in gaming with clear audio cues and effects.



Image: Two individuals, one holding a game controller, engaged in playing video games, illustrating the use of speakers for gaming.

Maintenance

To ensure the longevity and optimal performance of your speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Avoid using liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the cables excessively. Always grasp the plug, not the cable, when disconnecting.

Troubleshooting

If you encounter any issues with your speakers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Sound	Cables not fully connected.	Ensure both USB and 3.5mm audio cables are securely plugged in.
	Volume too low on speakers or computer.	Increase volume using the inline control and your computer's volume settings.
	Incorrect audio output selected on computer.	Check your computer's sound settings and select the correct output device.
	Faulty USB port or audio jack.	Try connecting to a different USB port or audio jack.
LED Lights Not Working	USB power not connected or insufficient. Faulty USB port.	Ensure the USB cable is securely connected to a powered USB port. Try a different USB port on your computer or a USB wall adapter.
Distorted Sound	Volume set too high. Poor audio source quality.	Lower the volume on both the speakers and your computer. Test with a different audio source or file.

Specifications

Feature	Detail
Model Name	XCA2-1016-BLK
Speaker Type	Multimedia
Special Feature	USB Port
Recommended Uses For Product	Volume, Volume Control
Compatible Devices	Desktop, Laptop
Controller Type	Button (Inline Volume Control)
Surround Sound Channel Configuration	2.0
Included Components	2 Speakers, USB Power/Line-In Aux Cable, User Manual
Item Weight	8 Ounces (approx. 227 grams)
Is Waterproof	No
Number of Items	1 (set)
Control Method	Touch (referring to volume slider)
Speaker Size	1 Inches (driver)

Feature	Detail
Power Source	Corded Electric (USB Powered)
Audio Driver Type	Dynamic Driver
Connectivity Protocol	USB
UPC	805106225636
Manufacturer	Jem Accessories
Package Dimensions	6.61 x 6.22 x 3.82 inches
Date First Available	July 11, 2022
Brand	XTREME
Speaker Maximum Output Power	10 Watts
Connectivity Technology	USB
Audio Output Mode	Stereo
Mounting Type	Plug Mount, Tabletop

Warranty

The Xtreme Multicolor LED Gaming Speakers come with a**Limited One Year Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. For specific details regarding the warranty policy, refer to the documentation included with your product or contact customer support. Standard return policy allows for refund/replacement within 30 days of purchase, subject to seller's terms.

Support

For further assistance, technical support, or warranty inquiries, please visit the official Xtreme website or contact their customer service department. Refer to the product packaging or the brand's online presence for the most current contact information.

You can also visit the [XTREME Store on Amazon](#) for more product information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question