

[Manuals.plus](#) /

› [COWSAR](#) /

› COWSAR Ice Maker Countertop User Manual

COWSAR Z5812H

COWSAR Ice Maker Countertop User Manual

Model: Z5812H

INTRODUCTION

Thank you for choosing the COWSAR Portable Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your ice machine. Please read it thoroughly before first use and keep it for future reference.



The COWSAR Ice Maker Countertop, shown here with an ice scoop and a refreshing iced drink, highlights its compact design and readiness for use. This appliance is designed for convenience, providing fresh ice quickly for various occasions.

SAFETY INSTRUCTIONS

- Ensure the ice maker is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Use only potable water in the water reservoir.
- Unplug the ice maker before cleaning or when not in use for extended periods.
- Keep children away from the appliance during operation.
- Do not operate the appliance with a damaged cord or plug.

SETUP AND FIRST USE

1. Unpacking

Carefully remove all packaging materials and inspect the ice maker for any damage. Ensure all accessories, including the ice basket and scoop, are present.

2. Placement

Place the ice maker on a flat, stable surface. Allow at least 15 cm (6 inches) of space around the unit for proper ventilation. Avoid placing it near heat-generating appliances or in direct sunlight.



The COWSAR Ice Maker's portable design makes it suitable for various settings, including outdoor gatherings. Its compact size allows for easy placement on countertops or tables, providing fresh ice wherever needed.

3. Initial Cleaning

Before first use, clean the interior of the ice maker. Wipe the water reservoir and ice basket with a soft cloth and warm water. Run a self-cleaning cycle as described in the Maintenance section.

4. Filling the Water Reservoir

Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

OPERATING INSTRUCTIONS

1. Power On/Off

Plug the ice maker into a grounded electrical outlet. Press the **ON/OFF** button on the control panel to turn the unit on. The **POWER** indicator light will illuminate.

Simple Operation Panel

Easy to make ice



The control panel of the COWSAR Ice Maker features intuitive buttons for easy operation. Indicator lights for "ADD WATER", "ICE FULL", and "POWER" provide clear status updates, simplifying the ice-making process.

2. Ice Making Cycle

Once powered on, the ice maker will automatically begin the ice-making process. The first batch of ice cubes will typically be ready in approximately 6 minutes. The machine produces 9 bullet-shaped ice cubes per cycle.

Effective Ice Making

Let the coolness come faster



Ready in 6 Mins



26.5 lbs/24h



Powerful Compressor



This diagram illustrates the efficient ice-making capability of the COWSAR Ice Maker, highlighting its ability to produce ice rapidly (ready in 6 minutes) and its daily capacity (26.5 lbs/24h) thanks to a powerful compressor.

Bullet Shaped Ice Cubes

Bullet ice melts more slowly and does not dilute the taste of your drink



The COWSAR Ice Maker produces distinctive bullet-shaped ice cubes. This design is noted for melting more slowly than traditional ice, which helps to prevent drinks from becoming diluted too quickly.

3. Indicator Lights

- **ADD WATER:** This light illuminates when the water reservoir is low and needs refilling. The ice maker will pause operation until water is added.
- **ICE FULL:** This light indicates that the ice basket is full. The ice maker will stop producing ice until some ice is removed.
- **POWER:** This light indicates that the unit is powered on and operating.

4. Low Noise Operation

The COWSAR ice maker is designed to operate quietly, with a noise level below 42 decibels, ensuring it does not disturb your environment.



The COWSAR Ice Maker is engineered for low noise operation, maintaining a quiet environment. This image shows the ice maker in a home setting, emphasizing its unobtrusive presence during use.

MAINTENANCE

1. Self-Cleaning Function

The ice maker features a convenient self-cleaning function. To activate, hold the **ON/OFF** button for 5 seconds. The machine will perform a deep cleaning cycle, helping to prevent limescale buildup and ensure fresh ice.

Convenient Self-Cleaning

Clear limescale and enjoy fresh ice



This illustration demonstrates the self-cleaning function of the COWSAR Ice Maker. Water circulates through the system to clear limescale and maintain hygiene, ensuring the production of fresh ice.

2. Regular Cleaning

- **Exterior:** Wipe the exterior with a soft, damp cloth.

- **Ice Basket and Scoop:** Wash with mild detergent and warm water, then rinse thoroughly.
- **Water Reservoir:** Periodically drain any remaining water and wipe the interior with a clean cloth. For thorough cleaning, a mixture of water and vinegar can be used, followed by rinsing.

3. Storage

If the ice maker will not be used for an extended period, drain all water from the reservoir, clean the unit thoroughly, and store it in a dry, well-ventilated area.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	Water reservoir is empty. Ice basket is full. Ambient temperature is too high. Machine is not plugged in or powered on.	Fill water reservoir (ADD WATER light on). Remove ice from basket (ICE FULL light on). Move unit to a cooler environment. Ensure unit is plugged in and ON/OFF button is pressed.
Ice cubes are small or cloudy.	Water temperature is too high. Poor water quality.	Use colder water. Use filtered or distilled water.
Machine is noisy.	Normal operation sounds (compressor, water pump). Unit not level.	This is normal. Ensure unit is on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Brand	COWSAR
Model Name	Máquina de hielo (Z5812H)
Product Dimensions	28.4D x 29.7W x 21.8H Centimetres (approx. 11.2D x 11.7W x 8.6H inches)
Weight	6.44 kg (approx. 14.2 lbs)
Ice Production Capacity	26.5 lbs / 24 hours
Ice Making Speed	9 bullet ice cubes in 6 minutes
Voltage	115 Volts
Wattage	120 watts
Refrigerant	R600a
Noise Level	Less than 42 dB

WARRANTY AND SUPPORT

For product support, warranty claims, or any inquiries, please contact COWSAR customer service. Refer to the contact information provided with your product packaging or visit the official COWSAR website for assistance.

Please note that the return policy through Amazon is typically 30 days from the date of purchase. For specific warranty details beyond this period, direct contact with the manufacturer is recommended.

© 2025 COWSAR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question