

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Amazon Basics](#) /
- › [Amazon Basics Mesh Desk Chair FG-50854M User Manual](#)

## Amazon Basics FG-50854M

# Amazon Basics Mesh Desk Chair FG-50854M User Manual

Model: FG-50854M

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Amazon Basics Mesh Desk Chair, Model FG-50854M. Please read this manual thoroughly before use to ensure proper function and safety.



*Figure 1: The Amazon Basics Mesh Desk Chair (Model FG-50854M) in a typical office environment. This chair features a black mesh backrest, a wide padded seat, and adjustable armrests, designed for comfort and support.*

The Amazon Basics Mesh Desk Chair is designed for comfort and durability, featuring a breathable mesh backrest, a wide seat with thick, high-density foam cushioning, and integrated lumbar support. It is built to accommodate a high load capacity and offers various adjustments for personalized comfort.

## **SAFETY INFORMATION**

---

**WARNING:** To ensure safe use, do not exceed the maximum load capacity of 181.4 kg (400 pounds). Verify that the chair is properly assembled and adjusted before each use. Improper use may result in injury.

- Always follow assembly instructions carefully.
- Do not stand on the chair.
- Do not use the chair if any parts are damaged or missing.
- Keep children away from the chair during assembly. Small parts may be a choking hazard.

- Use the chair only on a level surface.

## COMPONENTS AND ASSEMBLY

Before assembly, ensure all components are present and undamaged. Refer to the diagram below for identification of key parts and adjustable features.



Figure 2: Chair Components and Adjustable Features. This image illustrates the main parts of the chair, including the mesh backrest, padded seat, armrests, pneumatic height adjustment lever, and 360-degree swivel base with caster wheels.

### Assembly Steps

Assembly typically involves attaching the base to the pneumatic cylinder, then the seat and backrest. Specific tools may be included or required. Follow the detailed instructions provided in the packaging for your specific model.

1. Unpack all components and verify against the components list.
2. Insert the caster wheels into the base.
3. Place the pneumatic cylinder into the center hole of the base.
4. Attach the seat mechanism to the underside of the seat cushion.
5. Mount the backrest to the seat mechanism.
6. Place the assembled seat and backrest onto the pneumatic cylinder.
7. Attach the armrests to the seat.
8. Test all adjustments to ensure proper function.

## OPERATING INSTRUCTIONS

### Height Adjustment

To adjust the seat height (range: 47-55 cm):

- To raise the seat: Lift the height adjustment lever while taking your weight off the seat. Release the lever at the desired height.
- To lower the seat: Lift the height adjustment lever while seated. Release the lever at the desired height.

### Armrest Adjustment

The armrests are adjustable in height (range: 65-72 cm from the floor). Locate the adjustment buttons or levers on the armrests and press them to move the armrests up or down. Release to lock in place.

### Lumbar Support Adjustment

The chair features an ergonomic design with adjustable lumbar support. Locate the knob on the back of the chair's backrest. Rotate the knob to increase or decrease the intensity of the lumbar support to suit your preference.

### Swivel and Mobility

The chair is equipped with a 360-degree swivel function and five caster wheels for easy mobility. Ensure the wheels are clean and free of debris for smooth movement.

## MAINTENANCE

- **Cleaning:** Wipe the chair with a soft, damp cloth. For mesh and fabric parts, use a mild soap solution if necessary, then wipe with a clean, damp cloth and allow to air dry. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Casters:** Keep caster wheels free of hair and debris to ensure smooth rolling.
- **Storage:** Store the chair in a dry environment, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height.	Pneumatic cylinder malfunction or lever not engaged.	Ensure the lever is fully engaged. If the issue persists, the pneumatic cylinder may need replacement.
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check and tighten all screws and bolts. Re-verify assembly steps.

Problem	Possible Cause	Solution
Caster wheels do not roll smoothly.	Debris caught in wheels or damaged casters.	Clean any debris from the wheels. Replace damaged casters if necessary.
Squeaking noises.	Loose connections or friction between parts.	Tighten all connections. Apply a small amount of silicone lubricant to moving parts if needed.

SPECIFICATIONS



Figure 3: Chair Dimensions. This diagram provides detailed measurements for the chair's width, depth, and height, including seat dimensions, backrest height, and armrest height.

Feature	Detail
---------	--------

Feature	Detail
Brand	Amazon Basics
Model Number	FG-50854M
Color	Black
Material	Plastic, Metal, Mesh Fabric, High-Density Foam
Overall Dimensions (W x D x H)	Approx. 77.5 cm x 75 cm x 106 cm (Max Height)
Seat Dimensions (W x D)	58 cm x 56 cm
Seat Height Adjustment Range	47 cm - 55 cm
Armrest Height Adjustment Range (from floor)	65 cm - 72 cm
Backrest Height	69 cm (from seat)
Load Capacity	181.4 kg (400 lbs)
Product Weight	18.82 kg
Features	Mesh back, wide padded seat, adjustable lumbar support, adjustable armrests, 360-degree swivel, 5-point caster base.



# 4層構造で 支え快適




Figure 4: Seat Cushion Construction. This diagram illustrates the four layers of the seat cushion: fabric, top foam, low-rebound main foam, and plywood base, highlighting the 8cm thick high-density foam for comfort.

## WARRANTY AND SUPPORT

This Amazon Basics product is covered by a **1-year domestic warranty** in Japan from the date of purchase, provided by Amazon LLC. For warranty claims, technical support, or any inquiries regarding your product, please contact Amazon customer service through your purchase history on Amazon.co.jp.

Please have your purchase details and model number (FG-50854M) ready when contacting support.

