

[Manuals.plus](#) /

› [JYPS](#) /

› JYPS Wireless Cat Ear Headphones for Kids with LED Light, Bluetooth, and Detachable Microphone (Model BT029C)

JYPS BT029C

JYPS Wireless Cat Ear Headphones User Manual

Model: BT029C

Brand: JYPS

INTRODUCTION

Thank you for choosing the JYPS Wireless Cat Ear Headphones. These headphones are designed for children aged 3 and above, combining a fun cat ear design with cool LED lights and gradient colors. They offer both wireless Bluetooth 5.1 and wired 3.5mm auxiliary connectivity, along with a detachable noise-cancelling microphone for various uses such as gaming, remote learning, online chat, and music listening.



Image: A pair of purple JYPS Wireless Cat Ear Headphones, showcasing their design.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x JYPS Cat Ear Bluetooth Headset
- 1 x 3.5mm Aux Cable
- 1 x Type-C Charging Cable
- 1 x User Manual
- 1 x Detachable Microphone

SETUP

1. Charging the Headphones

Before first use, fully charge the headphones. Connect the Type-C charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status.

- Charging Time: Approximately 2.5 hours
- Total Playtime: Up to 15 hours

EXTRA LONG BATTERY LIFE

large-capacity battery
for long standby time



15h

Total duration

1K

1000 Songs

2.5h

Charging time

Image: Visual representation of the headphones' battery life (15 hours total duration) and charging time (2.5 hours).

2. Powering On/Off

To power on, press and hold the Power button until the LED indicator lights up. To power off, press and hold the Power button again until the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "BT029C" from the list of devices.
5. Once paired, the LED indicator will show a steady blue light or flash slowly.

THE NEWEST BLUETOOTH 5.1

ensures stable bluetooth connection
say goodbye to intermittent

5.1



34 FEET

Image: A visual showing the headphones connecting via Bluetooth 5.1 to a smartphone, highlighting a stable connection within 10 meters (34 feet).

4. Connecting the Detachable Microphone

Insert the detachable microphone into the designated port on the left earcup. Ensure it is securely connected for optimal voice pickup during calls or gaming.

OPERATING INSTRUCTIONS

1. Basic Audio Playback and Call Functions

Function	Action
Play/Pause	Press the Multi-function button once.
Volume Up	Short press the '+' button.
Volume Down	Short press the '-' button.
Next Track	Long press the '+' button.
Previous Track	Long press the '-' button.
Answer/End Call	Press the Multi-function button once.
Reject Call	Press and hold the Multi-function button.

2. LED Light Control

The headphones feature LED lights on the cat ears and earcups. Use the dedicated light control button to cycle through modes:

- **Hold:** Turn LED lights On/Off.
- **Press 3 times:** Monochromatic light always on.
- **Press 2 times:** Monochromatic light flashes.
- **Press 4 times:** Automatically switch between 7 colors.




Image: Close-up of the headphone controls, detailing how to operate the LED lights with different button presses.

3. Wired Mode Connection

To use the headphones in wired mode, connect the provided 3.5mm auxiliary cable to the headphone's audio jack and the other end to your device's 3.5mm audio output. This mode is useful when the battery is depleted or for devices without Bluetooth connectivity.



iPad



Phone



Kids Tablet



PC



Kindle Fire



Chrome book

WIDE COMPATIBILITY

standard 3.5mm jack makes it
compatible to most devices

Image: The headphones connected via a 3.5mm jack, illustrating compatibility with iPads, phones, kids' tablets, PCs, Kindle Fire, and Chromebooks.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use harsh chemicals or abrasive materials.

- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage, ideal for travel.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source using the Type-C cable.
Cannot pair via Bluetooth.	Make sure the headphones are in pairing mode (flashing blue/red LED). Ensure Bluetooth is enabled on your device and it's within 10 meters. Try restarting both devices.
No sound in wireless mode.	Check volume levels on both headphones and the connected device. Ensure headphones are successfully paired.
Microphone not working.	Ensure the detachable microphone is fully inserted into its port. Check microphone settings on your connected device.
LED lights are not working.	Press and hold the light control button to turn them on. Ensure the headphones have sufficient battery charge.



Image: Various usage scenarios for the headphones, including gaming, remote schooling, streaming, and online chat, demonstrating their versatility.

SPECIFICATIONS

Feature	Detail
Model Number	BT029C
Brand	JYPS
Connectivity Technology	Wireless (Bluetooth 5.1), Wired (3.5mm Jack)
Bluetooth Range	Up to 10 meters (34 feet)
Impedance	32 Ohms

Feature	Detail
Frequency Range	2.402-2.480 GHz
Ear Placement	On-Ear (Supra-aural)
Form Factor	Over-Ear (Circum-aural)
Control Type	Touch Control, Integrated Controls
Microphone	Detachable Noise-Cancelling Microphone, Integrated Microphone
LED Lights	Cat Ear LED lights with 4 adjustment modes (On/Off, Monochromatic Steady, Monochromatic Flashing, 7-Color Auto-Switch)
Battery Type	1 Lithium-ion battery (included)
Charging Time	Approx. 2.5 hours
Total Playtime	Up to 15 hours
Recommended Age Range	Child
Material (Earcups)	Faux Leather
Water Resistance Level	Not waterproof
Special Features	Foldable design, Cat Ear design, Detachable microphone

WARRANTY AND SUPPORT

JYPS offers a 6-month warranty for these headphones. For any product inquiries, technical support, or warranty claims, please contact our customer service. We provide 24-hour customer service to assist you. For further assistance, please refer to the contact information provided on the product packaging or the official JYPS website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question