Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Roland F107

Roland F107 Digital Piano User Manual

Comprehensive instructions for the setup, operation, and maintenance of your Roland F107 Digital Piano.

1. Introduction

The Roland F107 is a digital piano designed for home use, offering a blend of modern design and advanced musical performance. It features Roland's acclaimed SuperNATURAL Piano technology for authentic sound and an 88-note PHA-4 Standard keyboard for a realistic playing experience. This instrument includes Bluetooth connectivity for integration with mobile devices and the Roland Piano App, enhancing learning and enjoyment.



Image 1.1: The Roland F107 Digital Piano, showcasing its minimalist design and integrated pedal unit.

2. Setup

2.1 Unpacking and Assembly

Carefully unpack all components from the packaging. It is recommended to have two people for assembly due to the weight of the main piano unit. Follow the included assembly guide for detailed steps on attaching the stand, pedal unit, and main piano body.

- Ensure all screws and fasteners are securely tightened.
- When connecting the pedal unit cable, exercise caution as the pins can be delicate. Align the connector correctly before gently pushing it into place.



Image 2.1: Dimensional diagram of the Roland F107 Digital Piano, illustrating its compact footprint.

2.2 Power Connection

1. Connect the supplied AC adapter to the DC IN jack on the rear of the piano.
2. Plug the AC adapter into a standard electrical outlet.

3. Operating Instructions

3.1 Power On/Off

Press the **POWER** button located on the left side of the keyboard to turn the instrument on or off.

3.2 Sound Selection and Volume

The F107 defaults to a grand piano sound upon startup. To select other tones or adjust volume, use the dedicated controls or the Roland Piano App for a more intuitive interface.

3.3 PHA-4 Standard Keyboard

The 88-note PHA-4 Standard keyboard provides a weighted, hammer-action feel, simulating the touch of an acoustic grand piano. This action is designed to respond to subtle nuances in playing dynamics.

3.4 Bluetooth Connectivity

The F107 features Bluetooth for audio streaming and MIDI communication.

- **Bluetooth Audio:** Stream music from your smartphone or tablet through the piano's speakers.
- **Bluetooth MIDI:** Connect to the Roland Piano App or other MIDI music applications for enhanced functionality and learning.



Image 3.1: A user interacting with the Roland Piano App on a tablet while playing the F107.

3.5 Roland Piano App

The dedicated Roland Piano App (available for iOS and Android) provides a graphical interface for controlling F107 features, exploring various tones, accessing lessons, and managing settings. It is highly recommended for unlocking the full potential of the instrument.

3.6 Headphone Jacks and Twin Piano Mode

The F107 includes dual headphone jacks (one 1/4-inch, one 3.5mm) located underneath the piano, allowing two users to practice silently. The Twin Piano mode splits the keyboard into two identical ranges, enabling a student and teacher to play side-by-side.



Image 3.2: Two individuals using headphones while playing the F107, demonstrating the dual headphone jack feature.

4. Maintenance

4.1 Cleaning

Wipe the piano's surface with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid abrasive cleaners, solvents, or waxes, as these can damage the finish.

4.2 Environmental Care

To ensure longevity, keep the F107 away from direct sunlight, extreme temperatures, and high humidity. Avoid placing heavy objects on the keyboard or lid.

5. Troubleshooting

- **No Sound:**
  - Check if the power is on and the volume is turned up.
  - Ensure headphones are not plugged in if you expect sound from the speakers.
  - Verify all cables, especially the power adapter, are securely connected.
- **Keys Not Responding:**
  - If a specific key or keys are not producing sound, ensure no foreign objects are lodged beneath them.
  - For persistent issues with key functionality, professional service may be required.
- **Bluetooth Connection Issues:**
  - Ensure Bluetooth is enabled on both the piano and your mobile device.
  - Try unpairing and re-pairing the devices.
  - Restart both the piano and your mobile device.
- **Pedals Not Working:**
  - Check the pedal unit cable connection to ensure it is fully inserted and not damaged.

6. Specifications

Feature	Detail
Model Name	F107
Brand	Roland
Number of Keys	88
Keyboard Type	PHA-4 Standard Keyboard
Sound Engine	SuperNATURAL Piano
Polyphony	256 notes
Connectivity	Bluetooth, DC Jack, USB-B, USB-A, 3.5mm Jack, 1/4-inch Jack
Supported Software	Roland Piano App
Product Dimensions	57.9 x 26 x 14.6 inches
Item Weight	93.8 pounds
Color	Black



Image 6.1: Comparison of the F107 and RP107 models, highlighting their shared internal features and differing cabinet styles.

7. Warranty and Support

7.1 Warranty Information

Your Roland F107 Digital Piano is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration. Retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, service, or further inquiries, please contact Roland customer support. Visit the official Roland website for contact information and support resources.

Official Roland Website: www.roland.com

© 2025 Roland Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6D4YRBK

More documents and user manuals: **https://manuals.plus/**