

[Manuals.plus](#) /

> [MOFII](#) /

> MOFII Wireless Keyboard and Mouse Combo Instruction Manual

MOFII Sweet

MOFII Wireless Keyboard and Mouse Combo

Model: Sweet (Milk Tea Colorful-B)

Official Instruction Manual

INTRODUCTION

Thank you for choosing the MOFII Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient typing and navigation experience with its retro full-size keyboard and cute wireless mouse. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device.



Image: The MOFII Wireless Keyboard and Mouse Combo, featuring a full-size keyboard with round, colorful keycaps and a matching ergonomic mouse, along with the USB receiver.

SETUP

1. Battery Installation

- The keyboard requires 1 AA battery. Locate the battery compartment on the underside of the keyboard, open it, and insert the battery, ensuring correct polarity (+/-).
- The mouse requires 1 AA battery. Locate the battery compartment on the underside of the mouse, open it, and insert the battery, ensuring correct polarity (+/-).

2. Connecting the USB Receiver

1. Locate the USB receiver, which is typically stored inside the mouse's battery compartment for convenience.
2. Insert the USB-A receiver into an available USB-A port on your computer (PC, desktop, laptop).
3. For devices with only USB-C ports (e.g., some Mac OS systems), a USB-C to USB-A adapter (not included) is required. Plug the USB-A receiver into the adapter, then plug the adapter into your device's USB-C port.

How to connect:




Image: Step-by-step diagram illustrating battery insertion for the mouse and keyboard, and how to plug the USB-A receiver into a computer. It also shows the use of a USB-C adapter for compatible devices.

The keyboard and mouse are plug-and-play, meaning they should automatically connect to your computer once the receiver is inserted. No additional drivers are typically required.



WIDE COMPATIBILITY

2-in-1 USB Receiver



XP/Vista



Windows 7/8



Windows 10



Computer/PC



Laptop

Image: Icons indicating compatibility with Windows XP/Vista, Windows 7/8, Windows 10, Computer/PC, and Laptop, highlighting the 2-in-1 USB receiver.

OPERATING INSTRUCTIONS

Wireless Connection

The MOFii combo utilizes a reliable 2.4GHz wireless connection, providing a stable transmission range of up to 10 meters (33 feet) with minimal delays or dropouts. Ensure the receiver is within this range for optimal performance.



2.4G Wireless Tech

10m/33ft Stable Connection

Image: A laptop, keyboard, and mouse with wireless signals indicating a 10m/33ft stable connection range.

Ergonomic Design

The keyboard features an ergonomic design with folding holders and anti-slide pads on the underside. These allow you to adjust the keyboard to an optimum slope, helping to prevent wrist discomfort during long typing sessions. The contoured shape of the mouse also provides comfortable use for extended periods.

Ergonomic Design

Release wrist pressure and work effectively




Image: Close-up of the keyboard's underside showing foldable stands and silicone non-slip pads, designed for ergonomic comfort.

Multimedia Hotkeys

The keyboard includes 13 multimedia hotkeys for quick access to various functions, enhancing both work and entertainment. These keys provide instant access to the internet, email, play/pause controls, and volume adjustments.

With 13 Hotkey Function

work and entertainment are both correct




Image: An illustration of the keyboard with F1-F12 keys highlighted, indicating their multimedia hotkey functions such as media control, volume, and internet access.

Auto-Sleep Feature

To conserve battery life, both the keyboard and mouse are equipped with an intelligent auto-sleep feature. If not used for 8-10 minutes, the devices will automatically enter sleep mode. To wake them up, simply press any key on the keyboard or move/click the mouse.




Image: A dimly lit desk scene with the MOFII keyboard and mouse, illustrating the auto-sleep feature with a clock icon.

MAINTENANCE

Cleaning

The keyboard features detachable keycaps, making it easy to clean dust and debris that may accumulate underneath. A cleaning brush is included to assist with deep cleaning. Gently pull the keycaps off, clean the keyboard base and keycaps, then reattach them.



Detachable Keycaps

Include a brush to deep clean for the keyboard

Image: Detached keycaps from the MOFII keyboard, with a cleaning brush nearby, demonstrating the ease of cleaning.

Battery Replacement

When the devices stop responding or show signs of low power, it's time to replace the batteries. Refer to the "Battery Installation" section under Setup for instructions on how to replace the AA batteries in both the keyboard and mouse. Battery life may vary based on usage and computing conditions, but typically lasts up to 18 months for both devices.

TROUBLESHOOTING

- **No Connection/Lag:**
 - Ensure the USB receiver is securely plugged into a working USB port.
 - Check if the batteries in both the keyboard and mouse are correctly installed and have sufficient charge. Replace if necessary.
 - Move the keyboard and mouse closer to the USB receiver to ensure they are within the 10-meter (33 ft) range.
 - Try plugging the USB receiver into a different USB port on your computer.
 - Restart your computer.

- **Keys Not Responding:**
 - Check battery level.
 - Ensure the keyboard is not in auto-sleep mode (press any key to wake).
 - Clean under the keycaps if specific keys are sticking or not registering.
- **Mouse Not Moving/Clicking:**
 - Check battery level.
 - Ensure the mouse is not in auto-sleep mode (move or click to wake).
 - Ensure the optical sensor on the bottom of the mouse is clean and unobstructed.
 - Try using the mouse on a different surface.

SPECIFICATIONS

Feature	Detail
Brand	MOFII
Model Number	Sweet
Color	Milk Tea Colorful-B
Connectivity Technology	2.4GHz Wireless (USB-A Receiver)
Compatible Devices	Laptop, Personal Computer (Windows XP/7/8/10)
Keyboard Battery	1 AA battery (not included)
Mouse Battery	1 AA battery (not included)
Item Weight	1.96 pounds
Package Dimensions	17.72 x 5.55 x 2.99 inches
Special Feature	Ergonomic, Detachable Keycaps, Auto-Sleep

Full-Size Keyboard Combo




Image: A diagram illustrating the dimensions of the full-size keyboard (17.4 inches long) and mouse (4 inches long, 1.7 inches high), along with their respective heights.

WARRANTY AND SUPPORT

MOFII offers a 30-day money-back guarantee and a 12-month worry-free warranty for this product. For any support inquiries, technical assistance, or warranty claims, please contact MOFII customer service through the retailer where you purchased the product or visit the official MOFII website for contact information.

For more information and product updates, you may visit the [MOFII Store on Amazon](#).

© 2025 MOFII. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question