Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOFII B0B6G3H6ZD

MOFII Wireless Keyboard and Mouse Combo User Manual

Model: B0B6G3H6ZD

Brand: MOFII

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your MOFII Wireless Keyboard and Mouse Combo. Please read this manual carefully before using the product to ensure optimal performance and longevity.

2. Safety Information

- Keep the device away from water, moisture, and extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel for assistance.
- Dispose of batteries according to local regulations. Do not mix old and new batteries.

3. Package Contents

Verify that all items are present in the package:

- 1 x MOFII Wireless Keyboard
- 1 x MOFII Wireless Mouse
- 1 x USB Receiver (stored in the mouse battery compartment)
- 1 x Cleaning Brush
- User Manual (this document)

4. Setup Instructions

4.1. Battery Installation

The keyboard and mouse each require one AA battery (not included).

1. Locate the battery compartment on the underside of the keyboard and mouse.
2. Open the battery cover.
3. Insert one AA battery into each device, ensuring correct polarity (+/-).
4. Close the battery covers securely.

4.2. USB Receiver Connection

The wireless combo uses a single USB receiver for both devices.

1. Locate the USB receiver, typically stored in the mouse battery compartment.
2. Plug the USB receiver into an available USB port on your computer (Laptop, PC, Desktop, Chromebook, Notebook, Smart TV).
3. The system will automatically detect and install the necessary drivers. This is a plug-and-play device, requiring no manual driver installation.



Figure 1: USB receiver connecting to a laptop, illustrating plug and play functionality for the MOFII Wireless Keyboard and Mouse Combo.

4.3. Power On/Off

Each device has an on/off switch to conserve battery life.

- **Mouse:** Locate the power switch on the underside of the mouse. Slide it to the 'ON' position to activate.
- **Keyboard:** Locate the power switch on the underside of the keyboard. Slide it to the 'ON' position to activate.

5. Operating Instructions

5.1. Keyboard Features

- **Round Keycaps:** The keyboard features 104 round keycaps designed for comfortable typing and a retro aesthetic.
- **Multimedia Hotkeys:** The top row (F1-F12) includes dedicated multimedia functions for quick access to media controls, volume adjustment, and other common tasks.
- **Ergonomic Design:** The keyboard is designed with a slight tilt to reduce wrist pressure during extended use.



Figure 2: Ergonomic design of the MOFII keyboard with foldable stands for adjustable typing angle.




Figure 3: The keyboard features 13 hotkey functions for quick access to various controls.

5.2. Mouse Features

- **Precision Control:** The optical mouse provides accurate and smooth cursor movement.
- **Ambidextrous Design:** The symmetrical design allows for comfortable use by both left and right-handed users.

5.3. Power Saving Function

Both the keyboard and mouse are equipped with an intelligent auto-sleep function to extend battery life.

- If inactive for 5 minutes, the devices will automatically enter sleep mode.
- To wake up the device, simply press any key on the keyboard or move/click the mouse.



Figure 4: The intelligent auto-sleep feature helps conserve battery life when the devices are not in use.

6. Maintenance

6.1. Cleaning

To maintain hygiene and performance, regular cleaning is recommended.

- **Detachable Keycaps:** The round keycaps can be removed for thorough cleaning. Use the provided cleaning brush to remove dust and debris from between the keys.
- Wipe the surface of the keyboard and mouse with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.




Figure 5: Detachable keycaps allow for easy and thorough cleaning of the keyboard.

6.2. Battery Replacement

When the devices show signs of low power (e.g., erratic behavior, non-responsiveness), replace the AA batteries.

1. Turn off the device using its power switch.
2. Open the battery compartment.
3. Remove the old battery and insert a new AA battery, observing correct polarity.
4. Close the battery cover and turn the device back on.

7. Troubleshooting

If you encounter issues, try the following solutions:

- **No Connection/Unresponsive Devices:**
  - Ensure both the keyboard and mouse are turned on.

- Check if the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- Replace the batteries in both the keyboard and mouse.
- Restart your computer.

- **Mouse Lag/Erratic Movement:**
  - Ensure the mouse is used on a suitable surface (not highly reflective or transparent).
  - Check battery levels and replace if low.
  - Ensure there are no obstructions or strong electromagnetic interference between the mouse and the USB receiver. The effective range is up to 35 feet.
- **Keys Not Registering/Sticking:**
  - Clean the keycaps and the area beneath them using the provided brush or by removing the keycaps.
  - Check battery levels.

8. Specifications

Brand	MOFII
Model	B0B6G3H6ZD
Connectivity Technology	2.4G Wireless (USB Receiver)
Keyboard Layout	104-key Full Size, US QWERTY
Keycap Type	Round, Detachable
Special Features	Ergonomic Design, Multimedia Hotkeys, Intelligent Auto-Sleep
Power Source	1 x AA Battery (Keyboard), 1 x AA Battery (Mouse)
Compatible Devices	Laptop, PC, Desktop, Chromebook, Notebook, Smart TV
Operating Systems	Windows 98/Me/2000/XP/Vista/7/8/10/11 or latest
Wireless Range	Up to 35 ft (10m)
Item Weight	1.96 pounds
Package Dimensions	17.8 x 5.67 x 3.03 inches

9. Warranty and Support

For warranty information and customer support, please refer to the product packaging or visit the official MOFII website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6G3H6ZD

More documents and user manuals: **https://manuals.plus/**