

BILLCONCH B0B6HYSFBF

BILLCONCH Biometric Gun Safe

Instruction Manual
Model: B0B6HYSFBF

INTRODUCTION

The BILLCONCH Biometric Gun Safe provides secure and rapid access to your firearms and valuables. Designed with advanced biometric technology, digital PIN entry, and traditional key access, this safe offers multiple layers of security and convenience. Its portable size allows for versatile placement in various environments, from nightstands to vehicles.

SAFETY INFORMATION

WARNING: Always store firearms securely and out of reach of children. This safe is designed to deter unauthorized access but is not a substitute for responsible firearm handling and storage practices.

- Ensure the safe is securely mounted or placed to prevent unauthorized removal.
- Never store loaded firearms unless absolutely necessary and always with extreme caution.
- Keep backup keys in a secure location away from the safe and out of reach of children.
- Regularly check battery levels to ensure continuous functionality.

PACKAGE CONTENTS

Upon unboxing your BILLCONCH Biometric Gun Safe, please verify that all components are present:

- BILLCONCH Biometric Gun Safe Unit
- 2 x Backup Keys
- USB Charging Cable

- Mounting Hardware (Screws and Screwdriver)
- Lithium Ion Battery (pre-installed or separate)
- Instruction Manual



Figure 1: The BILLCONCH Biometric Gun Safe with its internal components, including the metal latch bar, padded foam, setting area, rechargeable battery, LED light, OK button, USB charging cable, and key slot. Dimensions are also shown.

SETUP

1. Battery Installation

The safe is powered by a rechargeable lithium-ion battery. Ensure the battery is properly installed before initial use.

1. Locate the battery compartment inside the safe.

2. Insert the provided lithium-ion battery, ensuring the flat side is against the spring.
3. Close the battery compartment securely.

Video 1: A detailed walkthrough of the BILLCONCH Biometric Gun Safe, including unboxing, battery installation, and programming of various access methods. This video demonstrates how to install the battery and set up the safe's security features.

2. Programming Fingerprints

The biometric scanner allows for quick and secure access. You can register multiple fingerprints for convenient use.

1. Open the safe using the backup key.
2. Locate the 'Set Fingerprint' button inside the safe.
3. Press and hold the 'Set Fingerprint' button until the indicator light turns blue.
4. Place your finger on the fingerprint scanner. Lift and repeat 5-6 times until the indicator light turns green and beeps three times, confirming successful registration.
5. Repeat for additional fingerprints as desired.



Figure 2: The high-resolution fingerprint scanner provides quick access to your handgun. It features learnable fingerprint technology, a low false acceptance rate (less than 1/10,000), and unlocks within 0.1 seconds.

3. Setting Digital PIN

For an alternative access method, you can set a digital PIN code.

1. Open the safe using the backup key or a registered fingerprint.
2. Locate the 'Set PWD' (Set Password) button inside the safe.
3. Press and hold the 'Set PWD' button until the indicator light turns blue.
4. Enter your desired 6-digit PIN using the keypad (1-5, OK). Press 'OK' after entering the PIN.
5. Re-enter the same 6-digit PIN and press 'OK' to confirm. The indicator light will turn green and beep three times upon successful registration.



Figure 3: The safe offers three primary unlock methods: Fingerprint Unlock, Keyboard Unlock (Digital PIN), and Key Unlock, providing versatile access options.

4. Mounting the Safe (Optional)

For added security, the safe can be mounted to a flat surface.

- Identify a suitable location for mounting (e.g., floor, wall, inside a cabinet).
- Use the provided mounting hardware and pre-drilled holes on the bottom of the safe to secure it.



Figure 4: The safe features durable metal material to prevent scratches and soft foam padding inside to protect valuables.

OPERATING THE SAFE

1. Unlocking with Fingerprint

For the fastest access, use your registered fingerprint:

1. Place a registered finger firmly on the fingerprint scanner.
2. The safe will unlock automatically if the fingerprint is recognized.

Video 2: This video demonstrates the super-fast opening mechanism of the safe using the biometric fingerprint scanner, highlighting its security options and the backup USB power mode.

2. Unlocking with Digital PIN

To unlock using the digital PIN:

1. Press any key on the keypad to activate it.
2. Enter your 6-digit PIN code.
3. Press 'OK' to confirm. The safe will unlock if the PIN is correct.

3. Unlocking with Key

In case of battery depletion or forgotten codes, use the backup key:

1. Insert the backup key into the keyhole on the front of the safe.
2. Turn the key clockwise to unlock the safe.

4. Internal LED Light

The safe features an internal LED light that illuminates when the safe is opened, allowing for clear visibility of contents, especially in low-light conditions.



Figure 5: The BILLCONCH Biometric Gun Safe open, showcasing the internal LED light that illuminates the contents, including space for two standard-sized pistols.

MAINTENANCE

1. Charging the Battery

The safe's battery can be recharged via the USB port. A low battery reminder will alert you when charging is needed.

1. Connect the provided USB charging cable to the USB port on the front of the safe.
2. Connect the other end of the cable to a standard USB power source (e.g., wall adapter, computer).
3. The indicator light will show charging status.

2. Cleaning

To maintain the safe's appearance and functionality:

- Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners.
- Keep the fingerprint scanner clean and free of debris for optimal performance.

3. Storage

The safe features a soft foam interior to protect your valuables from scratches and damage.



Figure 6: The safe's design includes thoughtful details such as durable metal construction to prevent scratches and soft foam lining to protect stored items.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fingerprint not recognized	Finger not placed correctly; dirty scanner; unregistered fingerprint.	Ensure full finger contact; clean scanner; re-register fingerprint.
Digital PIN not working	Incorrect PIN entered; keypad not activated.	Re-enter correct PIN; press any key to activate keypad before entering PIN.
Safe does not open	Battery is low or depleted.	Use backup key; connect USB charging cable for temporary power.
Internal light not working	Battery is low or depleted.	Charge the battery.

SPECIFICATIONS

Feature	Detail
Brand	BILLCONCH
Product Dimensions	8.6"D x 10"W x 2.75"H
Lock Type	Biometric, Electronic Combination Lock
Color	Black
Capacity	241.23 Cubic Inches (fits 2 standard pistols)
Material	Foam, Carbon Steel, Spring Steel
Special Feature	Portable, Internal LED Light
Mounting Type	Freestanding, Tabletop
Control Type	Key Control, Fingerprint, Digital PIN
Item Weight	6.46 Pounds
Battery Type	1 Lithium Ion battery (included)

WARRANTY AND SUPPORT

BILLCONCH is committed to providing you with greater peace of mind and a safer gun safe. We adhere to the principle of user first!

- **Worry-free One Year Warranty:** Your purchase is covered by a one-year warranty.
- **Reliable 24-hour Response Service:** We offer a reliable 24-hour response service for any inquiries.
- **Customer Service:** If you have any concerns or advice, please feel free to contact us directly. We'll offer friendly customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I connect my BILLCONCH Biometric Gun Safe (B0B6HYSFBF) to the app?

Based on the instruction manual for the BILLCONCH Biometric Gun Safe (Model B0B6HYSFBF), this specific model primarily supports three access methods: Fingerprint, Digital PIN, and Physical Key. The provided manual text does not contain...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0B6HYSFBF>

More documents and user manuals: <https://manuals.plus/>