

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kavey](#) /

› [Kavey 2.6 Cub Home Safe \(Model KS-56\) Instruction Manual](#)

## Kavey KS-56

# Kavey 2.6 Cub Home Safe (Model KS-56) Instruction Manual

Your guide to safe and secure operation.

## 1. INTRODUCTION

Thank you for choosing the Kavey 2.6 Cub Home Safe, Model KS-56. This instruction manual provides essential information for the proper installation, operation, and maintenance of your safe. Please read this manual thoroughly before using the product and retain it for future reference. Following these instructions will ensure optimal performance and security for your valuables.

## 2. IMPORTANT SAFETY INFORMATION

- Do not store emergency keys inside the safe. Keep them in a secure, separate location.
- Ensure the safe is securely mounted to a wall or floor to prevent unauthorized removal.
- Keep the safe door closed and locked when not in use to maintain security.
- Replace batteries promptly when the low battery indicator appears to avoid being locked out.
- Avoid exposing the safe to extreme temperatures or humidity.

## 3. PRODUCT OVERVIEW

The Kavey 2.6 Cub Home Safe (Model KS-56) is designed to protect your valuables with an electronic combination lock and a robust alloy steel construction. It features an alarm system for enhanced security and a versatile interior with a removable shelf and a hidden compartment.



Figure 3.1: Front view of the Kavey 2.6 Cub Home Safe, featuring a black finish and an illuminated electronic keypad with a circular dial below it.

## 4. SETUP INSTRUCTIONS

### 4.1. First Opening and Battery Installation

Before initial use, the safe must be opened using the emergency key to install the batteries.

1. Locate the emergency keyhole, usually concealed behind a cover on the keypad panel.
2. Insert the emergency key and turn it to unlock the safe.
3. Open the safe door. Inside the door, locate the battery compartment.
4. Insert 4\*AA batteries, ensuring correct polarity.
5. Close the battery compartment.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the initial opening of the Kavey KS-56 safe using the emergency key, followed by the correct procedure for installing 4\*AA batteries into the internal battery compartment.

## 4.2. Setting Your User Code

After battery installation, set your personal user code.

1. With the safe door open, press the red 'Setting Button' located on the inside of the door (refer to the video for exact location).
2. On the keypad, enter your desired new code (3-8 digits).
3. Confirm the code by pressing the '#' button.
4. Repeat steps 2 and 3 to set a second code if desired.

Your browser does not support the video tag.

Video 4.2: This video illustrates the process of setting the primary and secondary user codes for the Kavey KS-56 safe. It shows pressing the internal setting button and entering the new code on the keypad.

## 4.3. Mounting the Safe

For maximum security, it is recommended to mount the safe to a floor or wall.

- Choose a suitable location, preferably a discreet one.
- Use the pre-drilled holes at the back or bottom of the safe as templates.
- Drill pilot holes into the mounting surface.
- Secure the safe using the provided mounting hardware (bolts, washers).

# 5. OPERATING INSTRUCTIONS

## 5.1. Opening the Safe with Your Code

1. Enter your 3-8 digit user code on the keypad.
2. Press the '#' button to confirm.
3. Within 5 seconds, turn the knob clockwise and pull the door open.

## 5.2. Alarm System

The safe is equipped with a dual alarm system for enhanced security.

- **Vibration Alarm:** Press '9' on the keypad to activate the vibration alarm mode. If the safe is shaken or hit hard, it will trigger an alarm.
- **Incorrect Code Alarm:** Entering an incorrect code three consecutive times will activate the alarm.
- To stop the alarm, enter the correct user code.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the Kavey KS-56 safe's dual alarm system, showing how the vibration alarm is activated by pressing '9' and how both the vibration and incorrect code alarms sound, and how to deactivate them by entering the correct code.

## 5.3. Removable Shelf and Hidden Compartment

The safe features an adjustable interior for flexible storage and a hidden compartment for sensitive items.

- The interior shelf can be removed or adjusted to accommodate items of various sizes.

- A hidden compartment is located at the bottom of the safe, accessible by key, providing an extra layer of security for small, valuable items.

Your browser does not support the video tag.

Video 5.2: This video demonstrates the versatility of the Kavey KS-56 safe's interior, showcasing the removable and adjustable shelf and the secure hidden compartment accessible by key.

## 6. MAINTENANCE

- **Battery Replacement:** Replace all 4\*AA batteries when the low battery indicator lights up or if the keypad becomes unresponsive. Always use new, high-quality alkaline batteries.
- **Cleaning:** Clean the safe's exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.
- **Keypad Care:** Keep the keypad dry and free from dust or debris.

## 7. TROUBLESHOOTING

- **Safe will not open with code:**
  - Ensure batteries are not depleted. Replace if necessary.
  - Verify you are entering the correct code. Try re-entering slowly.
  - If the code is forgotten, use the emergency key to open the safe.
- **Keypad is unresponsive:**
  - Check battery connections and replace batteries.
  - Ensure no foreign objects are obstructing the buttons.
- **Alarm sounds unexpectedly:**
  - The vibration alarm may be active. Deactivate by entering the correct code.
  - Ensure no one has attempted to open the safe with incorrect codes.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Kavey
Model	KS-56
Product Dimensions	2.16"D x 9.45"W x 10.63"H
Lock Type	Electronic Combination Lock
Color	Black
Material	Alloy Steel
Special Feature	Alarm System
Mounting Type	Freestanding (Mountable)

Water Resistance Level	Not Water Resistant
Item Weight	50 pounds

## 9. WARRANTY AND SUPPORT

Kavey products are manufactured to high-quality standards. For warranty information, technical support, or any questions regarding your Kavey 2.6 Cub Home Safe, please refer to the contact information provided with your purchase or visit the official Kavey website. Please have your model number (KS-56) and purchase details ready when contacting support.

© 2023 Kavey. All rights reserved.