

BesLowe B04013P

BesLowe Outdoor Wall Mount Light Fixture (Model B04013P) - Instruction Manual

Model: B04013P | Brand: BesLowe

1. INTRODUCTION

Thank you for choosing the BesLowe Outdoor Wall Mount Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before installation and retain them for future reference.

Safety Information

- Always turn off the power at the main circuit breaker before beginning installation.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not exceed the maximum wattage specified for the bulb.
- Handle glass components with care to prevent breakage.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- BesLowe Outdoor Wall Mount Light Fixture (1 unit)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: Bulb is not included.



Image: Unboxing the BesLowe Outdoor Wall Lantern, revealing the pre-assembled fixture and included mounting hardware.

3. PRODUCT FEATURES

- **All-Weather Durability:** Sturdy metal construction and clear tempered glass panels ensure resistance to rain, high temperatures, and storms.

- **Waterproof & Anti-Rust:** Constructed from high-quality materials with a matte black finish to prevent rust and corrosion, extending product lifespan.
- **Sleek Modern Design:** Features clean glass elements and a matte black finish, suitable for various outdoor settings including porches, garages, doorways, backyards, patios, and entryways.
- **Easy Bulb Replacement:** Designed with an open bottom for convenient bulb changes and cleaning without disassembly.
- **E26 Socket:** Compatible with various E26 base bulbs, including LED, CFL, incandescent, and halogen bulbs (max 100W).




Image: The BesLowe Outdoor Wall Light Fixture showcasing its all-weather resistant properties against rain, snow, heat, and storms.





Image: Detailed view of the light fixture highlighting its anti-rust metal frame, high-strength glass panels, E26 bulb base, and convenient open bottom.

4. SPECIFICATIONS

Attribute	Detail
Brand	BesLowe
Model Number	B04013P
Color	Black
Material	Glass, Metal
Style	Modern & Farmhouse
Light Fixture Form	Sconce

Product Dimensions	4.7"L x 4.7"W x 12.8"H
Indoor/Outdoor Usage	Outdoor
Power Source	Hard-Wired
Installation Type	Wall Mount
Special Features	All Weather Resistant, Anti-Rust, No Assembly Required, Open-bottom Design, Waterproof
Light Source Type	Fluorescent, Halogen, Incandescent, LED
Finish Type	Matte Black
Shade Material	Glass
Number of Light Sources	1
Voltage	120 Volts (AC)
Bulb Base	E26
Wattage	100 watts (Max)
Water Resistance Level	Waterproof
Assembly Required	No

Product Details



**Recommended E26 Bulbs
(100W Max)**

(Bulbs Not Included)



Image: Detailed product dimensions (4.7"L x 4.7"W x 12.8"H) and a visual guide to compatible E26 bulb types (max 100W).

5. INSTALLATION INSTRUCTIONS

The BesLowe Outdoor Wall Mount Light Fixture comes pre-assembled for easy installation. Follow these steps to mount the fixture securely.

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting surface is clean and dry.
2. **Attach Mounting Plate:** Secure the provided mounting plate to your electrical junction box using the screws.
3. **Wire Connections:** Connect the fixture's wires to your household wiring. Connect the live (black) wire to the live wire, the neutral (white) wire to the neutral wire, and the ground (green/bare copper) wire to the ground wire. Use wire nuts to secure connections.
4. **Mount the Fixture:** Align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the wall.
5. **Install Bulb:** Insert an E26 base bulb (max 100W, not included) into the socket through the open bottom of the fixture.

6. **Restore Power:** Turn the power back on at the circuit breaker.

Your browser does not support the video tag.

Video: Official BesLowe video demonstrating the installation process and showcasing the modern outdoor wall lights in various settings.

6. OPERATING INSTRUCTIONS

Once installed, operate the light fixture using your standard wall switch. The fixture is designed for continuous outdoor use.

Bulb Replacement

To replace the bulb:

1. Turn off power to the fixture at the circuit breaker.
2. Allow the old bulb to cool completely before touching.
3. Reach into the open bottom of the fixture and unscrew the old E26 bulb.
4. Screw in a new E26 base bulb (max 100W).
5. Restore power at the circuit breaker.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your light fixture.

- **Cleaning:** Periodically wipe the fixture with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or glass.
- **Inspection:** Annually inspect the wiring and connections for any signs of wear or damage.
- **Glass Care:** The tempered glass panels can be cleaned with standard glass cleaner.

8. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power, loose wiring, faulty bulb	Check circuit breaker. Verify wire connections. Replace bulb.
Light flickers	Loose bulb, unstable power, incompatible bulb	Tighten bulb. Consult electrician. Ensure bulb is compatible with E26 socket.
Water inside fixture	Improper sealing during installation, damaged glass	Ensure fixture is properly sealed against the wall. Inspect glass for cracks.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact BesLowe customer service. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question