

Manuals.plus /
› Ibergrif /
› Ibergrif M85043 Kitchen Sink User Manual

Ibergrif M85043

Ibergrif M85043 Kitchen Sink User Manual

Model: M85043 | Brand: Ibergrif

INTRODUCTION

Thank you for choosing the Ibergrif M85043 Stainless Steel Kitchen Sink. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new kitchen sink. Please read this manual thoroughly before installation and keep it for future reference.



Figure 1: Ibergrif M85043 Kitchen Sink Overview

This image displays the top view of the Ibergrif M85043 kitchen sink, highlighting its brushed stainless steel finish and the central drain opening. The sink features clean lines and a modern aesthetic, suitable for various kitchen designs.

SAFETY INFORMATION

- Always wear appropriate personal protective equipment (PPE) such as gloves and safety glasses during installation.
- Ensure the water supply is turned off before beginning any installation work.
- Handle the sink with care to avoid scratches or damage to the finish.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep all small parts and packaging materials away from children.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- 1 x Ibergrif M85043 Kitchen Sink
- Drain assembly (strainer, basket, seals)
- Mounting clips/hardware
- Drain pipe components (P-trap, flexible hose)
- Installation manual (this document)




Figure 2: Included Components

This image provides an exploded view of the sink and its accompanying drain components, including the main sink body, drain strainer, basket, various pipes, and seals. It illustrates all the parts typically included for a complete installation.

SETUP AND INSTALLATION

The Ibergrif M85043 sink supports both topmount (drop-in) and undermount installation methods. Choose the method that best suits your countertop and design preference.

1. Prepare the Countertop

Based on your chosen installation method, mark and cut the opening in your countertop. Refer to the dimensions provided in Figure 4 and Figure 5 for precise measurements.

- **Topmount Installation:** The sink rim rests on the countertop. Cutout dimensions are typically 460-470mm (length) x 390-400mm (width) with R10 corner radius.
- **Undermount Installation:** The sink is mounted beneath the countertop. Cutout dimensions are typically 450mm (length) x 380mm (width) with R10 corner radius.



Topmount




Undermount

Figure 3: Topmount vs. Undermount Installation

This image visually compares the two primary installation methods: topmount (where the sink rim sits on the countertop) and undermount (where the sink is installed below the countertop surface), illustrating the finished appearance of each.

Tapping hole of topmount



Tapping hole of undermount




Figure 4: Tapping Hole Dimensions for Topmount and Undermount

This diagram provides precise measurements for the countertop cutout required for both topmount and undermount installations. It includes length, width, and corner radius specifications to ensure a proper fit for the sink.




Figure 5: Sink Dimensions

This technical drawing illustrates the overall dimensions of the Ibergrif M85043 sink, including its length (500mm), width (430mm), and

depth (200mm), along with internal basin measurements.

2. Install the Sink

1. Apply a bead of silicone sealant around the edge of the cutout on the countertop.
2. Carefully lower the sink into the opening (for topmount) or lift it into place from below (for undermount).
3. Secure the sink using the provided mounting clips. Tighten them evenly to ensure a snug fit and proper seal.
4. Wipe away any excess sealant immediately.

3. Assemble the Drain

Assemble the drain components as shown in Figure 2 and Figure 6. Ensure all seals are correctly seated to prevent leaks.

1. Insert the drain strainer into the sink's drain opening.
2. From underneath the sink, attach the rubber gasket and locking nut, tightening securely.
3. Connect the P-trap and flexible drain hose to the drain assembly and then to your household plumbing.
4. Ensure all connections are hand-tightened first, then use a wrench for a final snug fit, being careful not to overtighten.






Figure 6: Drain Assembly Components

This image provides a detailed exploded view of the individual components that make up the sink's drain system, including the strainer, gaskets, locking nuts, and various pipe sections, illustrating their order of assembly.

4. Test for Leaks

Once all connections are made, turn on the water supply and fill the sink. Check all connections for any signs of leaks. If leaks are detected, tighten the connections or re-seat the seals as necessary.

OPERATING INSTRUCTIONS

The Ibergrif M85043 sink is designed for everyday kitchen use. Its high capacity and efficient drainage system make daily tasks convenient.

- Use the sink for washing dishes, preparing food, and other kitchen activities.
- The included drain basket helps to catch food debris, preventing clogs in your plumbing.
- The X-channel design on the sink bottom promotes rapid water drainage, keeping the sink clean and dry.
- The overflow hole prevents the sink from overflowing if the faucet is left running.

MAINTENANCE

Proper care will ensure the longevity and appearance of your stainless steel sink.

- **Daily Cleaning:** After each use, rinse the sink thoroughly with water to remove food particles and soap residue. Wipe dry with a soft cloth to prevent water spots and mineral buildup.
- **Regular Cleaning:** For a deeper clean, use a mild dish soap or a specialized stainless steel cleaner with a soft sponge or cloth. Always rub in the direction of the grain.
- **Avoid Abrasives:** Do not use abrasive cleaners, steel wool, or harsh chemicals (like bleach or strong acids) as these can scratch or damage the stainless steel finish.

- **Prevent Stains:** Avoid leaving acidic foods (e.g., citrus, tomatoes) or corrosive substances in the sink for extended periods. Rinse immediately if they come into contact with the surface.
- **Sound Dampening:** The sound-insulating pads on the bottom of the sink help minimize noise during use.



Figure 7: Sound Dampening Pad

This image shows a close-up of the sound dampening pad applied to the underside of the sink, designed to reduce noise from water flow and dish impact.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaks from drain connections	Loose connections, improperly seated seals, damaged seals.	Tighten connections. Ensure gaskets are correctly positioned. Replace damaged seals if necessary.
Slow drainage	Drain basket clogged, P-trap obstruction.	Clear the drain basket of debris. Inspect and clear the P-trap.
Water spots/Stains on sink surface	Hard water deposits, food residue left to dry.	Wipe sink dry after each use. Use a stainless steel cleaner for stubborn spots.

SPECIFICATIONS

- Model:** M85043
- Brand:** Ibergrif
- Material:** High-Quality Stainless Steel
- Overall Dimensions (L x W x H):** 50 x 43 x 20 cm (19.7 x 16.9 x 7.9 inches)
- Inner Bowl Dimensions (L x W x H):** 45 x 38 x 20 cm (17.7 x 15 x 7.9 inches)
- Panel Thickness:** 3 mm
- Installation Type:** Undermount or Topmount
- Color:** Silver (Brushed Finish)
- Weight:** 6.4 kg (14.1 lbs)
- Drain Type:** Grid (with removable basket)
- Features:** X-channel drainage, Sound dampening pads, Overflow protection

WARRANTY AND SUPPORT

Ibergrif products are manufactured to high-quality standards. For any questions regarding installation, operation, or maintenance, please contact Ibergrif customer support. Please refer to your purchase documentation for specific warranty details.

For further assistance, visit the official Ibergrif store:[Ibergrif Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B6NWGWB3>

More documents and user manuals: <https://manuals.plus/>