

[Manuals.plus](#) /

› [TOUCHBeauty](#) /

› TOUCHBeauty Nail Dryer TB-2130 Instruction Manual

TOUCHBeauty TB-2130

TOUCHBeauty Nail Dryer TB-2130 Instruction Manual

INTRODUCTION

Thank you for choosing the TOUCHBeauty Nail Dryer TB-2130. This device is designed to provide fast and effective drying for regular nail polish on both fingers and toes. It features an integrated LED fan and light system, ensuring a comfortable and safe user experience without harmful UV radiation. Please read this manual thoroughly before use to ensure proper operation and care.



Image: The TOUCHBeauty Nail Dryer TB-2130 in operation, drying a user's hand.

SAFETY INFORMATION

- This nail dryer is designed for regular nail polish and peelable nail polish only. It is not suitable for gel polish.
- The device operates without harmful UV radiation, ensuring safety for eyes and skin.
- Ensure the device is used with the correct battery type (2 AAA batteries).
- Keep out of reach of small children.
- Do not immerse the device in water or any other liquid.



Image: Visual representation of the nail dryer's safety features, highlighting no UV light, no harm to eyes or hands, and no heat or pain.

SETUP

Battery Installation

1. Twist the top cover of the nail dryer anti-clockwise to open it.
2. Insert 2 AAA batteries into the battery compartment, ensuring correct polarity. Batteries are not included.
3. Place the top cover back onto the device and twist it clockwise to lock it securely.



Push down to switch on
Anticlockwise rotation to open the battery cap

Image: Step-by-step guide for installing 2 AAA batteries into the nail dryer, showing how to open and close the battery compartment.

Video: Battery Installation and Operation Overview

Your browser does not support the video tag.

Video: An official TOUCHBeauty video demonstrating the battery installation process and basic operation of the nail dryer.

OPERATING INSTRUCTIONS

1. After applying regular nail polish, gently press down on the top cover of the device. This action will activate the fan and LED light.
2. Place your hand or foot under the dryer, ensuring all painted nails are exposed to the airflow and light.
3. Allow approximately 60-120 seconds for effective drying. The actual drying time may vary depending on the thickness of the nail polish layers.
4. To turn off the device, simply lift your hand or foot from the sensor area, or press the top cover again.

Child



Student



Beginner



Image: The nail dryer in action, illustrating a hand placed underneath for drying, with an indication of 120 seconds for fast drying.

TOUCHBeauty

Anti-slip bottom

Practical for foot and hand



Image: The nail dryer's design, featuring an anti-slip bottom and demonstrating its practical use for both finger and toe nails.

MAINTENANCE

- Clean the exterior of the device with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- If the device will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Device does not turn on:** Ensure batteries are correctly installed with proper polarity and are not depleted. Replace batteries if necessary.
- **Weak airflow:** Check battery levels. If airflow remains weak after replacing batteries, contact customer support.
- **Light not working:** Verify battery installation and charge. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	TB-2130
Dimensions	4.69 x 2.83 x 2.83 inches
Weight	4.55 ounces
Power Source	2 x AAA Batteries (not included)
Voltage	3 Volts
Material	Plastic
Color	White





Image: Detailed dimensions of the nail dryer, illustrating its compact size.

WARRANTY & SUPPORT

The TOUCHBeauty Nail Dryer TB-2130 comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. For warranty claims or

technical support, please contact TOUCHBeauty customer service through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for warranty validation.