**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## VBGK K2003

# VBGK Electric Cooktop K2003 User Manual

Model: K2003

### Important Safety Information

Please read all instructions carefully before using the VBGK Electric Cooktop. Retain this manual for future reference. Improper operation may cause damage to the appliance or injury to the user.

- Ensure the cooktop is installed on a stable, level surface or properly built into a countertop.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

### Product Overview

The VBGK Electric Cooktop K2003 features two independent heating zones, knob controls, and multiple safety functions for efficient and safe cooking.




Image: The VBGK Electric Cooktop K2003, showcasing its dual heating zones and user-friendly knob controls.

## Setup and Installation

The VBGK Electric Cooktop K2003 is designed for both countertop use and built-in installation. Ensure proper ventilation and power supply before use.

- **Power Requirements:** The cooktop operates on 110-120V and has a total power rating of 2100W (1200W+900W). Ensure your electrical outlet meets these specifications.
- **Placement:** The unit can be placed directly on a countertop or integrated into a kitchen counter. Refer to the dimensions in the specifications section for built-in installation.
- **Ventilation:** Ensure adequate space around the cooktop for proper air circulation, especially for the bottom cooling fan.
- **Initial Cleaning:** Before first use, wipe the ceramic glass surface with a damp cloth.




Image: The cooktop illustrating its versatility for either countertop placement or built-in integration into a kitchen surface.

## Operating Instructions

The VBGK Electric Cooktop K2003 features intuitive knob controls for power adjustment and a timer function.

### Power Control

- **Turning On/Off:** Rotate the desired burner's knob clockwise to turn on and select a power level. Rotate counter-clockwise to turn off.
- **Power Levels:** There are 9 power levels (P1 to P9) available for each heating zone. Adjust the knob to select the appropriate heat setting for your cooking needs.




Image: Detail of the cooktop's control knobs and digital display, showing power level settings.

## Timer Function

- The cooktop includes an automatic timer that can be set for up to 120 minutes.
- To activate the timer, press the timer button (often indicated by a clock icon) and then use the corresponding knob to set the desired cooking duration.
- The cooktop will automatically turn off once the set time has elapsed.

## Child Lock

- The child lock feature prevents accidental operation.
- To activate or deactivate the child lock, press and hold the lock button (often indicated by a key or lock icon) for a few seconds until the indicator light changes.




Image: The cooktop displaying the child safety lock icon, indicating the feature is active or available.

## Overheat Protection

The cooktop is equipped with an overheat protection system that automatically shuts off the unit if it detects excessively high temperatures, preventing damage and ensuring safety.

## Residual Heat Indicator

After use, the cooktop surface may remain hot. An "H" indicator will appear on the display to warn that the surface is still hot to the touch, even after the burner has been turned off.




Image: The cooktop displaying the 'H' symbol, indicating residual heat on the cooking zone.

### Official Product Videos

Your browser does not support the video tag.

Video: This video demonstrates the operation of the VBGK Double Electric Cooktop, including power level adjustments and timer settings. It highlights the ease of use with knob controls.

Your browser does not support the video tag.

Video: A demonstration of the VBGK Double Electric Cooktop in use, showcasing its heating capabilities and control interface.

## Cookware Compatibility

The VBGK Electric Cooktop K2003 is compatible with a wide range of cookware types due to its radiant heating technology.

- **Compatible Cookware:** Aluminum pans, copper pans, cast iron frying pans, and non-magnetic stainless steel pans.
- **Requirement:** Always use flat-bottomed pots and pans for optimal heat transfer and stability.




Image: An illustration detailing the different types of cookware that can be used with the electric cooktop, including iron, stainless steel, casserole, aluminum, glass, copper, barbecue, and ceramic.

## Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your VBGK Electric Cooktop K2003.

- **Daily Cleaning:** After each use, allow the cooktop to cool completely. Wipe the ceramic glass surface with a clean, damp cloth. For stubborn stains, use a non-abrasive ceramic cooktop cleaner.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp objects like iron scrapers, as these can scratch or damage the glass surface.
- **Spills:** Clean spills immediately once the surface is cool to prevent them from baking onto the surface.




Image: The cooktop being cleaned with a soft cloth, emphasizing the importance of gentle cleaning and highlighting the bottom cooling fan.

## Troubleshooting

If you encounter issues with your VBGK Electric Cooktop K2003, refer to the following common problems and solutions:

| Error Code | Description | Possible Solution |
|---|---|---|
| E1 | Sensor on the control board is faulty. | Turn off the cooktop and unplug it. Wait a few minutes, then plug it back in and restart. If the error persists, contact customer support. |
| E2 | Short circuit in the thermistor of the touch pad. | Turn off the cooktop and unplug it. Wait a few minutes, then plug it back in and restart. If the error persists, contact customer support. |

For any other issues or if the above solutions do not resolve the problem, please contact VBGK customer support.

## Specifications

| Feature | Detail |
|---|---|
| **Model Number** | K2003 |
| **Brand** | VBGK |
| **Color** | Black |
| **Material** | Glass |
| **Product Dimensions (D x W x H)** | 20"D x 11.3"W x 3.14"H |
| **Number of Heating Elements** | 2 |
| **Heating Element Type** | Radiant |
| **Wattage** | 2100W (1200W+900W) |
| **Voltage** | 110-120 Volts |
| **Controls Type** | Knob |
| **Special Features** | Electric, Electric Stovetop Compatible, Manual Control, 9 Power Levels, Kids Lock, Timer, Overheat Protection |
| **Item Weight** | 4.34 Kilograms |
| **UPC** | 774803534788 |

*Note: The wattage and voltage information is based on the detailed feature description. Please refer to the product packaging or contact the manufacturer for the most accurate information for your specific model.*

## Warranty Information

The VBGK Electric Cooktop K2003 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.
Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or commercial use.

## Customer Support

For technical assistance, warranty claims, or any questions regarding your VBGK Electric Cooktop K2003, please contact VBGK customer support.
Refer to the contact information provided on the product packaging or the official VBGK website for the most up-to-date support details.
You can also visit the VBGK Store on Amazon for more product information and support resources.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0B6QWQZMZ**

More documents and user manuals: **https://manuals.plus/**