Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pawfan 752790727970

Pawfan TENS/EMS Microcurrent Mini Massager Machine User Manual

Model: 752790727970

For Full Body Pain Relief and Muscle Stimulation

1. Introduction

The Pawfan TENS/EMS Microcurrent Mini Massager Machine is a versatile physiotherapy instrument designed for full body pain relief and muscle stimulation. It combines Transcutaneous Electrical Nerve Stimulation (TENS) for non-invasive pain relief and Electrical Muscle Stimulation (EMS) to activate muscles, assisting in strength and endurance. This compact device is ideal for relieving fatigue and various body pains.



Figure 1: Pawfan TENS/EMS Mini Massager Unit in use.
This image shows the compact TENS/EMS unit with its two attached electrode pads, positioned on a person's upper back. The device is black with blue accents, indicating its controls and power status.

2. Important Safety Information

Please read all safety warnings and instructions before using this device. Failure to do so may result in injury or device malfunction.

- Always use on clean, dry skin.
- Avoid use on the face, head, or genitals.
- Keep away from water. Do not use in wet environments.
- Do not use if you have a pacemaker or other implanted medical device.
- Consult a doctor before use if you are pregnant, have epilepsy, or any other medical condition.
- Always follow the instructions provided with the device.
- For first-time use, it is suggested to apply the device to your back due to varying sensitivities across different body parts.

3. Product Components

Your Pawfan TENS/EMS Mini Massager Machine package includes the following:

- Main TENS/EMS Unit (Black)
- 2 x Individually Packaged Electrode Pads
- USB Charging Cable
- User Manual (this document)



Figure 2: Included components.
This image displays the main TENS/EMS unit, two electrode pads, and the USB charging cable, which are the primary components included in the product package.

4. Setup and Charging

4.1 Initial Charging

Before first use, fully charge the device. The unit features a powerful rechargeable battery.

1. Connect the provided USB charging cable to the charging port on the TENS/EMS unit.
2. Plug the other end of the USB cable into a wall charger, power bank, or USB outlet.
3. A battery level indicator will remind you to charge the device when needed.
4. A full charge can provide up to 30 days of use if used for one hour per day. Approximately 30 minutes of charging provides 5 hours of continuous use.



Figure 3: Charging the device.
This image illustrates the TENS/EMS unit connected to a USB cable for charging, highlighting its rechargeable capability.

4.2 Attaching Electrode Pads

The electrode pads are designed for easy attachment to the main unit.

1. Ensure the skin where the pad will be applied is clean and dry. Wetting the skin slightly before use can improve adhesion.
2. Carefully remove the protective film from the electrode pads.
3. Attach the pads securely to the main TENS/EMS unit via the snap connectors.

5. Operating Instructions

Follow these steps to operate your Pawfan TENS/EMS Mini Massager:

1. **Step 1: Apply to Skin.** Place the assembled massager (unit with pads attached) on the desired body part. Ensure good contact with the skin. Note: Skin with too much hair may affect the effect.
2. **Step 2: Power On.** Press the "ON/INC" button once to turn on the device. The first light will illuminate.
3. **Step 3: Start Pulse.** Press the "ON/INC" button again. The first light will flash, and the TENS pulse will begin.
4. **Step 4: Adjust Intensity.**
    - Press the "ON/INC" button to increase the intensity level.
    - Press the "OFF/DEC" button to decrease the intensity level.

    The device offers 10 levels of intensity.
5. **Step 5: Change Mode.** Press the "PROGRAM" button to cycle through the 6 available modes. It is recommended to use different modes alternately for beneficial treatment and fatigue relief.
6. **Step 6: Power Off.** Press the "OFF/DEC" button to turn off the machine.

Automatic Shut-off: After 15 minutes of massage, the machine automatically shuts down and stops working. 15 minutes is considered one working cycle. After a period of use, take the machine off the skin; it will automatically shut down.




Figure 4: Step-by-step usage guide.
This diagram visually guides the user through the process of turning on the device, starting the pulse, adjusting intensity, and changing modes.

5.1 Available Modes

The device features 6 streamlined modes (A-F) and 10 intensity levels for professional-grade pain relief and muscle stimulation.




Figure 5: Multiple modes and intensity levels.

This image demonstrates the variety of modes (A-F) and the 10 intensity levels available on the device, allowing for customized therapy.

6. Maintenance and Care

6.1 Electrode Pad Care

Proper care of the electrode pads will extend their lifespan.

- If the pad's adhesive becomes less effective, it can be washed with clean water and allowed to air dry.
- Each pad can typically be used for 15-30 applications.
- Store replacement pads in their individual airtight bags to maintain their adhesive quality.
- Replacement pads can be purchased separately (search for B0BKQQ94ML).

6.2 Device Cleaning and Storage

- Wipe the main unit with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- Store the device and pads in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues with your device, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Ensure the device is fully charged using the provided USB cable.
No sensation or weak pulse.	Pads not adhering properly, low intensity, or worn-out pads.	Ensure pads are firmly pressed onto clean, dry skin. Increase intensity using the "ON/INC" button. Clean pads with water and air dry if adhesive is weak. Replace pads if they are old or no longer effective.
Pads do not stick.	Dirty pads or worn-out adhesive.	Wash pads with clean water and air dry. If problem persists, replace pads.
Device shuts off unexpectedly.	Automatic 15-minute cycle completion or low battery.	This is normal operation after 15 minutes. If it happens sooner, recharge the device.

If the issue persists after trying these solutions, please contact customer support.

8. Product Specifications

Feature	Detail
Product Dimensions	1.14 x 2.83 x 5.98 inches
Item Weight	2.75 ounces
Model Number	752790727970
Power Source	Battery Powered (Rechargeable)

Feature	Detail
Material	Plastic
Color	Black
Modes	6 Modes
Intensity Levels	10 Levels
Auto Shut-off	15 minutes

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Pawfan website. Keep your purchase receipt as proof of purchase.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2025 Pawfan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6RY29XZ

More documents and user manuals: **https://manuals.plus/**