

[Manuals.plus](#) /

› [DailyBody](#) /

› Sound Machine White Noise Machine with 30 Soothing Sounds 36 Levels Volume 5 Timers and Memory Function Effectively Blocks Noise
Ideal Sleep Machine for Baby Kids Adults... (Black)

DailyBody DWN-Z1

DailyBody White Noise Machine User Manual

Model: DWN-Z1

1. INTRODUCTION

Thank you for choosing the DailyBody White Noise Machine. This device is designed to help you create a peaceful and conducive environment for sleep, relaxation, and focus by effectively masking unwanted noises. It features a wide variety of soothing sounds, adjustable volume levels, and convenient timer functions.



Image: The DailyBody White Noise Machine, a compact black rectangular device with control buttons on its top surface, designed for ease

of use and portability.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the device to ensure safe and proper operation.

- **CAUTION:** To avoid risk of electric shock, use only the provided power adapter or USB charging cable.
- Do not use damaged cords or plug into damaged outlets.
- This device emits sound; do not expose children or adults to loud sounds for extended periods to avoid hearing damage.
- This is not a toy; keep out of reach of children under 3 years old.
- Always follow the instructions in the user manual for safe operation.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- DailyBody White Noise Machine (Model: DWN-Z1)
- USB Charging Cable (Type-C)
- Power Adapter
- User Manual (this document)



Image: The DailyBody White Noise Machine, its USB-C charging cable, and power adapter, all included in the product packaging.

4. SETUP

To set up your DailyBody White Noise Machine:

1. Connect the provided USB charging cable to the Type-C port on the back of the sound machine.
2. Plug the other end of the USB cable into the power adapter.
3. Insert the power adapter into a standard electrical outlet.
4. The device is now ready for use.

Easy to Use

Type - C interface A plug can be used immediately



Image: A close-up view of the DailyBody White Noise Machine, highlighting the Type-C charging port located on its rear side, with the charging cable connected.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- Press the **Power** button (🔌) to turn the device on or off.

5.2. Sound Selection

The machine offers 30 soothing sounds. Use the **Previous Track** (⏮) and **Next Track** (⏭) buttons to cycle through the available sounds.

- **White Noises (3)**: Brown Noise, White Noise, Pink Noise
- **Fan Sounds (2)**: Loud Fan, Soft Fan
- **Natural Sounds (16)**: 4 Rain sounds, 3 Wave sounds, 2 Brook sounds, River, 2 Water Drop sounds, Singing Birds,

Train, Campfire, Fireplace

- **Other Sounds (9):** 5 Lullabies, Heart's Beating, Meditation, Piano, Hushing Sound

30 Soothing Sounds



2

Fan Sounds



3

White Noise



16

Natural Sounds



9

Other Sounds



Image: The DailyBody White Noise Machine displayed with icons illustrating the variety of 30 soothing sounds available, categorized into fan, white noise, natural, and other sounds.

5.3. Volume Adjustment

- The machine features 36 levels of adjustable volume.
- Press the + button to increase the volume.
- Press the - button to decrease the volume.

Louder Speaker



A louder speaker can block out ambient noise and help you fall asleep faster




Image: The DailyBody White Noise Machine with visual sound waves emanating from it, illustrating its louder speaker capability to block ambient noise.

5.4. Timer Settings

The sound machine has 5 timer settings:

- Press the **Timer** button (🕒) to cycle through the options: 1 hour, 2 hours, 3 hours, 4 hours, or continuous playback.
- The corresponding indicator light on the top of the device will illuminate to show the selected timer duration.



Image: The DailyBody White Noise Machine positioned on a nightstand next to a sleeping man, with visual representations of its adjustable timer settings (1h, 2h, 3h, 4h, and continuous play).

5.5. Memory Function

The device remembers and restores the last used sound and volume level when you turn it on again.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	3.54 x 2.79 x 2.55 inches
Item Weight	7.23 ounces
Model Number	DWN-Z1
Brand	DailyBody

Material	Plastic
Power Source	Corded Electric
Sound Options	30 Soothing Sounds
Volume Levels	36 Levels
Timer Options	1h, 2h, 3h, 4h, Continuous

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Not properly connected to power.	Ensure the USB cable and power adapter are securely connected to the device and a working electrical outlet.
No sound or low volume.	Volume is too low or muted.	Press the + button to increase the volume.
Sound quality is poor.	Interference or speaker obstruction.	Ensure the speaker grille is not obstructed. Move the device away from other electronic devices that may cause interference.
Timer function not working as expected.	Incorrect timer setting.	Press the Timer button to select the desired duration. Ensure the correct indicator light is illuminated.

8. WARRANTY AND SUPPORT

This white noise machine is safe and guaranteed. If you have any questions or require support, please contact DailyBody customer service. Refer to the product packaging or the seller's information on the purchase platform for contact details.

9. PRODUCT MEDIA

9.1. Product in Use

Observe the DailyBody White Noise Machine in various settings, demonstrating its compact design and ease of integration into daily life.

DailyBody[®]

White Noise Machine

Sleep Better and Relax More



Image: The DailyBody White Noise Machine placed on a wooden nightstand beside a bed, suggesting its use for sleep and relaxation.

Sleep Better

- Block out ambient noise that interferes with sleep
- Fall asleep with soothing sounds




Image: The DailyBody White Noise Machine on a desk beside a laptop, indicating its suitability for creating a focused work environment.

30 Soothing Sound



2 Fan Sounds



3 White Noise



9 Ambient Sounds



16 Natural Sounds



Singing Birds



Campfire




Sea Wave



Train



River



White Noise



ThunderStorm



Piano



Water Drop



Lullabies

Image: The DailyBody White Noise Machine positioned near a sleeping child, highlighting its use for soothing babies and kids.

9.2. Official Product Videos

No official product videos from the seller are available for embedding at this time.

© 2023 DailyBody. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question