

[manuals.plus](#) /

› [Einhell](#) /

› [Einhell Cordless pipe cleaner TE-DA 18/760 Li-Solo Power X-Change \(18 V, Li-ion, 7.6 m long cleaning spiral, suitable for pipe diameter 16-55 mm, battery and charger not included\)](#)

## Einhell TE-DA 18/760 Li-Solo

# Einhell Cordless Pipe Cleaner TE-DA 18/760 Li-Solo Instruction Manual

Model: TE-DA 18/760 Li-Solo

## 1. INTRODUCTION

---

The Einhell TE-DA 18/760 Li-Solo cordless pipe cleaner is designed to efficiently clear blockages in pipes. As a member of the Power X-Change family, it offers flexible compatibility with other Einhell Power X-Change batteries and chargers. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your device.



Image 1.1: The Einhell TE-DA 18/760 Li-Solo cordless pipe cleaner, showing its compact design and the cleaning spiral extending from the front.

## 2. SAFETY INFORMATION

---

Always read and understand all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- Keep the work area clean and well-lit.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool.
- Wear appropriate personal protective equipment, including safety glasses, gloves, and non-slip footwear.
- Ensure the pipe cleaner is switched off and the battery is removed before making any adjustments, changing accessories, or storing power tools.
- Do not force the power tool. Use the correct power tool for your application.
- Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the power tool's operation.

## 3. COMPONENTS AND PACKAGE CONTENTS

---

The Einhell TE-DA 18/760 Li-Solo cordless pipe cleaner package includes the following:

- Cordless pipe cleaner unit
- Cleaning spiral (7.6 m length, 7 mm diameter)

**Note: Battery and charger are NOT included and must be purchased separately.**



Image 3.1: Visual reminder that the battery and charger are not included with the pipe cleaner.

## 4. SETUP

### 4.1 Battery Installation

This device operates on an 18V Power X-Change battery.

1. Ensure the pipe cleaner is switched off.
2. Align the battery pack with the battery receptacle on the tool.
3. Slide the battery pack into the tool until it clicks securely into place.
4. To remove, press the battery release button and slide the battery out.





Image 4.1: The Einhell Power X-Change battery system, illustrating the wide range of compatible tools and the central battery unit.

## 5. OPERATING INSTRUCTIONS

The Einhell TE-DA 18/760 Li-Solo is designed for cleaning pipes with diameters ranging from 16 mm to 55 mm. The 7.6-meter long, 7 mm thick galvanized spiral effectively tackles blockages.

### 5.1 Controls Overview

- **Forward/Neutral/Reverse Lever:** This lever controls the direction of the spiral's movement (in or out) and stops it.
- **Direction of Rotation Switch:** This switch controls the rotational direction of the spiral (clockwise or counter-clockwise) to effectively break up blockages.
- **LED Light:** An integrated LED light illuminates the work area for better visibility.



Image 5.1: Close-up view of the forward/neutral/reverse lever, used to control the spiral's feed direction.



Image 5.2: Close-up view of the main trigger and the direction of rotation switch, located near the handle.

## 5.2 Cleaning Procedure

1. Ensure the battery is fully charged and properly installed.
2. Position the pipe cleaner near the drain opening.
3. Insert the cleaning spiral into the pipe.
4. Use the forward/neutral/reverse lever to feed the spiral into the pipe. The driven feed allows for automatic retraction and removal.
5. Once the spiral encounters a blockage, use the direction of rotation switch to engage clockwise or counter-clockwise rotation to break up the obstruction. The locking mechanism can be used for stubborn dirt.
6. Continue feeding and rotating the spiral until the blockage is cleared.
7. Once the pipe is clear, use the lever to retract the spiral back into the drum.





Image 5.3: A user operating the Einhell pipe cleaner to clear a sink drain, demonstrating typical usage.



Image 5.4: A detailed view of the flexible cleaning spiral, ready for insertion into a pipe.

## 6. MAINTENANCE

---

### 6.1 Cleaning the Drum

The drum of the pipe cleaner can be easily cleaned of dirty water thanks to the inlet and outlet openings. After each use, especially when dealing with dirty water, it is recommended to:

- Remove the battery.
- Drain any remaining water from the drum through the designated openings.
- Rinse the drum and spiral with clean water to remove debris.
- Allow all components to dry thoroughly before storage to prevent rust and odor.

### 6.2 Spiral Care

The galvanized and rust-proof spiral is designed for longevity. To ensure its continued performance:



- Always clean the spiral after use.
- Inspect the spiral for any signs of damage or wear. Replace if necessary.
- Store the device in a dry place.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery not inserted correctly or discharged.	Ensure battery is fully inserted. Charge battery if necessary.
Spiral not moving.	Forward/Neutral/Reverse lever in neutral position; severe blockage.	Move lever to forward or reverse. Apply more pressure or use rotational switch to break up blockage.
Spiral gets stuck.	Spiral encountered a very stubborn blockage or sharp bend.	Reverse the spiral direction briefly, then try again. Do not force.

## 8. SPECIFICATIONS

Model Number	TE-DA 18/760 Li-Solo (4514160)
Power Source	Battery (Power X-Change 18V)
Spiral Length	7.6 meters
Spiral Diameter	7 mm
Suitable Pipe Diameter	16 - 55 mm
Item Weight	7.96 pounds
Special Features	Convenient cleaning of the drum thanks to outlet openings, LED light



Image 8.1: Icons illustrating key specifications: suitable pipe diameter (16-55mm), rotational directions (R/L), and the zinc-coated coil length (7.6m).

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Einhell website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance or to purchase compatible Power X-Change batteries and chargers, please visit the [Einhell official website](#).



Related Documents - TE-DA 18/760 Li-Solo

	<p><a href="#">Einhell TE-VC 18/10 Li - Solo Akku-Nass-Trockensauger Bedienungsanleitung</a></p> <p>Betriebsanleitung für den Einhell TE-VC 18/10 Li - Solo Akku-Nass-Trockensauger. Enthält Sicherheitshinweise, Gerätebeschreibung, technische Daten, Montage-, Bedienungs-, Reinigungs- und Wartungsanweisungen.</p>
	<p><a href="#">Einhell TE-AG 18/115-2 Li Akku-Winkelschleifer Bedienungsanleitung</a></p> <p>Die offizielle Bedienungsanleitung für den Einhell TE-AG 18/115-2 Li Akku-Winkelschleifer. Enthält wichtige Informationen zur sicheren Handhabung, technischen Daten und Wartung des kabellosen Winkelschleifers von Einhell.</p>
	<p><a href="#">Einhell TE-MB 18/127 Li Akku-Bandsäge Bedienungsanleitung</a></p> <p>Originalbetriebsanleitung für die Einhell Akku-Bandsäge TE-MB 18/127 Li. Enthält Sicherheitshinweise, Bedienung, Wartung und technische Daten.</p>
	<p><a href="#">Einhell TE-AG 18/115 Li BL-Solo Cordless Angle Grinder Operating Instructions</a></p> <p>Comprehensive guide for the Einhell TE-AG 18/115 Li BL-Solo Cordless Angle Grinder, covering safety, operation, maintenance, and technical specifications.</p>
	<p><a href="#">Einhell TE-VC 18 Li Akku-Handstaubsauger - Originalbetriebsanleitung</a></p> <p>Umfassende Betriebsanleitung für den Einhell TE-VC 18 Li Akku-Handstaubsauger, inklusive Sicherheitshinweisen, technischen Daten, Montage-, Bedienungs- und Wartungsanleitungen sowie Garantieinformationen. Teil des Power X-Change Systems.</p>

<div data-bbox="140 123 290 168"><p><b>Einhell</b> TE-CD 18/50 Li-i BL 18 V Lithium-Ionen-Akku Cordless Hammer Drill/Screwdriver</p></div> <div data-bbox="140 280 290 336"><p>7 CE Einhell Power-Tools Einhell Power-Tools Einhell Power-Tools</p></div>	<div data-bbox="341 152 1340 190"><p><a href="#">Einhell TE-CD 18/50 Li-i BL Cordless Hammer Drill/Screwdriver - Operating Instructions</a></p></div> <div data-bbox="341 197 1436 309"><p>Comprehensive operating instructions for the Einhell TE-CD 18/50 Li-i BL cordless hammer drill/screwdriver, covering safety, technical data, operation, maintenance, disposal, and warranty information.</p></div>
---	---