

[Manuals.plus](#) /

› [ESR](#) /

› ESR Rebound Series Case for iPad (A16) 11th/10th Generation Instruction Manual

ESR bdc_pad2022_bk_eu

ESR Rebound Series Case

INSTRUCTION MANUAL FOR iPad (A16) 11TH/10TH GENERATION

1. Introduction

This manual provides detailed instructions for the proper use, installation, and maintenance of your ESR Rebound Series Case. Designed for the iPad (A16) 11th/10th Generation, this case offers robust protection, versatile functionality, and a sleek design to enhance your tablet experience.

2. Compatibility

The ESR Rebound Series Case is specifically designed for the following iPad models:

- iPad (A16) 11th Generation (2025)
- iPad 10th Generation (2022), models A3354, A3355, A2696, A2757

To confirm compatibility, please check the back bottom of your iPad for the model number, which typically starts with "AXXXX". This case is not compatible with other iPad models.

Only for iPad 11" (A16) 2025, iPad 10th Gen 2022



**iPad 11" (A16) 2025,
iPad 10th Gen 2022**



iPad Air 10.9" (5th/4th Gen)



**iPad Air 11" (M3) 2025,
Air 11" (M2) 2024**

Please Double Check



Model A2696

In California Mode **A2696**
Serial: DMPXKA2VKD6U



**Verify your model number
before ordering**

Models

iPad 11" (A16) 2025,
iPad 10th Gen 2022:
A3354, A3355, A2696, A2757

*Locate the model number on the back of your iPad

This diagram provides essential compatibility information, indicating that the case is designed for iPad 11-inch (A16) 2025 and iPad 10th Generation 2022 models (A3354, A3355, A2696, A2757). It also includes a visual guide on how to locate your iPad's model number for verification.

3. Key Features

3.1 Secure Magnetic Attachment

The case features powerful magnets that ensure a strong and secure lock between the case and your iPad. This

magnetic connection provides stability and ease of attachment/detachment.



This image displays the ESR Rebound Series Case in black, securely attached to an iPad. The case is shown folded into a stable trifold stand, highlighting its magnetic attachment and versatile viewing angle.

3.2 Lightweight Protection

The Rebound Series Case is engineered to protect every inch of your tablet from drops and bumps while maintaining its sleek profile. Its lightweight design ensures convenient portability without adding unnecessary bulk.

Lightweight Protection

Defends against scratches without the bulk

 2.5 mm

 260 g



This visual emphasizes the case's lightweight yet protective design. It highlights the slim 2.5 mm profile and the overall weight of 260 grams, ensuring robust protection without adding significant bulk to your iPad.

3.3 Two-Way Trifold Stand

The magnetic trifold cover can be easily folded into a stable stand, offering two distinct positions: a viewing mode for media consumption and a writing mode for comfortable typing or drawing with your Pencil.

Stable Trifold Stand

2 stand positions for added versatility



► Viewing mode



► Writing mode



This image illustrates the two versatile stand positions offered by the trifold cover. The top shows the 'Viewing mode,' ideal for watching videos or presentations. The bottom shows the 'Writing mode,' providing an ergonomic angle for typing or using a stylus.

3.4 Auto Sleep/Wake Function

The case reacts instantly to maximize your iPad's battery life. Opening the cover automatically wakes your iPad, and closing it puts the device to sleep.

Smooth and Grippy

Rubberized surface provides a comfortable grip



This image demonstrates the seamless auto sleep/wake feature. Opening the cover instantly wakes your iPad, and closing it puts the device to sleep, helping to conserve battery life.

3.5 Easy-to-Clean Surface

Constructed from advanced material, the case provides powerful stain resistance. Smudges and pen marks can be easily wiped off, ensuring your case stays looking clean for longer.



This image focuses on the case's exterior, highlighting its smooth and grippy rubberized surface. This material provides a comfortable and secure hold, reducing the risk of accidental slips.

4. Setup Instructions

1. **Clean Your iPad:** Before attaching the case, ensure your iPad's back and edges are clean and free of dust or debris.
2. **Align the iPad:** Carefully align your iPad with the back panel of the ESR Rebound Series Case. The camera cutout and port openings should match perfectly.
3. **Magnetic Attachment:** The powerful magnets within the case will automatically align and securely attach your iPad to the back panel. Ensure all edges are flush.
4. **Verify Fit:** Gently press around the edges of the iPad to ensure it is fully seated and securely held by the magnets.

5. Operating the Case

- **Using the Trifold Stand:**
 - a. For *Viewing Mode*: Fold the front cover into a triangular stand behind the iPad. The magnets will hold it in

place, providing an upright angle suitable for watching videos or video calls.

- b. For *Writing Mode*: Fold the front cover into a lower, more angled triangular stand. This position is ideal for typing, drawing, or browsing with a comfortable incline.

- **Auto Sleep/Wake:** Simply open the front cover to automatically wake your iPad. Close the cover to put your iPad to sleep and conserve battery.

6. Maintenance and Care

To ensure the longevity and appearance of your ESR Rebound Series Case, follow these care instructions:

- **Cleaning:** Use a soft, damp cloth to wipe down the surface of the case. For stubborn smudges or marks, a small amount of mild soap can be used, followed by wiping with a clean, damp cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical solutions, as these can damage the case material.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use for extended periods.

7. Troubleshooting

- **iPad Not Attaching Securely:**
 - Ensure your iPad model is compatible with the case (refer to Section 2).
 - Check for any debris or foreign objects between the iPad and the case that might prevent a flush magnetic connection.
 - Verify the iPad is correctly aligned with the case's magnetic points.
- **Auto Sleep/Wake Not Working:**
 - Ensure the case cover is fully closed and making contact with the iPad screen.
 - Check your iPad settings to ensure the "Lock/Unlock" feature (for Smart Covers) is enabled. This is usually found under Display & Brightness settings.
 - Restart your iPad to resolve any temporary software glitches.

8. Specifications

Attribute	Detail
Brand	ESR
Series	Rebound
Item Model Number	bdc_pad2022_bk_eu
Compatible Devices	iPad 11" (A16) 2025, iPad 10th Gen 2022: A3354, A3355, A2696, A2757
Standing Screen Display Size	10.9 Inches
Item Weight	9.4 ounces
Product Dimensions (LxWxH)	9.88 x 7.26 x 0.59 inches
Color	Black
Manufacturer	Electronic Silk Road Corp

Shell Type	Hybrid
------------	--------

9. Warranty and Customer Support

ESR provides comprehensive customer support for its products. Your ESR Rebound Series Case comes with a 12-month protection plan.

For detailed setup videos, FAQs, personalized help, or to inquire about the 12-month protection plan, please refer to the product packaging or visit the official ESR website. You can also find support information on the ESR store page on Amazon.

Online Resources:

- ESR Official Website: www.esrgear.com
- ESR Amazon Store: [Amazon.com/ESR](https://www.amazon.com/ESR)

© 2025 ESR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0B6VP16FB>

More documents and user manuals: <https://manuals.plus/>