

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 24V AC/DC Adapter for Powerfit PL-1911 Foot Massager Instruction Manual

UPBRIGHT Powerfit pl-1911 Foot Massager 24V Power

UpBright 24V AC/DC Adapter Instruction Manual

For Powerfit PL-1911 PowerLegs Vibration Plate and Electric Shiatsu Foot Massager Platforms

1. PRODUCT OVERVIEW

The UpBright 24V AC/DC Adapter is designed to provide a stable and reliable power source for compatible devices. This adapter is specifically engineered to be compatible with the Powerfit PL-1911 PowerLegs Power Fit Platform Vibration Plate and Electric Shiatsu Foot Massager platforms, as well as models like XH2400-1500W. It features built-in safety protections to ensure secure operation.

Security Protection

Multiple professional protection, so that fast
Charge more safe



Image 1.1: The UpBright AC/DC Adapter is compatible with Powerfit PowerLegs Foot Massager platforms.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Do not** expose the adapter to water or moisture.
- **Do not** disassemble or modify the adapter.
- **Do not** use the adapter if the cable is damaged.
- Ensure the adapter is connected to a power outlet with the correct voltage (100-240VAC).
- Keep the adapter away from heat sources and direct sunlight.
- Unplug the adapter from the power outlet when not in use for extended periods.

This adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.




Image 2.1: The adapter features multiple security protections including overvoltage, overheat, overcharge, and overcurrent protection.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x UpBright 24V AC/DC Adapter
- 1 x AC Power Cord (suitable for your region)

Come With A Suitable AC Power Cord (Only One)
to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



Image 3.1: The product includes an AC power cord appropriate for the country of purchase.

4. SETUP

Follow these steps to set up your UpBright AC/DC Adapter:

1. **Verify Compatibility:** Ensure your device requires a 24V DC power input and has a compatible barrel round connector. This adapter is designed for Powerfit PL-1911 and XH2400-1500W models.
2. **Connect to Device:** Insert the barrel connector of the adapter cable firmly into the power input port of your Powerfit device.
3. **Connect to Power Outlet:** Plug the AC power cord into the adapter, then plug the other end of the AC power cord into a standard wall outlet (100-240VAC, 50/60Hz).
4. **Power On:** Once connected, your device should receive power. Refer to your device's manual for specific power-on procedures.




Image 4.1: The adapter features a premium cable design and connects directly to a power outlet.

5. OPERATING INSTRUCTIONS

The UpBright AC/DC Adapter operates automatically once connected to a compatible device and a power source. It provides continuous 24V DC power to your device. There are no user-adjustable settings on the adapter itself.

- Ensure the adapter is securely plugged into both the device and the wall outlet.
- Monitor the device for proper function after connecting the adapter.
- If the device does not power on, refer to the Troubleshooting section.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a dry, soft cloth to wipe the adapter. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures.
- **Cable Care:** Avoid bending or crimping the cable excessively. Do not place heavy objects on the cable.



Image 6.1: The adapter features a flexible and durable wire designed for longevity.

7. TROUBLESHOOTING

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Adapter not properly connected. Incorrect power outlet. Device incompatibility.	Ensure all connections are secure. Try a different wall outlet. Verify device power requirements match adapter specifications.
Adapter feels hot.	Normal operation (slight warmth). Overload or poor ventilation.	Ensure adapter is in a well-ventilated area. Disconnect if excessively hot and check device power draw.
Loose connection.	Connector not fully inserted. Worn connector.	Push the connector firmly into the device's port. If the connector is worn, replacement may be necessary.

8. SPECIFICATIONS

Feature	Specification
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	24V DC
Output Amperage	1.5A (1500mA)
Output Wattage	30W
Connector Type	Barrel Round Connector
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	4 x 2 x 2 inches
Item Weight	5 ounces
Color	Black

9. WARRANTY AND SUPPORT

UpBright products are designed for reliability and performance.

- **Refund Policy:** UpBright offers a 30-day refund period from the date of purchase.
- **Exchange Policy:** The product is covered by a 24-month exchange warranty.

For warranty claims or technical support, please contact UpBright customer service through the retailer where the product was purchased or visit the official UpBright website for contact information.



Image 9.1: The product comes with a limited warranty certificate.

© 2024 UpBright. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

