



[Manuals.plus](#) /

> [JUBEST](#) /

> JUBEST Bypass Double Glass Barn Door 84x84in with 7.5FT Side-Mounted Hardware Kit (Model KDA04)

## JUBEST KDA04

# JUBEST Bypass Double Glass Barn Door Instruction Manual

Model: KDA04

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your JUBEST Bypass Double Glass Barn Door. Please read all instructions carefully before beginning installation to ensure safe and correct usage. Keep this manual for future reference.

## 2. SAFETY INFORMATION

---

- Always wear appropriate safety gear, including gloves and eye protection, during assembly and installation.
- The glass panels are tempered but can still break if mishandled. Handle with care.
- The door system is heavy. It is recommended that at least two people assist with assembly and installation to prevent injury.
- Ensure the wall structure is capable of supporting the weight of the door system. Reinforcement may be necessary.
- Keep children and pets away from the work area during installation.
- Do not modify the product in any way not described in this manual.

## 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer service immediately.

# UNIQUE DESIGN



## High Quality Frame

Made of aluminum which is anti-rust and corrosion-resistant



## Clear & Tempered Glass

CE certified tempered glass which is high hardness, scratch-resistant and wear-resistant




Image: Overview of the JUBEST Bypass Double Glass Barn Door package contents, including two glass door panels and the 7.5ft hardware kit.

- 2 x Clear Tempered Glass Door Panels (42x84 inches each, combining to 84 inches total width)
- 2 x Rails (3.75FT each, combining to 7.5FT total length)
- 2 x Anti-jump Blocks
- 4 x Roller Hangers
- 2 x Floor Guides
- 2 x Stoppers
- All other necessary hardware sets (screws, anchors, etc.)

## 4. SETUP AND ASSEMBLY

The JUBEST Bypass Double Glass Barn Door is designed for easy assembly, but careful attention to detail is required. All panels are mitered for a snug fit. The bottom of each door has a pre-made groove for the floor guide.

## 4.1 Pre-Installation Checks

- **Wall Preparation:** Ensure the wall where the track will be mounted is structurally sound and can support the door's weight (approximately 140 lbs). Reinforce if necessary.
- **Opening Measurement:** The door system is designed to fit a maximum opening width of 77 3/4 inches and a maximum opening height of 82 inches. Verify your opening dimensions. A minimum of 6 inches clearance is needed above the door opening for track installation.




Image: Diagram illustrating the bypass sliding door size chart, showing dimensions for the 84x84 inch door and required opening width/height, including 6 inches clearance above the door.

## 4.2 Tools Required (Not Included)

- Drill
- Measuring Tape
- Level
- Pencil
- Screwdriver Set (ensure correct bit sizes for provided screws)
- Clamps (recommended for securing panels during assembly)

### 4.3 Assembly Steps (General Overview)

1. Assemble the aluminum frame components for each door panel.
2. Carefully insert the clear tempered glass panels into the assembled frames. Ensure a snug fit.
3. Attach the roller hangers to the top of each door panel.
4. Mount the 7.5FT track (assembled from two 3.75FT rails) to the wall above the door opening, ensuring it is level and securely fastened to studs or with appropriate anchors.
5. Hang the assembled door panels onto the track.
6. Install the anti-jump blocks and stoppers on the track to prevent the doors from derailing or sliding too far.
7. Install the floor guides into the pre-made grooves at the bottom of the doors to ensure smooth and stable sliding.

*Note: Detailed step-by-step diagrams are typically included in the physical instruction booklet. Refer to those for precise assembly sequences and hardware identification.*

## 5. OPERATING INSTRUCTIONS

---

Your JUBEST Bypass Double Glass Barn Door is designed for smooth and quiet operation. To open or close the door, gently slide the panels along the track. The bypass design allows one door to slide in front of the other, providing flexible access to your space.



Image: A JUBEST Bypass Double Glass Barn Door installed in a modern home, showcasing its functionality and aesthetic appeal.

## 5.1 Features

- **Smooth Sliding:** The roller hangers and track system ensure effortless movement.
- **Quiet Operation:** Designed to minimize noise during opening and closing.
- **Space-Saving:** Ideal for areas where traditional swinging doors are impractical.
- **Natural Light:** Clear tempered glass allows light to pass through, brightening your space.

## 6. MAINTENANCE

---

Regular maintenance will ensure the longevity and optimal performance of your JUBEST Bypass Double Glass Barn Door.

### 6.1 Cleaning

- **Glass Panels:** Clean with a standard glass cleaner and a soft, lint-free cloth. Avoid abrasive cleaners or tools that could scratch the glass.

- **Aluminum Frame:** Wipe the aluminum frame with a damp cloth and mild soap. Dry thoroughly. Avoid harsh chemicals.
- **Track and Rollers:** Periodically wipe the track to remove dust and debris. Check rollers for any buildup that might impede smooth operation.

## 6.2 Hardware Inspection

- Regularly check all screws and fasteners to ensure they are tight. Retighten as needed.
- Inspect roller hangers and floor guides for wear or damage. Replace components if necessary.

## 7. TROUBLESHOOTING

If you encounter issues with your barn door, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Difficulty during assembly	Incorrect tools, misaligned parts, heavy glass panels.	Ensure you have the correct metric screwdriver bits. Use clamps to hold heavy glass panels in place during frame assembly. Work with a second person.
Doors do not slide smoothly or quietly	Track not level, debris in track, loose rollers, damaged floor guide.	Check track for levelness and adjust if necessary. Clean the track and rollers. Ensure rollers are securely attached. Inspect and adjust floor guides.
Doors jump off the track or floor guide	Anti-jump blocks not installed or adjusted correctly, floor guide loose or misaligned.	Verify anti-jump blocks are installed and positioned correctly. Secure and align the floor guides.
Glass appears foggy after cleaning	Residue from cleaning product, improper cleaning technique.	Use a dedicated glass cleaner and a clean, lint-free microfiber cloth. Wipe in one direction to avoid streaks.

If the problem persists after attempting these solutions, please contact JUBEST customer service.

## 8. SPECIFICATIONS

Feature	Detail
Brand	JUBEST
Model	KDA04
Door Dimensions (each panel)	42 x 84 inches
Total Door Width (combined)	84 inches
Track Length	7.5 FT (assembled from two 3.75 FT rails)
Material	Aluminum, Clear Tempered Glass

Feature	Detail
Color	Black Frame
Style	Modern
Item Weight	140 Pounds
Required Assembly	Yes
Max Opening Width Fit	77 3/4 inches
Max Opening Height Fit	82 inches

## 9. SUPPORT

---

JUBEST is committed to providing quality products and excellent customer service. For any quality problems, missing parts, or installation issues, please do not hesitate to contact us. Our professional customer service team is available to assist you.

For further assistance, please visit the [JUBEST Store on Amazon](#).