

SANODESK 156E

SANODESK Electric Standing Desk

MODEL 156E - USER MANUAL

Brand: SANODESK

1. Introduction

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your SANODESK Electric Standing Desk, Model 156E. Please read this manual thoroughly before use to ensure proper function and safety.

2. Safety Information

Important Safety Warnings:

- Do not exceed the maximum weight limit of 176 lbs (79.8 kg).
- Ensure the desk is placed on a level surface and is stable before use.
- Keep children and pets away from the desk during operation.
- Avoid placing objects that could be damaged by movement under the desk.
- Do not disassemble or modify the desk's electrical components. Contact customer service for repairs.
- Always use the desk in accordance with the manufacturer's instructions to prevent injury.

3. Product Overview

The SANODESK Electric Standing Desk is designed to provide a versatile and ergonomic workspace. Key features include:

- **Spacious Desktop:** A 55 x 28 inch (139.7 x 71.1 cm) whole-piece desktop offers ample space for multiple monitors, laptops, and other office essentials.
- **Electric Lifting System:** Smooth and quiet height adjustment.
- **6-Button Controller:** Features up/down arrows and four programmable memory presets for quick height adjustments.
- **Sturdy Construction:** Industrial-grade steel frame for stability and durability.
- **Integrated Hooks:** Convenient hooks for headphones or bags.
- **Rounded Corners:** Enhanced safety and aesthetic appeal.



Figure 3.1: SANODESK Electric Standing Desk in standing position.

One-Piece Desk

Spacious and neat desk surface




Figure 3.2: The spacious one-piece desktop design.

4. Assembly Instructions

Assembly of the SANODESK Electric Standing Desk is designed to be straightforward. Please refer to the separate assembly guide included in your package for detailed, step-by-step instructions. Ensure all components are present before beginning assembly.

- Unpack all components and verify against the parts list in the assembly guide.

- Follow the provided diagrams and instructions carefully.
- Ensure all screws and fasteners are securely tightened.
- Connect the power cable to a suitable outlet after assembly is complete.

5. Operating Instructions

Your SANODESK features an intuitive 6-button control panel for easy height adjustment.



I Intelligent Keyboard

Four memory height adjustment buttons

Figure 5.1: The 6-button control panel.

5.1. Height Adjustment

- **Up/Down Buttons:** Press and hold the **Up (▲)** or **Down (▼)** arrow buttons to manually raise or lower the desk to your desired height. The current height will be displayed on the LED screen.
- The desk operates smoothly and quietly, allowing for seamless transitions between sitting and standing positions.

5.2. Memory Presets

The control panel includes four memory buttons (1, 2, 3, 4) to save and recall your preferred sitting and standing heights.

- **To Save a Height:** Adjust the desk to your desired height using the Up/Down buttons. Press the **M** button (often indicated by a person icon) followed by one of the number buttons (1, 2, 3, or 4). The height is now saved to that preset.
- **To Recall a Height:** Simply press the corresponding number button (1, 2, 3, or 4) for your saved height. The desk will automatically move to that position.

Adjust the Height Arbitrarily

28.9"-46.5"/154LBS



Figure 5.2: Height adjustment range from 28.9 to 46.5 inches.

6. Care and Maintenance

To ensure the longevity and optimal performance of your SANODESK Electric Standing Desk, follow these care guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The frame surface is coated with a fine, smooth paint that is waterproof and rustproof, making it easy to clean.

- **Cable Management:** Periodically check and organize cables to prevent tangles and damage.
- **Regular Inspection:** Ensure all screws and connections remain tight.

7. Troubleshooting

If you encounter any issues with your desk, refer to the following common troubleshooting tips:

- **Desk Not Moving:** Check if the power cable is securely plugged into both the desk and the wall outlet. Ensure no obstructions are blocking the desk's movement.
- **Error Codes:** If an error code appears on the LED display, consult the detailed troubleshooting section in your separate assembly guide or contact customer support. Some users have reported intermittent error codes when adjusting height too frequently.
- **Unstable Movement:** Verify that the desk is on a flat surface and that all assembly screws are tightened.

8. Specifications

Feature	Detail
Brand	SANODESK
Model Name	156E
Product Dimensions	55"W x 28"D x 28"H (139.7 cm W x 71.1 cm D x 71.1 cm H)
Minimum Height	28 Inches (71.1 cm)
Maximum Height	45.7 Inches (116.1 cm)
Top Material Type	Mahogany
Base Material	Metal (Thickened Steel Pipe)
Maximum Weight Recommendation	176 lbs (79.8 kg)
Control Panel	6-Button with LED Display and 4 Memory Presets
Assembly Required	Yes
UPC	810072819512

| Product Size



Figure 8.1: Product dimensions.

9. Warranty and Support

SANODESK is committed to your satisfaction. If you encounter any problems upon receiving or using your product, we offer a 30-day return or exchange service. Please contact customer service through your order page for assistance.

For further support or inquiries, please visit the official SANODESK store on Amazon: [SANODESK Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question