VssoPlor B0B71HMJ6Y

VssoPlor Wireless Keyboard and Mouse Combo User Manual

Model: B0B71HMJ6Y

PRODUCT OVERVIEW

This manual provides detailed instructions for the VssoPlor 2.4GHz Ultra-Slim Aluminum Rechargeable Wireless Keyboard and Mouse Combo. It covers setup, operation, maintenance, troubleshooting, and specifications to ensure optimal performance and longevity of your device.

Image: The VssoPlor Wireless Keyboard and Mouse Combo, featuring a white gold keyboard, matching mouse, and a USB receiver.

PACKAGE CONTENTS

- 1 x VssoPlor Wireless Keyboard
- 1 x VssoPlor Wireless Mouse

- 1 x USB Receiver (for both keyboard and mouse)

- 1 x Charging Cable

- 1 x User Manual (this document)

SETUP INSTRUCTIONS

1. Charging the Devices

Both the keyboard and mouse come with built-in lithium batteries. Before first use, it is recommended to fully charge both devices.

1. Connect the provided charging cable to the charging port on the keyboard (usually located on the top edge).
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The Charging Indicator light on the keyboard will illuminate during charging and turn off when fully charged.
4. Repeat the process for the wireless mouse. The mouse typically has a charging port on its front or bottom.

Image: Close-up of the keyboard showing the charging indicator, Fn Lock, NumLock, Caps Lock, and Power indicators, along with the

2. Connecting the Wireless Combo

The keyboard and mouse share a single 2.4GHz USB receiver for a strong and reliable connection.

1. Locate the USB receiver, usually stored in a compartment on the bottom of the mouse or keyboard.
2. Insert the USB receiver into an available USB port on your computer or laptop.
3. Turn on the keyboard using the power switch (typically on the top right edge).
4. Turn on the mouse using its power switch (usually on the bottom).
5. The devices should automatically connect to your computer. No additional software installation is required.

Image: Illustration showing the USB receiver plugged into a laptop, with the keyboard and mouse nearby, indicating wireless connectivity.

OPERATING INSTRUCTIONS

Keyboard Usage

The keyboard features a full-size layout with whisper-quiet keys for comfortable and smooth typing. It includes hot keys for quick access to applications and media control.

- **Function Keys (F1-F12):** Many function keys have secondary multimedia or system control functions. These are typically accessed by pressing the **Fn** key simultaneously with the desired function key.
- **Indicators:** The keyboard has indicator lights for Charging, Fn Lock, NumLock, and Caps Lock.

ABS Material , Whisper-quiet Keys

Durable Metal Material

Image: Close-up of the keyboard highlighting the ABS material and whisper-quiet keys, along with the durable metal material of the base.

Mouse Usage

The precision mouse offers adjustable DPI settings for varied usage needs.

- **DPI Adjustment:** The mouse features an adjustable DPI switch (800/1200/1600 DPI). Press the DPI button (usually located behind the scroll wheel) to cycle through the sensitivity levels.
- **Whisper-Quiet Click:** The mouse is designed for quiet operation, minimizing click noise.

Image: Diagram of the mouse showing the DPI button and indicating the 800/1200/1600 DPI settings, along with the whisper-quiet click area.

Compatibility

The VssoPlor Wireless Keyboard and Mouse Combo is compatible with Windows XP, Vista, Win 7, Win 8, and Win 10. It can be used with laptops, PCs, and desktops.

FULL SIZE & ULTRA SLIM DESIGN

16.85in

4.92in

0.16in

0.59in

Image: Visual representation of the keyboard and mouse combo alongside a laptop and a desktop computer, illustrating compatibility.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the devices frequently. Recharge them when the low battery indicator appears.
- **USB Receiver:** When not in use, you can store the USB receiver in its designated slot on the mouse to prevent loss.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low battery; USB receiver not properly connected; devices not powered on.	Charge the devices. Ensure the USB receiver is firmly plugged into a working USB port. Turn on both the keyboard and mouse.
Lag or intermittent connection	Interference from other wireless devices; too far from receiver; low battery.	Move closer to the receiver. Ensure no large metal objects are between the devices and receiver. Charge the devices. Try a different USB port.

Problem	Possible Cause	Solution
Mouse cursor erratic or not moving smoothly	Dirty optical sensor; unsuitable surface; low battery.	Clean the optical sensor on the bottom of the mouse. Use the mouse on a clean, non-reflective surface or a mouse pad. Charge the mouse.
Keyboard keys not working	Low battery; debris under keys; software issue.	Charge the keyboard. Gently clean around and under the affected keys. Restart your computer.

SPECIFICATIONS

Brand: VssoPlor

Model: B0B71HMJ6Y

Connectivity: 2.4GHz Wireless (USB Receiver)

Keyboard Dimensions: 16.85 x 4.92 x 0.59 inches

Item Weight: 1.52 pounds

Keyboard Material: Ultra-Slim Aluminum Design

Key Type: Whisper-Quiet Keys

Mouse DPI: 800/1200/1600 (Adjustable)

Battery: Built-in Rechargeable Lithium Batteries (for both keyboard and mouse)

Compatibility: Windows XP, Vista, Win 7, Win 8, Win 10 (Laptop, PC, Desktop)

Color: White Gold

Image: Diagram illustrating the dimensions of the keyboard and mouse.

WARRANTY AND SUPPORT

VssoPlor products are designed for reliability and performance. For warranty information, technical support, or any inquiries regarding your Wireless Keyboard and Mouse Combo, please refer to the contact information provided on the product packaging or visit the official VssoPlor website.

You can also visit the VssoPlor Store on Amazon for additional resources and support.

IMPORTANT SAFETY INFORMATION

- Do not expose the devices to liquid or excessive moisture.
- Avoid dropping or subjecting the devices to strong impacts.
- Do not attempt to disassemble or repair the devices yourself. Contact qualified service personnel.
- Keep out of reach of children.
- Dispose of batteries and electronic components responsibly according to local regulations.