

[Manuals.plus](#) /

› [DÉBUT](#) /

› DÉBUT Asymmetrical Bob Lace Front Wig - 1B Black Color User Manual

DÉBUT Asymmetrical Bob Wig

DÉBUT Asymmetrical Bob Lace Front Wig User Manual

Model: Asymmetrical Bob Wig (1B Black Color)

Brand: DÉBUT

INTRODUCTION

Welcome to your DÉBUT Asymmetrical Bob Lace Front Wig. This manual provides essential information for the proper setup, care, and maintenance of your new wig, ensuring its longevity and your satisfaction. Please read these instructions carefully before use.

PRODUCT FEATURES

- **Lace Construction:** Soft 2-layer lace with a 1.5"x5" deep lace part. The outer layer is hand-tied lace, and the inner layer features a simulated scalp for a natural appearance.
- **Hairline:** Signature pre-plucked hairline with ear-to-ear HD lace front and baby hair, designed to protect your natural hair.
- **Hair Type:** High-quality heat-resistant synthetic fibers, capable of withstanding temperatures up to 400°F.
- **Texture:** Weak Yaki Straight texture.
- **Style:** Asymmetrical bob cut, with one side intentionally longer than the other.
- **Wig Cap:** Breathable rose net cap with an average size, featuring adjustable straps and 3 combs for a secure and comfortable fit.
- **Color:** 1B Black Color.

SETUP AND WEARING INSTRUCTIONS

Preparing the Wig

Upon receiving your wig, gently shake it out of the package. Hang it on a wig stand for some time to allow the fibers to settle. Use your fingers to gently comb the wig initially to remove any tangles from packaging.

Wearing the Wig

Place the wig on your head, ensuring the two ear cushions are positioned next to your ears. This helps align the wig correctly. Adjust the adjustable straps at the back of the cap and use the three combs inside the cap to secure the wig comfortably and firmly. The asymmetrical style means one side is longer; you can wear it asymmetrically or style it to appear even based on your

preference.

début



Can slay your edges



Can cut the baby hair



Many of baby hair can be styled freely

This image demonstrates the natural appearance of the wig when worn, showcasing the pre-plucked hairline and styled baby hairs.

début



A detailed view of the wig's lace front, showing the realistic simulated scalp and the hand-tied lace with baby hairs around the hairline for a natural look.



Elastic Net

- Breathable, soft and comfortable stretch hair cap



3 Combs

- Combs on both sides and back help secure wig easily



Flexible Ear Tab

- Comfortable cushions on both sides to help you easily put the wig in the correct position

This image illustrates the internal structure of the wig cap, featuring the breathable elastic net, three combs for secure attachment, and flexible ear tabs for proper positioning.



The adjustable straps at the back of the wig cap allow for a secure and comfortable fit for various head sizes.

Your browser does not support the video tag.

This video provides a quick guide on wearing the DÉBUT bob wig, showing how to achieve a new look in just one minute.

CARE AND MAINTENANCE

General Care Tips

- Do not brush your wig when it is wet.
- Allow the wig to air-dry or use a low-temperature setting if blow-drying. Brush only after it is completely dry.
- Use a mild shampoo and conditioner specifically designed for synthetic wigs.
- Consider using a detangling spray when wearing the wig to prevent knots.
- Wash your wig approximately every 2-3 weeks, or when it appears dull. Always hand wash.
- Avoid high heat settings when blow-drying to prevent damage to knots or fibers.

- Do not sleep with the wig on. Store it on a wig stand in a cool, dry place when not in use.
- Avoid spraying gel water or wax on the wig, as this can make it oily.
- If hair becomes knotted after extended use, apply a non-oily wig maintenance fluid.

Washing Instructions

1. Brush the wig with a wide-tooth comb. For curly wigs, comb only the head portion and use fingers for the curly sections.
2. Add a small amount of mild shampoo to cold or warm water.
3. Gently swish the wig in the water until saturated, soaking for about 15 minutes. Avoid scrubbing.
4. Hand wash only; do not use a washing machine.
5. Empty the water and rinse the wig several times with clean, cool water.
6. Gently squeeze excess water from the wig. Do not wring or twist.
7. Spread the wig out on a dry towel and allow it to air dry at a low temperature. Avoid direct sunlight.

début[®]



Back view of the wig on a mannequin, showing the overall style and length.



An inside view of the wig cap, detailing the lace and mesh construction for breathability and comfort.

TROUBLESHOOTING

Common Issues

- **Shedding:** Some initial shedding is normal. Excessive shedding may indicate improper care or brushing. Follow care instructions carefully.
- **Tangling:** Use a wide-tooth comb and detangling spray. Avoid harsh brushing, especially when wet.
- **Unnatural Look:** Ensure the lace is properly trimmed and baby hairs are styled. The simulated scalp should blend naturally.
- **Wig Fit:** Adjust the internal straps and use the combs to secure the wig. The flexible ear tabs help with correct positioning.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Weight	120g
Length	9.5 Inches
Type	Lace Front Wig
Style	Asymmetrical Bob Wig
Material	High Temperature Fiber (Synthetic Hair)
Texture	Weak Yaki Straight
Lace Type	2 Layers, 5" Hand Tied Lace Outside, 5" Simulated Scalp Inside
Hairline	Pre-plucked, ear to ear hand tied lace front, baby hair along the hairline
Heat Resistance	Up to 400°F
Wig Cap	Breathable rose net, adjustable straps, 3 combs
Color	1B Black
Package Dimensions	10.63 x 7.52 x 2.17 inches
Unit Count	1.00 Count

WARRANTY AND SUPPORT

Warranty Information

Warranty details for this product are not explicitly provided in the available information. Please refer to the retailer's return policy or contact DÉBUTonlineshop for specific warranty terms.

Customer Support

For further assistance or inquiries, please visit the official DÉBUT store on Amazon: [DÉBUT Store](#).

Manufacturer: DÉBUT

ADDITIONAL INFORMATION

Your browser does not support the video tag.

This video displays the DÉBUT bob wig in multiple colors, demonstrating the style across different shades.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question