Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Safeguard Supply ERA-RXPG

Safeguard Supply ERA-RXPG Wireless Doorbell Chime Receiver

INSTRUCTION MANUAL

1. Introduction

The Safeguard Supply ERA-RXPG is a plug-in wireless doorbell chime receiver designed to expand your existing Safeguard Supply ERA Series wireless doorbell system. This receiver provides both audible alerts up to 90dB and a visual flashing strobe light, ensuring notifications are received in various environments. It is engineered for long-range performance and reliable operation within the ERA Series ecosystem.



Image 1.1: Front view of the Safeguard Supply ERA-RXPG receiver, showing the speaker grille and the clear strobe light housing at the top.

2. Package Contents

Verify that your package contains the following item:

- 1 x Safeguard Supply ERA-RXPG Plug-in Receiver

3. Product Features

- UL Listed & FCC Certified for safety and compliance.
- Designed for expansion of Safeguard Supply ERA Series wireless doorbell kits and driveway sensors.
- Utilizes Duty Cycle technology for extended range up to 4,000ft (approximately 1,219 meters).
- Loud 90dB wireless doorbell chime with adjustable volume.
- Three distinct modes of operation: Flashing Strobe Only, Chime Only, and Strobe & Chime.
- Allows for adding multiple receivers to a single system.

4. Setup

4.1. Powering On

Plug the ERA-RXPG receiver into a standard 120V AC wall outlet. The unit will power on automatically.

4.2. Pairing with Transmitters

The ERA-RXPG receiver must be paired with a compatible Safeguard Supply ERA Series transmitter (e.g., doorbell button, driveway sensor) to function. Refer to the specific instructions provided with your ERA Series transmitter for detailed pairing procedures. Generally, pairing involves placing the receiver into a learning mode and then activating the transmitter.



Image 4.1: Angled view of the ERA-RXPG receiver, highlighting its compact design suitable for wall outlets.

5. Operating Modes

The ERA-RXPG receiver offers three operational modes, selectable via the 'MODE' button located on the side of the unit. The 'Music Note' button adjusts the chime sound or volume.

1. **Flashing Strobe Only:** Provides a visual alert for approximately 15 seconds without an audible chime. Ideal for quiet environments or users with hearing impairments.
2. **Chime Only:** Produces an audible alert with one of four selectable volume levels. No flashing strobe light in this mode.
3. **Strobe & Chime:** Activates both the flashing strobe light and the audible chime simultaneously.



Image 5.1: Front view of the ERA-RXPG receiver, illustrating the flashing strobe light in action.



Image 5.2: Side view of the ERA-RXPG receiver, clearly showing the 'Music Note' button (for chime/volume) and the 'MODE' button (for operating modes).

6. Installation

The ERA-RXPG receiver is designed for simple plug-in installation. Insert the receiver directly into any standard indoor 120V AC wall outlet. Ensure the outlet is easily accessible and not obstructed. For optimal performance, avoid plugging

the receiver into outlets controlled by a switch that may be turned off inadvertently.



Image 6.1: Back view of the ERA-RXPG receiver, displaying the two-prong plug and the product information label.

7. Maintenance

- **Cleaning:** Wipe the receiver with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Location:** Ensure the receiver is plugged into a stable outlet and not subject to excessive heat, moisture, or direct sunlight.

- **Interference:** While designed to resist interference, avoid placing the receiver near large metal objects or other strong radio frequency sources that could potentially reduce range.

8. Troubleshooting

Issue	Possible Cause	Solution
Receiver does not chime or flash.	Not powered on; Not paired; Transmitter issue; Out of range.	Ensure receiver is securely plugged in. Re-pair the receiver with the transmitter. Check transmitter battery/power. Move receiver closer to transmitter.
Intermittent or false alerts.	Interference; Transmitter malfunction; Proximity to other wireless devices.	Relocate receiver or transmitter away from potential interference sources. Check transmitter for damage or low battery.
Difficulty pairing.	Incorrect pairing procedure; Transmitter not in pairing mode.	Review the pairing instructions for both the receiver and your specific ERA Series transmitter. Ensure both devices are in pairing mode simultaneously.
Chime is too quiet or too loud.	Volume setting.	Press the 'Music Note' button on the side of the receiver to cycle through volume levels.

9. Specifications

Specification	Detail
Model Number	ERA-RXPG
Manufacturer	Safeguard Supply
Dimensions	4.75 x 2.75 x 1.5 inches (12.07 x 6.99 x 3.81 cm)
Item Weight	7.8 ounces (221 grams)
Color	White
Material	ABS Plastic
Installation Method	Plug-in
Sound Output	Up to 90dB
Wireless Range	Up to 4,000ft (1,219 meters)
Certifications	UL Listed, FCC Approved
Power Source	AC Plug-in (120V)

10. Warranty and Support

For warranty information, technical support, or further assistance with your Safeguard Supply ERA-RXPG receiver, please contact Safeguard Supply directly. Refer to the manufacturer's official website or product packaging for the most current contact details and warranty terms.

Manufacturer: Safeguard Supply, LLC
Website: www.safeguardsupply.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B727Y8DS

More documents and user manuals: **https://manuals.plus/**